

ACTIVE CUBE

Operating Instructions
Frequency inverter 230 V / 400 V
0.25 kW ... 132 kW



TABLE OF CONTENTS

1	General Information about the Documentation	11
1.1	Instruction Manuals	11
1.2	This document	12
1.3	Warranty and liability	13
1.4	Obligation	13
1.5	Copyright	14
1.6	Storage	14
2	General safety instructions and information on use	15
2.1	Terminology	15
2.2	Designated use	15
2.3	Misuse	16
2.3.1	Explosion protection	16
2.4	Residual risks	16
2.5	Safety and warning signs on frequency inverter	16
2.6	Warning information and symbols used in the Operating Instructions	17
2.6.1	Hazard classes	17
2.6.2	Hazard symbols	17
2.6.3	Prohibition signs	17
2.6.4	Personal safety equipment	18
2.6.5	Recycling	18
2.6.6	Grounding symbol	18
2.6.7	ESD symbol	18
2.6.8	Information signs	18
2.6.9	Font style in documentation	18
2.7	Directives and guidelines to be adhered to by the operator	19
2.8	Operator's general plant documentation	19
2.9	Operator's/operating staff's responsibilities	19
2.9.1	Selection and qualification of staff	19
2.9.2	General work safety	19
2.9.3	Ear protectors	19
2.10	Organizational measures	20
2.10.1	General	20
2.10.2	Use in combination with third-party products	20
2.10.3	Handling and installation	20
2.10.4	Electrical connections	20
2.10.4.1	The five safety rules	20
2.10.5	Safe operation	21
2.10.6	Maintenance and service/troubleshooting	22
2.10.7	Final decommissioning	22
2.11	Safety Instructions on Function "Safe Torque Off" (STO)	23
3	Storage and transport	24
3.1	Storage	24
3.2	Special safety instructions on transport of heavy frequency inverters	24
3.3	Dimensions/weight	25

3.4	Transfer to place of installation	25
3.5	Unpacking the device	25
3.6	Bringing the device into installation position	25
3.6.1	Sizes 1 through 6	25
3.6.2	Sizes 7 and 8	25
4	Scope of supply	27
4.1	Sizes 1 and 2: ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)	27
4.2	Sizes 3 and 4: ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)	28
4.3	Size 5 ACU 401 (18.5 to 30.0 kW)	29
4.4	Size 6 ACU 401 (37.0 to 65.0 kW)	30
4.5	Size 7 ACU 401 (75.0 to 132.0 kW)	31
5	Technical data	32
5.1	General technical data.....	32
5.2	Technical Data – Control Electronic Equipment	33
5.3	ACU 201 Size 1 (0.25 to 1.1 kW, 230 V)	35
5.4	ACU 201 Size 2 (1.5 to 3.0 kW, 230 V)	36
5.5	ACU 201 sizes 3 and 4 (4.0 to 9.2 kW, 230 V).....	37
5.6	ACU 401 Size 1 (0.25 to 1.5 kW, 400 V)	38
5.7	ACU 401 Size 2 (1.85 to 4.0 kW, 400 V)	39
5.8	ACU 401 sizes 3 and 4 (5.5 to 15.0 kW, 400 V).....	40
5.9	ACU 401 Size 5 (18.5 to 30.0 kW, 400 V)	41
5.10	ACU 401 Size 6 (37.0 to 65.0 kW, 400 V)	42
5.11	ACU 401 Size 7 (75.0 to 132.0 kW, 400 V).....	43
5.12	Operation diagrams.....	44
6	Mechanical installation	46
6.1	Air circulation	46
6.2	Sizes 1 and 2: ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW).....	46
6.3	Sizes 3 and 4: ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)	48
6.4	Size 5: ACU 401 (18.5 to 30.0 kW)	49
6.5	Size 6: ACU 401 (37.0 to 65.0 kW) (air-cooled).....	50
6.6	Size 7: ACU 401 (75.0 to 132.0 kW)	51
7	Electrical installation.....	52
7.1	EMC information.....	54
7.2	Block diagram.....	56
7.3	Optional components	57
7.4	Connection of Unit.....	58
7.4.1	Dimensioning of conductor cross-section.....	58
7.4.1.1	Typical cross-sections Size 1 through 7 (0.25 kW ... 132 kW)	58
7.4.2	Mains connection.....	60
7.4.3	Motor connection.....	60

7.4.3.1	Length of motor cables, without filter	61
7.4.3.2	Motor cable length, with output filter dU/dt	61
7.4.3.3	Motor cable length, with sinus filter	61
7.4.3.4	Group drive	61
7.4.3.5	Speed sensor connection	61
7.4.4	Connection of a braking resistor	62
7.5	Connection by size	63
7.5.1	Sizes 1 and 2: ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)	63
7.5.2	Sizes 3 and 4: ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)	65
7.5.3	Size 5 ACU 401 (18.5 to 30.0 kW)	67
7.5.4	Size 6 ACU 401 (37.0 to 65.0 kW)	69
7.5.5	Size 7 ACU 401 (75.0 to 132.0 kW)	71
7.6	Control terminals	73
7.6.1	External DC 24 V power supply	75
7.6.2	Relay output	75
7.7	X13 connection in ACU 501 and ACU 601	76
7.7.1	Motor Thermo-Contact	76
7.7.2	Control terminals – Wiring diagrams of configurations	76
7.8	Configurations overview	77
7.8.1	Configuration 110 – Sensorless Control	78
7.8.2	Configuration 111 – Sensorless Control with Technology Controller	78
7.8.3	Configuration 410 – Sensorless Field-Oriented Control	79
7.8.4	Configuration 411 – Sensorless Field-Oriented Control with Technology Controller	79
7.8.5	Configuration 430 – Sensorless Field-Oriented Control, speed and torque controlled	80
7.8.6	Configuration 210 – Field-Oriented Control, Speed Controlled	81
7.8.7	Configuration 211 – Field-Oriented Control with Technology Controller	82
7.8.8	Configuration 230 – Field-Oriented Control, Speed and Torque Controlled	82
7.8.9	Configuration 510 – Field-Oriented Control of Synchronous Machine, Speed Controlled	83
7.8.10	Configuration 511 – Field-Oriented Control of Synchronous Machine with Technology Controller	84
7.8.11	Configuration 530 – Field-Oriented Control of a Synchronous Machine Speed and Torque Controlled	84
7.8.12	Configuration 610 – Sensorless Field-Oriented Control of Synchronous Machine, Speed Controlled	85
7.8.13	Configuration 611 – Sensorless Field-Oriented Control of Synchronous Machine with Technology Controller	85
7.8.14	Configuration 630 – Sensorless Field-Oriented Control of a Synchronous Machine Speed and Torque Controlled	86
7.9	Notes on installation as per UL508c	86
8	Control unit KP500	87
8.1	Menu structure	88
8.2	Main Menu	88
8.3	Actual Value Menu (VAL)	89
8.4	Parameter Menu (PARA)	90
8.5	Copy Menu (CPY)	91
8.5.1	Reading the Stored Information	91
8.5.2	Menu structure	91
8.5.3	Selecting the Source	92
8.5.4	Selecting the Destination	92
8.5.5	Copy Operation	93
8.5.6	Error messages	93
8.6	Reading Data From Control Unit	94

8.6.1	Activation.....	94
8.6.2	Data transfer.....	95
8.6.3	Resetting to Normal Operation	96
8.7	Control Menu (CTRL)	96
8.8	Controlling the Motor via the Control Unit.....	97
9	Commissioning of frequency inverter	99
9.1	Turn mains voltage on.....	99
9.2	Setup Using the Control Unit.....	99
9.2.1	Configuration	100
9.2.2	Data Set	102
9.2.3	Motor Type	103
9.2.4	Machine data	103
9.2.5	Plausibility check	104
9.2.6	Parameter identification	105
9.2.7	Status messages during commissioning (SS...)	106
9.2.8	Warnings during commissioning (SA...)	106
9.2.9	Error messages during commissioning (SF...)	108
9.2.10	Application data	108
9.2.10.1	Acceleration and deceleration	109
9.2.10.2	Set points at multifunction input	109
9.2.11	Quitting commissioning.....	109
9.2.12	Selection of an actual value for display	110
9.3	Check direction of rotation.....	110
9.4	Speed sensor	111
9.4.1	Speed Sensor 1	111
9.4.2	Speed Sensor 2	112
9.5	Set-up via the Communication Interface	112
10	Inverter data	115
10.1	Serial Number.....	115
10.2	Optional Modules.....	115
10.3	Inverter Software Version.....	115
10.4	Set Password	115
10.5	Control Level	115
10.6	User Name	115
10.7	Configuration.....	116
10.8	Language	120
10.9	Programming.....	120
11	Machine data	121
11.1	Rated motor parameters	121
11.2	Further motor parameters.....	122
11.2.1	Stator resistance	122
11.2.2	Leakage coefficient.....	122
11.2.3	Magnetizing Current	123
11.2.4	Rated slip correction factor	123
11.2.5	Voltage Constant	124
11.2.6	Stator inductance	124

11.2.7	Peak current	125
11.2.8	Reverse sense of rotation.....	125
11.3	Internal values	125
11.4	Speed Sensor 1.....	126
11.4.1	Operation Mode Speed Sensor 1.....	126
11.4.2	Division Marks, Speed Sensor 1	128
11.4.3	Gear factor speed sensor 1	128
11.4.4	Filter time constant, Speed Sensor 1.....	129
11.5	Sensor evaluation.....	130
12	System data	131
12.1	Actual value system.....	131
12.2	Volume Flow and Pressure	131
13	Operating behavior	132
13.1	Starting behavior.....	132
13.1.1	Starting Behavior of Sensorless Control System	132
13.1.1.1	Starting current	133
13.1.1.2	Frequency Limit.....	134
13.1.1.3	Brake release time	134
13.1.2	Flux formation.....	134
13.2	Stopping behavior	136
13.2.1	Switch-Off Threshold	138
13.2.2	Holding Time.....	138
13.3	Direct current brake	138
13.4	Auto start.....	139
13.5	Search run	140
13.6	Positioning.....	142
13.6.1	Reference Positioning	142
13.6.2	Axle Positioning	145
14	Error behavior and warning behavior	148
14.1	Overload Ixt	148
14.2	Temperature.....	148
14.3	Controller Status	149
14.4	IDC Compensation Limit	149
14.5	Frequency Switch-off Limit	150
14.6	Motor temperature	150
14.7	Phase failure.....	151
14.7.1	Settings for sizes 1 to 7	151
14.8	Automatic acknowledgment of errors/faults.....	151
15	Reference Values.....	152
15.1	Frequency Limits	152
15.2	Slip Frequency	152
15.3	Percentage Value Limits.....	152
15.4	Frequency reference channel	152

15.4.1	Block diagram	154
15.5	Reference percentage channel	156
15.5.1	Block diagram	157
15.6	Fixed reference values	159
15.6.1	Fixed frequencies	159
15.6.2	JOG frequency	159
15.6.3	Fixed percentages	160
15.7	Frequency ramps	160
15.8	Percentage Value Ramps.....	162
15.9	Blocking frequencies	163
15.10	Motor potentiometer	164
15.10.1	Motorpoti (MP)	165
15.10.2	Motorpoti (KP).....	165
15.10.3	Controlling the Motor via the Control Unit	166
15.11	PWM-/repetition frequency input.....	166
16	Control inputs and outputs	168
16.1	Multifunction input MFI1.....	168
16.1.1	Analog Input MFI1A.....	168
16.1.1.1	Characteristic	168
16.1.1.2	Scaling	170
16.1.1.3	Tolerance Band and Hysteresis	170
16.1.1.4	Filter time constant.....	171
16.1.1.5	Error and warning behavior	172
16.2	Multifunction Output MFO1	173
16.2.1	Analog Output MFO1A	173
16.2.1.1	Output Characteristic	174
16.2.2	Frequency Output MFO1F	174
16.2.2.1	Scaling	175
16.3	Digital Outputs	175
16.3.1	Digital message	178
16.3.2	Setting Frequency	179
16.3.3	Reference value reached	180
16.3.4	Flux forming finished	182
16.3.5	Brake release	182
16.3.6	Current limitation.....	182
16.3.7	External fan	182
16.3.8	Warning mask	183
16.3.9	Warning mask, application	186
16.4	Digital Inputs	187
16.4.1	Start command.....	192
16.4.2	3-wire control.....	192
16.4.3	Error Acknowledgment.....	193
16.4.4	Timer.....	193
16.4.5	Thermocontact	193
16.4.6	n-/M control change-over	193
16.4.7	Switch data set.....	193
16.4.8	Fixed Value Change-Over	194
16.4.9	Motor potentiometer	194
16.4.10	Handshake Traverse Function	195
16.4.11	User Warning	195
16.4.12	External Error.....	195

16.5	Function Modules	195
16.5.1	Timer.....	195
16.5.1.1	Timer – Time Constant.....	196
16.5.2	Comparator.....	198
16.5.3	Table of functions.....	200
16.5.4	Multiplexer/demultiplexer	200
17	V/f characteristic	202
17.1	Dynamic voltage pre-control.....	203
18	Control functions.....	204
18.1	Intelligent current limits	204
18.2	Voltage controller.....	206
18.3	Technology controller.....	212
18.4	Functions of sensorless control.....	221
18.4.1	Slip compensation	221
18.4.2	Current limit value controller	222
18.5	Functions of field-oriented control.....	223
18.5.1	Current controller	223
18.5.2	Advanced current controller	224
18.5.3	Torque controller.....	224
18.5.3.1	Torque preset.....	225
18.5.3.2	Upper and lower frequency limit in torque control.....	225
18.5.3.3	Limit value sources	226
18.5.3.4	Switching over between speed control and torque control	226
18.5.4	Speed controller	226
18.5.4.1	Limitation of speed controller	228
18.5.4.2	Limit value sources	229
18.5.4.3	Integral time speed compensation	230
18.5.5	Acceleration pre-control	230
18.5.6	Field controller	231
18.5.6.1	Limitation of field controller	232
18.5.7	Modulation controller	232
18.5.7.1	Limitation of modulation controller.....	233
19	Special functions	234
19.1	Pulse width modulation.....	234
19.2	Fan 235	
19.3	Bus controller	235
19.4	Brake chopper and brake resistance.....	236
19.4.1	Dimensioning of brake resistor	237
19.5	Motor circuit breaker.....	238
19.5.1	Motor circuit breaker.....	238
19.5.2	Motor protection by I^2t monitoring.....	242
19.6	V-belt monitoring	244
19.7	Functions of field-oriented control.....	245
19.7.1	Motor chopper.....	245
19.7.2	Temperature Adjustment	246
19.7.3	Speed sensor monitoring	247
19.8	Traverse function	247
19.9	Profibus/Internal Notation converter	249

20	Actual values	251
20.1	Actual values of frequency inverter	251
20.1.1	STO Status.....	253
20.2	Actual values of machine.....	253
20.3	Actual value memory	254
20.4	Actual values of the system	255
20.4.1	Actual value system	255
20.4.2	Volumetric Flow and Pressure.....	256
21	Error protocol	257
21.1	List of errors	257
21.1.1	Error messages	257
21.2	Error environment	261
22	Operational and error diagnosis	263
22.1	Status display	263
22.2	Status of digital signals	263
22.3	Controller Status	264
22.4	Warning Status and Warning Status Application	265
23	List of parameters	267
23.1	Actual Value Menu (VAL).....	267
23.2	Parameter Menu (PARA)	270
Index		280
Functions of control terminals (table).....		282

1 General Information about the Documentation

1.1 Instruction Manuals

For better clarity, the documentation is structured according to the customer-specific requirements made on the frequency inverter.

Quick start guide

The Quick Start Guide describes the basic steps required for mechanical and electrical installation of the frequency inverter. The guided commissioning supports you in the selection of necessary parameters and the configuration of the frequency inverter by the software.

Operating instructions

The Operating Instructions describe all functions of the frequency inverter. The parameters required for adapting the frequency inverter to specific applications and the numerous additional functions are described in detail.

Application manual

The application manual supplements the documentation for purposeful installation and commissioning of the frequency inverter. Information on various subjects connected with the use of the frequency inverter is described specific to the application.



If you need a copy of the documentation or additional information, contact your local representative of BONFIGLIOLI.

The following instructions are available for the *ACTIVE CUBE* series:

<i>ACTIVE CUBE</i> Operating Instructions	Function of frequency inverter.
Quick Start Guide <i>ACTIVE CUBE</i> Manuals	Installation and commissioning Supplied with the device.
Communication interfaces	CM-CAN: CANopen manual CM-PDP-V1: Profibus DP-V1 manual CM-232/CM-485: VABus manual (serial protocol) CM-232/CM-485 Modbus: Modus ASCII and RTU manual CM-VABus/TCP: Ethernet Module CM-VABus/TCP CM-ModbusTCP: Ethernet Module CM-Modbus/TCP CM-EtherCAT®: Ethernet Module CM-EtherCAT® CM-ProfiNet: Ethernet Module CM-ProfiNet CM-EtherNet-I/P: Ethernet Module CM-EtherNet-I/P (i.V.)
Manuals Extension modules	EM-ABS-01: Absolute encoder module EM-ENC-01: Speed sensor (encoder) module EM-ENC-02: Speed sensor (encoder) module EM-ENC-03: Speed sensor (encoder) module EM-ENC-04: Speed sensor (encoder) module EM-ENC-05: Speed sensor (encoder) module EM-IO-01: Extension module for digital inputs/outputs EM-IO-02: Extension module for digital inputs/outputs EM-IO-03: Extension module for digital inputs/outputs EM-IO-04: Extension module for digital inputs/outputs EM-RES-01: Resolver module EM-RES-02: Resolver module EM-RES-03: Resolver module EM-SYS: System Bus module
Safe Torque Off (STO) manual	Safety function STO
Operating Instructions Liquid Cooling Supplemental	Properties specific to liquid cooled frequency inverters
PLC application manual	Logic linking of digital signals. Functions for analog signals such as comparisons and mathematical functions. Graphical support for programming with function blocks.

Application manual Positioning	Positioning functions of Configurations x40.
Application manual Electronic gear	Linking of at least 2 drives as electronic gear with Slave drive in Configuration x15 or x16.
Application manual Hoist unit drives	Advanced brake control for hoist unit drives.



The products for CANopen[®] communication comply with the specifications of the user organization CiA[®] (CAN in Automation).



The products for EtherCAT[®] communication comply with the specifications of the user organization ETG (EtherCAT Technology Group).

The present documentation was prepared with great care and was subjected to extensive and repeated reviews. For reasons of clarity, it was not possible to include all details of all types of the product in the documentation. Neither was it possible to consider all conceivable installation, operation or maintenance situations. If you require further information or if you encounter specific problems which are not dealt with in sufficient detail in the documentation, contact your local BONFIGLIOLI agent.

The present document was created in German. Other language versions are translations.

1.2 This document

This document describes the frequency inverters of the *ACTIVE Cube* series. The modular hardware and software structure enables customer-specific adaptation of the frequency inverter series. Applications with high functionality and dynamism can be realized easily.

This documentation applies to the following frequency inverter series:

- ACTIVE Cube 201
- ACTIVE Cube 401
- ACTIVE Cube 501
- ACTIVE Cube 601

This document contains important information on the installation and use of the product in its specified application range. Compliance with this document contributes to avoiding risks, minimizing repair cost and downtimes and increasing the reliability and service life of the frequency inverter.

For this reason, make sure you read the Operating Instructions carefully.

IMPORTANT:

Compliance with the documentation is required to ensure safe operation of the frequency inverter. BONFIGLIOLI VECTRON GmbH shall not be held liable for any damage caused by any non-compliance with the documentation.



In case any problems occur which are not covered by the documentation sufficiently, please contact the manufacturer.



For safe commissioning and operation of the ACU series, the following documentation must be complied with:

- This Operating Instructions Document
- Application manual "Safe Torque Off ACU"

The ACU series can be identified by its label on the case and the identification below the top cover.




Figure 1-1: Device identification

1.3 Warranty and liability

BONFIGLIOLI VECTRON GmbH (hereinafter referred to as “manufacturer”) notes that the contents of this Operating Instructions document do not form part of any previous or existing agreement, assurance or legal relationship between the manufacturer and the user of these Operating Instructions (hereinafter referred to as the “User”). Neither are they intended to supplement or replace such agreements, assurances or legal relationships. Any obligations of the manufacturer shall solely be based on the relevant purchase agreement which also includes the complete and solely valid warranty stipulations. These contractual warranty provisions are neither extended nor limited by the specifications contained in this documentation.

The manufacturer reserves the right to correct or amend the specifications, product information and omissions in these operating instructions without prior notice. The manufacturer assumes no responsibility to update these Operating Instructions. The manufacturer shall not be liable for any damage, injuries or costs which may be caused by the aforementioned reasons.

In addition, the manufacturer excludes any warranty and disclaims all liability, including without limitation direct, indirect, special, punitive, incidental, exemplary or consequential damages arising out of or in connection with one or more of the following causes:

- inappropriate use of the frequency inverter,
- non-compliance with the instructions, warnings and prohibitions contained in the documentation,
- unauthorized modifications of the solar inverter,
- insufficient monitoring of parts of the machine/plant which are subject to wear,
- repair work at the machine/plant not carried out properly or in time,
- catastrophes by external impact and Force Majeure.

1.4 Obligation

This Operating Instructions document must be read before commissioning. Anybody entrusted with tasks in connection with the

- transport,
- assembly,
- installation of the frequency inverter and
- operation of the frequency inverter

must have read and understood the Operating Instructions and, in particular, the safety instructions in order to prevent personal and material losses.

1.5 Copyright

Any copyrights relating to this document shall remain with

BONFIGLIOLI VECTRON GmbH
Europark Fichtenhain B6
47807 Krefeld
Germany

This document is intended for the operator of the frequency inverter. Any disclosure or copying of this document, exploitation and communication of its contents (as hardcopy or electronically) shall be forbidden, unless permitted expressly.

Any non-compliance will constitute an offense against the copyright law, the law against unfair competition and the German Civil Code and may result in claims for damages. All rights relating to patent, utility model or design registration reserved.

1.6 Storage

The documentation forms an integral part of the frequency inverter. It must be stored such that it is accessible to operating staff at all times. In case the frequency inverter is sold to other users, this Operating Instructions document must also be handed over.

2 General safety instructions and information on use

The chapter "General safety instructions and information on use" contains general safety instructions for the Operator and the Operating Staff. At the beginning of certain main chapters, some safety instructions are included which apply to all work described in the relevant chapter. Special work-specific safety instructions are provided before each safety-relevant work step.

2.1 Terminology

According to the documentation, different activities must be performed by certain persons with certain qualifications.

The groups of persons with the required qualification are defined as follows:

Operator

This is the entrepreneur/company who/which operates the frequency inverter and uses it as per the specifications or has it operated by qualified and instructed staff.

Operating staff

The term Operating Staff covers persons instructed by the Operator of the frequency inverter and assigned the task of operating the frequency inverter.

Skilled Personnel

The term Skilled Personnel covers staff that are assigned special tasks by the Operator of the frequency inverter, e.g. installation, maintenance and service/repair and troubleshooting. Based on their qualification and/or know-how, Skilled Personnel must be capable of identifying defects and assessing functions.

Qualified electrician

The term Qualified Electrician covers qualified and trained staff who has special technical know-how and experience with electrical installations. In addition, Qualified Electricians must be familiar with the applicable standards and regulations, they must be able to assess the assigned tasks properly and identify and eliminate potential hazards.

Instructed person

The term Instructed Person covers staff who was instructed and trained about/in the assigned tasks and the potential hazards that might result from inappropriate behavior. In addition, instructed persons must have been instructed in the required protection provisions, protective measures, the applicable directives, accident prevention regulations as well as the operating conditions and verified their qualification.

Expert

The term Expert covers qualified and trained staff who has special technical know-how and experience relating to frequency inverter. Experts must be familiar with the applicable government work safety directives, accident prevention regulations, guidelines and generally accepted rules of technology in order to assess the operationally safe condition of the frequency inverter.

2.2 Designated use

The product is a frequency inverter. It is designed for

- installation in machines and electrical equipment
- industrial environments

The frequency inverter is designed according to the state of the art and recognized safety regulations.

The frequency inverters are electrical drive components intended for installation in industrial plants or machines. Commissioning and start of operation is not allowed until it has been verified that the machine meets the requirements of the EC Machinery Directive 2006/42/EC and DIN EN 60204-1.

The frequency inverters meet the requirements of the low voltage directive 2006/95/EEC and DIN EN 61800-5-1. CE-labeling is based on these standards. Responsibility for compliance with the EMC Directive 2004/108/EC lies with the operator. Frequency inverters are only available at specialized dealers and are exclusively intended for commercial use as per EN 61000-3-2.

No capacitive loads may be connected to the frequency inverter.

The technical data, connection specifications and information on ambient conditions are indicated on the rating plate and in the documentation and must be complied with in any case.

2.3 Misuse

Any use other than that described in "Designated use" shall not be permissible and shall be considered as misuse.

For example, the machine/plant must not be operated

- by uninstructed staff,
- while it is not in perfect condition,
- without protection enclosure (e.g. covers),
- without safety equipment or with safety equipment deactivated.

The manufacturer shall not be held liable for any damage resulting from such misuse. The sole risk shall be borne by the operator.

2.3.1 Explosion protection

The frequency inverter is an IP 20 ingress protection rating device. For this reason, use of the device in explosive atmospheres is not permitted.

2.4 Residual risks

Residual risks are special hazards involved in handling of the frequency inverter which cannot be eliminated despite the safety-compliant design of the device. Residual risks are not obviously identifiable and can be a potential source of injury or a health hazard.

Typical residual hazards include:

Electrical hazard

Danger of contact with energized components due to a defect, opened covers or enclosures or improper working on electrical equipment.

Danger of contact with energized components in frequency inverter if no external disconnection device was installed by the operator.

During operation, all covers must be installed correctly, and all electrical cabinet doors must be closed to minimize electrical hazards.

When LEDs and other indicating elements on the frequency inverter go out, this does not necessarily mean that the device is deenergized. Before carrying out any work on the device where contact with energized parts might be possible, check in any case, i.e. irrespective of the status of any indicating elements that may be installed, if the device is deenergized.

Charged capacitors in DC link

Sizes 1 through 7 (up to 132 kW): The DC-link may have dangerous voltage levels even up to 3 minutes after shutdown.

Electrostatic charging

Touching electronic components entails the risk of electrostatic discharges.

Thermal hazards

Risk of accidents by hot machine/plant surfaces, e.g. heat sink, transformer, fuse or sine filter.

Danger of equipment falling down/over, e.g. during transport

Center of gravity is not the middle of the electrical cabinet modules.

2.5 Safety and warning signs on frequency inverter

- Comply with all safety instructions and danger information provided on the frequency inverter.
- Safety information and warnings on the frequency inverter must not be removed.

2.6 Warning information and symbols used in the Operating Instructions

2.6.1 Hazard classes

The following hazard identifications and symbols are used in the Operating Instructions to mark particularly important information:



DANGER

Identification of immediate threat holding a **high** risk of death or serious injury if not avoided.



WARNING

Identification of immediate threat holding a **medium** risk of death or serious injury if not avoided.








CAUTION

Identification of immediate threat holding a **low** risk of minor or moderate physical injury if not avoided.


NOTICE

Identification of a threat holding a risk of material damage if not avoided.



2.6.2 Hazard symbols

Symbol	Meaning	Symbol	Meaning
	General hazard		Suspended load
	Electrical voltage		Hot surfaces
	Danger of crushing		


2.6.3 Prohibition signs

Symbol	Meaning
	No switching; it is forbidden to switch the machine/plant, assembly on


2.6.4 Personal safety equipment

Symbol	Meaning
	Wear body protection
	Wear ear protectors


2.6.5 Recycling

Symbol	Meaning
	Recycling, to avoid waste, collect all materials for reuse


2.6.6 Grounding symbol

Symbol	Meaning
	Ground connection

2.6.7 ESD symbol

Symbol	Meaning
	ESD: Electrostatic Sensitive Devices, i.e. components and assemblies sensitive to electrostatic energy

2.6.8 Information signs

Symbol	Meaning
	Tips and information making using the frequency inverter easier.

2.6.9 Font style in documentation

Example	Font style	Use
1234	bold	Representation of parameter numbers
<i>Parameter</i>	inclined, font: Times New Roman	Representation of parameter names
P.1234	bold	Representation of parameter numbers without name, e.g. in formulas
Q.1234	bold	Representation of source numbers

2.7 Directives and guidelines to be adhered to by the operator

The operator must follow the following directives and regulations:

- Ensure that the applicable workplace-related accident prevention regulations as well as other applicable national regulation are accessible to the staff.
- An authorized person must ensure, before using the frequency inverter, that the device is used in compliance with its designated use and that all safety requirements are met.
- Additionally, comply with the applicable laws, regulations and directives of the country in which the frequency inverter is used.
- For liquid cooled frequency inverters, comply with the cooling water guideline VGB-R 455 P.
- Any additional guidelines and directives that may be required additionally shall be defined by the operator of the machine/plant considering the operating environment.

2.8 Operator's general plant documentation

- In addition to the Operating Instructions, the operator should issue separate internal user manuals for the frequency inverter. The Operating Instructions of the frequency inverter must be included in the Operating Instructions of the whole plant.

2.9 Operator's/operating staff's responsibilities

2.9.1 Selection and qualification of staff

- Any work on the frequency inverter may only be carried out by skilled personnel. The staff must not be under the influence of any drugs. Note the minimum age required by law. Define the staff's responsibility pertaining to all work on the frequency inverter clearly.
- Work on the electrical components may only be performed by a qualified electrician according to the applicable rules of electrical engineering.
- The operating staff must be trained for the relevant work to be performed.

2.9.2 General work safety

- In addition to the Operating Instructions of the machine/plant, any applicable legal or other regulations relating to accident prevention and environmental protection must be complied with. The staff must be instructed accordingly.
Such regulations and/or requirements may include, for example, handling of hazardous media and materials or provision/use of personal protective equipment.
- In addition to these Operating Instructions, issue any additional directives that may be required to meet specific operating requirements, including supervision and reporting requirements, e.g. directives relating to work organization, workflow and employed staff.
- Unless approved of expressly by the manufacturer, do not modify the frequency inverter in any way, including addition of attachments or retrofits.
- Only use the frequency inverter if the rated connection and setup values specified by the manufacturer are met.
- Provide appropriate tools as may be required for performing all work on the frequency inverter properly.

2.9.3 Ear protectors

- The frequency inverter produces noise. Due to noise development, frequency inverters should only be installed in normally unstaffed areas.
- Noise emission in operation is < 85 dB(A) in the case of sizes 1 through 7.

2.10 Organizational measures

2.10.1 General

- Train your staff in the handling and use of the frequency inverter and the machine/plant as well as the risks involved.
- Use of any individual parts or components of the frequency inverter in other parts of the operator's machine/plant is prohibited.
- Optional components for the frequency inverter must be used in accordance with their designated use and in compliance with the relevant documentation.

2.10.2 Use in combination with third-party products

- Please note that Bonfiglioli Vectron MDS GmbH will not accept any responsibility for compatibility with third-party products (e.g. motors, cables or filters)..
- In order to enable optimum system compatibility Bonfiglioli Vectron MDS GmbH offers components facilitating commissioning and providing optimum synchronization of the machine/plant parts in operation.
- If you use the frequency inverter in combination with third-party products, you do so at your own risk.

2.10.3 Handling and installation

- Do not commission any damaged or destroyed components.
- Prevent any mechanical overloading of the frequency inverter. Do not bend any components and never change the isolation distances.
- Do not touch any electronic construction elements and contacts. The frequency inverter is equipped with components which are sensitive to electrostatic energy and can be damaged if handled improperly. Any use of damaged or destroyed components will endanger the machine/plant safety and shall be considered as non-compliance with the applicable standards.
- Only install the frequency inverter in a suitable operating environment. The frequency inverter is exclusively designed for installation in industrial environments.
- If seals are removed from the case, this can result in the warranty becoming null and void.

2.10.4 Electrical connections

- The five safety rules must be complied with.
- Never touch live terminals. In sizes 1 through 7, the DC-link may have dangerous voltage levels up to 3 minutes after shutdown.
- When performing any work on/with the frequency inverter, always comply with the applicable national and international regulations/laws on work on electrical equipment/plants of the country in which the frequency inverter is used.
- The cables connected to the frequency inverters may not be subjected to high-voltage insulation tests unless appropriate circuitry measures are taken before.
- Only connect the frequency inverter to suitable supply mains. The frequency inverter may be operated in TN, TT and IT grid types. Precautions must be taken for operation in IT grids, see Chapter 7 "Electrical installation". Operation in a corner-grounded TN grid shall not be permissible.

2.10.4.1 The five safety rules

When working on/in electrical plants, always follow the five safety rules:

- 1 Isolate
- 2 Secure to prevent restarting
- 3 Check isolation
- 4 Earth and short-circuit
- 5 Cover or shield neighboring live parts

2.10.5 Safe operation

- During operation of the frequency inverter, always comply with the applicable national and international regulations/laws on work on electrical equipment/plants.
- Before commissioning and the start of the operation, make sure to fix all covers and check the terminals. Check the additional monitoring and protective devices according to the applicable national and international safety directives.
- During operation, all covers must be installed correctly, and all electrical cabinet doors must be closed. During operation, never open the machine/plant.
- No connection work shall be carried out while power supply is on.
- The machine/plant holds high voltage levels during operation, is equipped with rotating parts (fan) and has hot surfaces. Any unauthorized removal of covers, improper use, wrong installation or operation may result in serious injuries or material damage.
- Some components, e.g. the heat sink or braking resistor, may be hot even some time after the machine/plant was shut down. Don't touch any surfaces directly after shutdown. Wear safety gloves where necessary.
- The frequency inverter may hold dangerous voltage levels until the capacitor in the DC link is discharged. After shutdown, wait for at least 3 minutes (sizes 1 through 7) before starting any electrical or mechanical work on the frequency inverter. Even after this waiting time, make sure that the equipment is deenergized in accordance with the safety rules before starting the work.
- In order to avoid accidents or damage, only skilled personnel and electricians may carry out the work such as installation, commissioning or setup.
- In the case of a defect of terminals and/or cables, immediately disconnect the frequency inverter from mains supply.
- Persons not familiar with the operation of the frequency inverter and children must not have access to the device.
- Do not bypass nor decommission any protective devices.
- The frequency inverter may be connected to power supply every 60 s. This must be considered when operating a mains contactor in jog operation mode. For commissioning or after an emergency stop, a non-recurrent, direct restart is permissible.
- After a failure and restoration of the power supply, the motor may start unexpectedly if the AutoStart function is activated.
If staff are endangered, a restart of the motor must be prevented by means of external circuitry.
- Before commissioning and the start of the operation, make sure to fix all covers and check the terminals. Check the additional monitoring and protective devices according to EN 60204 and applicable the safety directives (e.g. Working Machines Act or Accident Prevention Directives).

2.10.6 Maintenance and service/troubleshooting

- Visually inspect the frequency inverter when carrying out the required maintenance work and inspections at the machine/plant.
- Perform the maintenance work and inspections prescribed for the machine carefully, including the specifications on parts/equipment replacement.
- Work on the electrical components may only be performed by a qualified electrician according to the applicable rules of electrical engineering. Only use original spare parts.
- Unauthorized opening and improper interventions in the machine/plant can lead to personal injury or material damage. Any repair work may only be carried out by the manufacturer or persons approved/licensed by the manufacturer. Any repair work must be carried out by qualified electricians. Check protective equipment regularly.
- Before performing any maintenance work, the machine/plant must be disconnected from mains supply and secured against restarting. The five safety rules must be complied with.

2.10.7 Final decommissioning

Unless separate return or disposal agreements were made, recycle the disassembled frequency inverter components:

- Scrap metal materials
- Recycle plastic elements
- Sort and dispose of other component materials



Electric scrap, electronic components, lubricants and other utility materials must be treated as special waste and may only be disposed of by specialized companies.



In any case, comply with any applicable national disposal regulations as regards environmentally compatible disposal of the frequency inverter. For more details, contact the competent local authorities.

2.11 Safety Instructions on Function "Safe Torque Off" (STO)

The function „Safe Torque Off“ (STO) is a functional safety feature, i.e. it protects staff from damage, provided that projecting, installation and operation are performed properly. This function does not disconnect the plant from power supply.

In order to disconnect the plant from power supply (e.g. for maintenance work), an "Emergency Stop" provision as per EN 60204 must be installed.



WARNING

Improper installation of the safety circuitry may result in uncontrolled starting of the drive. This may cause death, serious injuries and significant material damage.

Safety functions may only be installed and commissioned by skilled personnel.

The STO function is not suitable for emergency stop as per EN 60204. An emergency stop can be realized by installing a mains contactor.

An emergency stop according to EN 60204 must be functioning in all operation modes of the frequency inverter. Resetting of an emergency stop must not result in uncontrolled starting of the drive.

The drive is started again when the function STO is no longer required. In order to comply with EN 60204, ensure by taking external measures that the drive does not start without prior confirmation.

Without a mechanical brake, the drive will not stop immediately but coast to a standstill. If this may result in personal or material damage, additional safety measures must be taken.

If persons may be endangered after disconnection of the motor power supply by STO, access to the hazard areas must be prevented until the drive has stopped.

Check the safety function at regular intervals according to the results of your risk analysis. Bonfiglioli Vectron MDS GmbH recommends that the check be performed after one year, at the latest.

The STO function is fail-safe. However, on rare occasions, the occurrence of component defects may cause jerking of the motor shaft (max. 180°/pole pair, e. g. jerk by 90° with 4-pole motor, 180°/2). Check if this causes a dangerous movement of the machine.

If the STO function is used, the special safety, installation and instructions on use instructions shall be complied with.



The application manual "Safe Torque Off STO" must be complied with, particularly if the safety function described there is used.



Warning! Dangerous voltage!

The safety function "Safe Torque Off" may only be used if mechanical work is to be performed on the driven machines, not for work on live components.

After disconnection of an external DC 24 V power supply, the DC link of the frequency inverter is still connected to mains supply.

Even if power supply to the motor is disconnected, and the motor is coasting to a standstill or has already stopped, high voltages may still be present on the motor terminals.

Before working (e. g. maintenance) on live parts, the plant must always be disconnected from mains supply (main switch). This must be documented on the plant.

When the function "Safe Torque Off" is triggered, the motor is not isolated from the DC link of the frequency inverter. High voltage levels may be present at the motor.

Do not touch live terminals.

3 Storage and transport

NOTICE

Draining the heat sink

- Liquid cooled devices may be transported only with the heat sink completely drained of the coolant. Use compressed air to drain the heat sink radiator.

3.1 Storage

NOTICE

Damage caused by incorrect storage

- Wrong or inappropriate storage may result in damage, e.g. due to moisture and dirt. Avoid major temperature variations and high air humidity.
- During storage, protect the device against moisture and dirt.
- The frequency inverters must be stored in an appropriate way. During storage, the devices must remain in their original packaging.
- The units may only be stored in dry rooms which are protected against dust and moisture and are exposed to small temperature deviations only. The requirements of DIN EN 60721-3-1 for storage, DIN EN 60721-3-2 for transport and labeling on the packaging must be met.
- The duration of storage without connection to the permissible nominal voltage may not exceed one year. After one year of storage, connect the device to mains voltage for 60 minutes.

3.2 Special safety instructions on transport of heavy frequency inverters



WARNING

High weight and unusual center of gravity!

Tilting the frequency inverter may result in death or serious injuries. Due to the size and weight of the frequency inverter, there is the risk of accidents during transport. Center of gravity is not the middle of the frequency inverter. The underside of the frequency inverter, due to its design, cannot support the frequency inverter.

- Take utmost care during transport in order to prevent damage and deformation. Transport, attachment and lifting of loads may only be carried out by specially instructed staff who are familiar with the work.
- Only use suitable transport and lifting equipment with sufficient carrying capacity. The lifting cables/chains used must be able to carry the weight of the frequency inverter. Check the ropes or chains for damage.
- Wear appropriate safety clothing.
- When lifting the frequency inverter up ensure that it does not fall over, is displaced, swings out or falls down.
- Before the frequency inverter is lifted up, everybody must have left the work area.
- Before transport, make sure the transport path has sufficient carrying capacity.
- Do not step under suspended loads.
- Do not put the frequency inverter down in upright position without providing a suitable supporting structure.

3.3 Dimensions/weight



For information on the weight and dimensions of the frequency inverter, refer to chapter 5 "Technical data".

3.4 Transfer to place of installation

Transfer to the place of installation is done with the product in its original packaging. Frequency inverters as from size 7 must be transferred to the place of installation in horizontal position, rear-side down. A fork lift truck or crane with crane fork can be used for transfer to the place of installation.

- Apply the fork in the middle of the transport unit.
- Secure the transport unit to prevent it from falling down and overturning.
- Lift the transport unit up carefully.
- At the place of installation, put the transport unit down on a level and bearing surface.

3.5 Unpacking the device

- Carefully remove packaging.
- Check if the delivered devices corresponds to the order.
- Check the device for transport damage and completeness.
- Any defects/damage must be reported to the supplier immediately.



Ensure that all packaging materials are disposed of in an environmentally compatible manner.


3.6 Bringing the device into installation position

3.6.1 Sizes 1 through 6

- Depending on the weight, one or two persons are required for lifting the device into the installation position in the electrical cabinet. Installation, see Chapter 6 "Mechanical installation".


3.6.2 Sizes 7 and 8

- Fix two crane eyes (M8) in the marked threaded holes on the top side of the device.
- Use appropriate lifting means.



NOTICE

The pull angle must not be smaller than 60°.



- Use appropriate lifting means and a crane to lift the frequency inverter up carefully. Bring the device into vertical position by turning it up on the pallet via the rear lower edge of the case.

NOTICE

Do not leave the device standing in upright position.


- Move the frequency inverter to its installation position in the electrical cabinet and fix it there, see Chapter 6 "Mechanical installation".
- After mechanical installation, disconnect the device from the crane and remove the crane eyes.

4 Scope of supply

Due to modular hardware components, the frequency inverters can be integrated in the automation concept easily. The scope of delivery described can be supplemented by optional components and adapted to the customer-specific requirements. The plug-in type connection terminals enable a safe function and quick and easy assembly.

4.1 Sizes 1 and 2: ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)

Scope of supply



Scope of supply


A	Frequency inverter
B	Terminal strip X1 (Phoenix ZEC 1,5/ST7,5) Plug-in terminals for mains connection and DC linking
C	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
D	Standard fixtures for vertical assembly
E	Quick Start Guide and Operating Instructions
F	Terminal strip X2 (Phoenix ZEC 1,5/ST7,5) Plug-in terminal for braking resistor and motor connection
G	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

4.2 Sizes 3 and 4: ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)

Scope of supply



Scope of supply


A	Frequency inverter
B	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
C	Standard fittings with fitting screws (M4x20, M4x60) for vertical assembly
D	Quick Start Guide and Operating Instructions
E	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

4.3 Size 5 ACU 401 (18.5 to 30.0 kW)

Scope of supply



Scope of supply


A	Frequency inverter
B	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
C	Standard fittings with fitting screws (M4x20, M4x70) for vertical assembly
D	Quick Start Guide and Operating Instructions
E	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

4.4 Size 6 ACU 401 (37.0 to 65.0 kW)

Scope of supply



Scope of supply


A	Frequency inverter The illustration shows an air-cooled frequency inverter as an example.
B	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
C	For air-cooled frequency inverters only: Standard fittings with fitting screws (M5x20) for vertical assembly
D	Quick Start Guide and Operating Instructions
E	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

4.5 Size 7 ACU 401 (75.0 to 132.0 kW)

Scope of supply



Scope of supply

A	Frequency inverter The illustration shows an air-cooled frequency inverter as an example.
B	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
C	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals
D	Quick Start Guide and Operating Instructions



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

5 Technical data

5.1 General technical data

CE conformity	The ACU frequency inverters meet the requirements of the low voltage directive 2006/95/EEC and DIN EN 61800-5-1.		
EMC directive	For proper installation of the frequency inverter in order to meet the requirements of EN 61800-3, please comply with the installation instructions in these operating instructions.		
Interference immunity	The ACU frequency inverters meet the requirements of EN 61800-3 for use in industrial environments.		
UL Approval	The frequency inverters are also marked with the UL label according to UL508c, which proves that they also meet the requirements of the CSA Standard C22.2-No. 14. ACU 401 device series are UL-approved in sizes 1 through 7, ACU 201 devices are UL-approved in sizes 1 and 2.		
Safety function	The function is described in application manual "Safe Torque Off STO".		
Ambient temperature	Storage: -25 ... 55°C (for liquid cooling: drain the heat sink completely!) Transport: -25 ... 70°C (for liquid cooling: drain the heat sink completely!) Operation: 0...55°C; as from 40 °C power reduction should be considered.		
Ambient pressure	70 ... 106 kPa (to be checked)		
Environmental class	Operation: 3K3 (EN60721-3-3) Relative humidity Air cooling: 15...85%, no water condensation Liquid cooling: 15...95%, non-condensing For liquid cooling: Comply with the notes on "Heat sink condensation protection" in the "Operating Instructions Liquid Cooling Supplemental". In addition, the following environmental conditions must be considered for operation according to DIN EN 60721-3-3: 3Z1 (negligible thermal radiation) 3B1 (no biological impact) 3C1 (chemically active substances, limits as per standard) 3S1 (mechanically active substances, no sand in air, limits as per standard) 3M4 (mechanical vibration and shocks, limits as per standard)		
Ingress protection rating	IP20 if covers and connection terminals are used properly.		
Altitude of installation	Up to 1000 m at rated specifications. Up to 4000 m at reduced power.		
Storage	Storage according to EN 50178. After one year of storage, connect the device to mains voltage for 60 minutes.		
Permitted grid types	The frequency inverter may be operated in TN, TT and IT grid types. Precautions must be taken for operation in IT grids, see Chapter 7 "Electrical installation". Operation in a corner-grounded TN grid shall not be permissible.		
Overload capacity	Continuous operation 100 % IN Up to 150% IN for 60 s Up to 200% IN for 1 s	Devices -01, -03 (0.25 & 0.37 kW):	Up to 200% IN for 60 s Up to 200% IN for 1 s
	Overload capacity can be used every 10 minutes. For the individual overload capacity, refer to the technical data.		

Max. permissible short-circuit current to be expected with mains supply	Up to 132 kW device power (size 7): 5 kA
Contamination level	The frequency inverters are designed for Pollution Degree 2.
Overvoltage category	The frequency inverters are designed for Overvoltage Category III.
Functions	<ul style="list-style-type: none"> – Control methods adjusted to motors and application (configuration). – Adjustable speed/torque control. – Various protection functions for motor and frequency inverter. – Positioning absolute or relative to a reference point. – Catching function. – Special brake control and load detection for lifting gear. – S-ramps for jerk limitation during acceleration and deceleration. – Technology (PI) controller. – Parameterizable Master-Slave operation via system bus. – Error memory. – Simplified and extended control via PC (commissioning, parameterization, data set backup, diagnosis with Scope).
Parameterization	<ul style="list-style-type: none"> – Freely programmable digital inputs and outputs. – Various logic modules for linking and processing of signals. – Four separate data sets incl. motor parameters.

5.2 Technical Data – Control Electronic Equipment

Control terminal X210A		
X210A.1	DC 20 V output (I_{\max} =180 mA) or DC 24 V \pm 10% input for external power supply	
X210A.2	GND 20 V/ GND 24 V (ext.)	
X210A.3	Digital input STOA (first shut-down path)	safety relevant
X210A.4	Digital inputs ¹⁾	
X210A.5		
X210A.6		
X210A.7		
Relay output X10		
X10	Inverter error message ¹⁾	

Control terminal X210B		
X210B.1	Digital input ¹⁾	
X210B.2	Digital input STOB (second shut-down path)	safety relevant
X210B.3	Digital output ¹⁾	
X210B.4	Multifunction output ¹⁾ (voltage signal, proportional act. frequency, factory settings)	
X210B.5	Supply voltage DC 10 V for reference value potentiometer, (I_{\max} =4 mA)	
X210B.6	Multifunction input ¹⁾ (reference speed 0 ... +10 V, factory settings)	
X210B.7	Ground 10 V	

¹⁾ Control terminals are freely configurable.

- Control "Safe Torque Off": Contacts on X210A.3 and X210B.2 open.
- Release of frequency inverter: Contacts on X210A.3 and X210B.2 closed.



By default, the different configurations occupy the control terminals with certain settings. These settings can be adjusted to the specific application, and various functions can be assigned freely to the control terminals. For an overview of the settings, see Page 282 of these Operating Instructions.

Technical data of control terminals

Digital inputs (X210A.3...X210B.2): <ul style="list-style-type: none"> – Low Signal: DC 0...3 V, High Signal: DC 12...30 V, – Input resistance: 2.3 kΩ, response time: 2 ms (STOA and STOB: 10 ms), PLC compatible, – X210A.6 and X210A.7 additionally: Frequency signal: DC 0 V...30 V, 10 mA at DC 24 V, $f_{\max}=150\text{kHz}$
Digital output (X210B.3): <ul style="list-style-type: none"> – Low Signal: DC 0...3 V, High Signal: DC 12...30 V, – Maximum output current: 50 mA, PLC compatible
Relay output (X10): <ul style="list-style-type: none"> – Change-over contact, response time approx. 40 ms, – Make contact AC 5 A / 240 V, DC 5 A (ohmic) / 24 V – Break contact AC 3 A / 240 V, DC 1 A (ohmic) / 24 V
Multifunction output (X210B.4): <ul style="list-style-type: none"> – Analog signal: DC 19...28 V, maximum output current: 50 mA, pulse-width modulated ($f_{\text{PWM}}=116\text{ Hz}$), – Digital signal: Low Signal: DC 0...3 V, High Signal: DC 12...30 V, output current: 50 mA, PLC compatible, – Frequency signal: Output voltage: DC 0...24 V, maximum output current: 40 mA, maximum output frequency: 150 kHz
Multifunction input (X210B.6): <ul style="list-style-type: none"> – Analog signal: Input voltage: DC 0... 10 V ($R_i=70\text{ k}\Omega$), input current: DC 0...20 mA ($R_i=500\text{ }\Omega$), – Digital signal: Low Signal: DC 0...3 V, High Signal: DC 12 V...30 V, response time: 4 ms, PLC compatible
Conductor cross-section: The signal terminals are suitable for the following cable sizes: <ul style="list-style-type: none"> – with ferrule: 0.25...1.0 mm² – without ferrule: 0.14...1.5 mm²

5.3 ACU 201 Size 1 (0.25 to 1.1 kw, 230 V)

Type							
ACU 201			-01	-03	-05	-07	-09
Size			1				
Output, motor side							
Recommended motor shaft power	P	kW	0.25	0.37	0.55	0.75	1.1
Output current	I	A	1.6	2.5	3.0	4.0	5,4 ⁵⁾
Long-term overload current (60 s)	I	A	3.2	5.0	4.5	6.0	7.3
Short-time overload current (1 s)	I	A	3.2	5.0	6.0	8.0	8.0
Output voltage	U	V	Maximum input voltage, three-phase				
Protection	-	-	Short circuit / earth fault proof				
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency				
Switching frequency	f	kHz	2, 4, 8, 12, 16				
Output, braking resistor							
Min. braking resistance	R	Ω	100	100	100	100	100
Recommended braking resistor (U _{DBC} = 385 V)	R	Ω	430	300	230	160	115
Input, mains side							
Mains current ³⁾ 3ph 1ph/N/PE; 2ph	I	A	1,6 2.9	2,5 4.5	3 5.4	4 7.2	5.5 ¹⁾ 9.5 ²⁾
Mains voltage	U	V	184 ... 264				
Mains frequency	f	Hz	45 ... 66				
Fuse 3ph 1ph/N; 2ph	I	A	6 6	6 10			10 16
UL type 250 VAC RK5, 3ph 1ph/N; 2ph	I	A	6 6	6 10			10 15
Mechanical							
Dimensions	HxWxD	mm	190 x 60 x 175				
Weight approx.	m	kg	1.2				
Ingress protection rating	-	-	IP20 (EN60529)				
Connection terminals	A	mm ²	0.2 ... 1.5				
Form of assembly	-	-	vertical				
Ambient conditions							
Energy dissipation (2 kHz switching frequency)	P	W	32	38	43	53	73
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)				

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁶⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
0.25 kW	1.6 A	1.6 A	1.6 A	1.3 A	1.1 A
0.37 kW	2.5 A	2.5 A	2.5 A	2.1 A	1.7 A
0.55 kW	3.0 A	3.0 A	3.0 A	2.5 A	2.0 A
0.75 kW	4.0 A	4.0 A	4.0 A	3.4 A	2.7 A
1.1 kW	5.4 A ²⁾	5.4 A ^{2) 5)}	5.4 A ^{2) 5)}	4.5 A ^{2) 5)}	3.7 A ⁵⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ One- and two-phase connection requires a commutating choke.

³⁾ Mains current with relative mains impedance ≥ 1% (see Chapter 7 "Electrical installation")

⁴⁾ Maximum output current = 9.5 A with single-phase and two-phase connection

⁵⁾ Reduction of switching frequency in thermal limit range

⁶⁾ Maximum current in continuous operation

5.4 ACU 201 Size 2 (1.5 to 3.0 kW, 230 V)

Type					
ACU 201			-11	-13	-15
Size			2		
Output, motor side					
Recommended motor shaft power	P	kW	1.5	2.2	3,0 ⁴⁾
Output current	I	A	7.0	9.5	12.5 ^{4) 5)}
Long-term overload current (60 s)	I	A	10.5	14.3	16.2
Short-time overload current (1 s)	I	A	14.0	19.0	19.0
Output voltage	U	V	Maximum input voltage, three-phase		
Protection	-	-	Short circuit / earth fault proof		
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency		
Switching frequency	f	kHz	2, 4, 8, 12, 16		
Output, braking resistor					
Min. braking resistance	R	Ω	37	37	37
Recommended braking resistor (U _{DBC} = 385 V)	R	Ω	75	55	37
Input, mains side					
Mains current ³⁾ 3ph 1ph/N; 2ph	I	A	7 13.2	9.5 16.5 ²⁾	10.5 ¹⁾ 16.5 ^{2) 4)}
Mains voltage	U	V	184 ... 264		
Mains frequency	f	Hz	45 ... 66		
Fuse 3ph 1ph/N; 2ph	I	A	10 16	16 20	16 20
UL type 250 VAC RK5, 3ph 1ph/N; 2ph	I	A	10 15	15 20	15 20
Mechanical					
Dimensions	HxWxD	mm	250 x 60 x 175		
Weight approx.	m	kg	1.6		
Ingress protection rating	-	-	IP20 (EN60529)		
Connection terminals	A	mm ²	0.2 ... 1.5		
Form of assembly	-	-	vertical		
Ambient conditions					
Energy dissipation (2 kHz switching frequency)	P	W	84	115	170
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)		

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁶⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
1.5 kW	7.0 A	7.0 A	7.0 A	5.9 A	4.8 A
2.2 kW	9.5 A ²⁾	9.5 A ²⁾	9.5 A ²⁾	8.0 A ²⁾	6.5 A
3.0 kW ^{2) 4)}	12.5 A ¹⁾	12.5 A ^{1) 5)}	12.5 A ^{1) 5)}	10.5 A ^{1) 5)}	8.5 A ⁵⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ One- and two-phase connection requires a commutating choke.

³⁾ Mains current with relative mains impedance ≥ 1% (see Chapter 7 "Electrical installation")

⁴⁾ Maximum output current = 9.5 A with single-phase and two-phase connection

⁵⁾ Reduction of switching frequency in thermal limit range

⁶⁾ Maximum current in continuous operation

5.5 ACU 201 sizes 3 and 4 (4.0 to 9.2 kW, 230 V)

Type						
ACU 201			-18	-19	-21	-22
Size			3		4	
Output, motor side						
Recommended motor shaft power	P	kW	4.0	5.5 ⁴⁾	7.5 ⁴⁾	9.2 ⁴⁾
Output current	I	A	18.0	22.0	32.0	35.0
Long-term overload current (60 s)	I	A	26.3	30.3	44.5	51.5
Short-time overload current (1 s)	I	A	33.0	33.0	64.0	64.0
Output voltage	U	V	Maximum input voltage, three-phase			
Protection	-	-	Short circuit / earth fault proof			
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency			
Switching frequency	f	kHz	2, 4, 8, 12, 16			
Output, braking resistor						
Min. braking resistance	R	Ω	24	24	12	12
Recommended braking resistor (U _{DBC} = 385 V)	R	Ω	30	24	16	12
Input, mains side						
Mains current ³⁾ 3ph 1ph/N; 2ph	I	A	18 28 ^{2) 7)}	20 ¹⁾ - ⁴⁾	28.2 ¹⁾ - ⁴⁾	35.6 ¹⁾ - ⁴⁾
Mains voltage	U	V	184 ... 264			
Mains frequency	f	Hz	45 ... 66			
Fuse 3ph 1ph/N; 2ph	I	A	25 35	25 - ⁴⁾	35 - ⁴⁾	50 - ⁴⁾
Mechanical						
Dimensions	HxWxD	mm	250 x 100 x 200		250 x 125 x 200	
Weight approx.	m	kg	3.0		3.7	
Ingress protection rating	-	-	IP20 (EN60529)			
Connection terminals	A	mm ²	0.2 ... 6		0.2 ... 16	
Form of assembly	-	-	vertical			
Ambient conditions						
Energy dissipation (2 kHz switching frequency)	P	W	200	225	310	420
Coolant temperature	T _a	°C	0 ... 40 (3K3 DIN IEC 721-3-3)			

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁶⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
4.0 kW	18.0 A ²⁾	18.0 A ²⁾	18.0 A ²⁾	15.1 A ²⁾	12.2 A
5.5 kW ⁴⁾	23.0 A ¹⁾	22.7 A ^{1), 5)}	22.0 A ^{1), 5)}	18.5 A ⁵⁾	15.0 A ⁵⁾
7.5 kW ⁴⁾	32.0 A ¹⁾	32.0 A ¹⁾	32.0 A ¹⁾	26.9 A ¹⁾	21.8 A
9.2 kW ⁴⁾	40.0 A ¹⁾	38.3 A ^{1), 5)}	35.0 A ^{1), 5)}	29.4 A ^{1), 5)}	23.8 A ⁵⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ One- and two-phase connection requires a commutating choke.

³⁾ Mains current with relative mains impedance ≥ 1% (see Chapter 7 "Electrical installation")

⁴⁾ Three-phase connection permissible only.

⁵⁾ Reduction of switching frequency in thermal limit range

⁶⁾ Maximum current in continuous operation

⁷⁾ Device for single-phase mains connection is not included in the product catalog. However, it is available upon request.

5.6 ACU 401 Size 1 (0.25 to 1.5 kW, 400 V)

Type								
ACU 401			-01	-03	-05	-07	-09	-11
Size			1					
Output, motor side								
Recommended motor shaft power	P	kW	0.25	0.37	0.55	0.75	1.1	1.5
Output current	I	A	1.0	1.6	1.8	2.4	3.2	3.8 ³⁾
Long-term overload current (60 s)	I	A	2.0	3.2	2.7	3.6	4.8	5.7
Short-time overload current (1 s)	I	A	2.0	3.2	3.6	4.8	6.4	7.6
Output voltage	U	V	Maximum input voltage, three-phase					
Protection	-	-	Short circuit / earth fault proof					
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency					
Switching frequency	f	kHz	2, 4, 8, 12, 16					
Output, braking resistor								
Min. braking resistance	R	Ω	300	300	300	300	300	300
Recommended braking resistor (U _{DBC} = 770 V)	R	Ω	930	930	930	634	462	300
Input, mains side								
Power supply current ²⁾	I	A	1.0	1.6	1.8	2.4	2.8 ¹⁾	3.3 ¹⁾
Mains voltage	U	V	320 ... 528					
Mains frequency	f	Hz	45 ... 66					
Fuses	I	A	6					
UL type 600 VAC RK5	I	A	6					
Mechanical								
Dimensions	HxWxD	mm	190 x 60 x 175					
Weight approx.	m	kg	1.2					
Ingress protection rating	-	-	IP20 (EN60529)					
Connection terminals	A	mm ²	0.2 ... 1.5					
Form of assembly	-	-	vertical					
Ambient conditions								
Energy dissipation (2 kHz switching frequency)	P	W	30	35	40	46	58	68
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)					

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
0.25 kW	1.0 A	1.0 A	1.0 A	0.8 A	0.7 A
0.37 kW	1.6 A	1.6 A	1.6 A	1.3 A	1.1 A
0.55 kW	1.8 A	1.8 A	1.8 A	1.5 A	1.2 A
0.75 kW	2.4 A	2.4 A	2.4 A	2.0 A	1.6 A
1.1 kW	3.2 A ¹⁾	3.2 A ¹⁾	3.2 A ¹⁾	2.7 A ¹⁾	2.2 A
1.5 kW ¹⁾	3.8 A	3.8 A ³⁾	3.8 A ³⁾	3.2 A ³⁾	2.6 A ³⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance $\geq 1\%$ (see Chapter 7 "Electrical installation")

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

5.7 ACU 401 Size 2 (1.85 to 4.0 kW, 400 V)

Type						
ACU 401			-12	-13	-15	-18
Size			2			
Output, motor side						
Recommended motor shaft power	P	kW	1.85	2.2	3.0	4.0
Output current	I	A	4.2	5.8	7.8	9.0 ³⁾
Long-term overload current (60 s)	I	A	6.3	8.7	11.7	13.5
Short-time overload current (1 s)	I	A	8.4	11.6	15.6	18.0
Output voltage	U	V	Maximum input voltage, three-phase			
Protection	-	-	Short circuit / earth fault proof			
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency			
Switching frequency	f	kHz	2, 4, 8, 12, 16			
Output, braking resistor						
Min. braking resistance	R	Ω	136	136	136	92
Recommended braking resistor (U _{DBC} = 770 V)	R	Ω	300	220	148	106
Input, mains side						
Power supply current ²⁾	I	A	4.2	5.8	6.8 ¹⁾	7.8 ¹⁾
Mains voltage	U	V	320 ... 528			
Mains frequency	f	Hz	45 ... 66			
Fuses	I	A	6	10		
UL type 600 VAC RK5	I	A	6	10		
Mechanical						
Dimensions	HxWxD	mm	250 x 60 x 175			
Weight approx.	m	kg	1.6			
Ingress protection rating	-	-	IP20 (EN60529)			
Connection terminals	A	mm ²	0.2 ... 1.5			
Form of assembly	-	-	vertical			
Ambient conditions						
Energy dissipation (2 kHz switching frequency)	P	W	68	87	115	130
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)			

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
1.85 kW	4.2 A	4.2 A	4.2 A	3.5 A	2.9 A
2.2 kW	5.8 A	5.8 A	5.8 A	4.9 A	3.9 A
3.0 kW	7.8 A ¹⁾	7.8 A ¹⁾	7.8 A ¹⁾	6.6 A ¹⁾	5.3 A
4.0 kW	9.0 A ¹⁾	9.0 A ^{1) 3)}	9.0 A ^{1) 3)}	7.6 A ^{1) 3)}	6.1 A ³⁾

¹⁾ Three-phase connection requires a commutating choke

²⁾ Mains current with relative mains impedance ≥ 1% (see Chapter 7 "Electrical installation")

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

5.8 ACU 401 sizes 3 and 4 (5.5 to 15.0 kW, 400 V)

Type							
ACU 401			-19	-21	-22	-23	-25
Size			3			4	
Output, motor side							
Recommended motor shaft power	P	kW	5.5	7.5	9.2	11.0	15.0
Output current	I	A	14.0	18.0	22.0 ³⁾	25.0	32.0
Long-term overload current (60 s)	I	A	21.0	26.3	30.3	37.5	44.5
Short-time overload current (1 s)	I	A	28.0	33.0	33.0	50.0	64.0
Output voltage	U	V	Maximum input voltage, three-phase				
Protection	-	-	Short circuit / earth fault proof				
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency				
Switching frequency	f	kHz	2, 4, 8, 12, 16				
Output, braking resistor							
Min. braking resistance	R	Ω	48	48	48	32	32
Recommended braking resistor (U _{DBC} = 770 V)	R	Ω	80	58	48	48	32
Input, mains side							
Power supply current ²⁾	I	A	14.2	15.8 ¹⁾	20.0 ¹⁾	26.0	28.2 ¹⁾
Mains voltage	U	V	320 ... 528				
Mains frequency	f	Hz	45 ... 66				
Fuses	I	A	16	25		35	
UL type 600 VAC RK5	I	A	20			30	40
Mechanical							
Dimensions	HxWxD	mm	250 x 100 x 200			250 x 125 x 200	
Weight approx.	m	kg	3.0			3.7	
Ingress protection rating	-	-	IP20 (EN60529)				
Connection terminals	A	mm ²	0.2 ... 6			0.2 ... 16	
Form of assembly	-	-	vertical				
Ambient conditions							
Energy dissipation (2 kHz switching frequency)	P	W	145	200	225	240	310
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)				

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
5.5 kW	14.0 A	14.0 A	14.0 A	11.8 A	9.5 A
7.5 kW	18.0 A ¹⁾	18.0 A ¹⁾	18.0 A ¹⁾	15.1 A ¹⁾	12.2 A
9.2 kW ¹⁾	23.0 A	22.7 A ³⁾	22.0 A ³⁾	18.5 A ³⁾	15.0 A ³⁾
11 kW	25.0 A	25.0 A	25.0 A	21.0 A	17.0 A
15 kW	32.0 A ¹⁾	32.0 A ¹⁾	32.0 A ¹⁾	26.9 A ¹⁾	21.8 A

¹⁾ Three-phase connection requires a commutating choke

²⁾ Mains current with relative mains impedance $\geq 1\%$ (see Chapter 7 "Electrical installation")

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

5.9 ACU 401 Size 5 (18.5 to 30.0 kW, 400 V)

Type					
ACU 401			-27	-29	-31
Size			5		
Output, motor side					
Recommended motor shaft power	P	kW	18.5	22.0	30.0
Output current	I	A	40.0	45.0	60.0
Long-term overload current (60 s)	I	A	60.0	67.5	90.0
Short-time overload current (1 s)	I	A	80.0	90.0	120.0
Output voltage	U	V	Maximum input voltage, three-phase		
Protection	-	-	Short circuit / earth fault proof		
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency		
Switching frequency	f	kHz	2, 4, 8		
Output, braking resistor					
Min. braking resistance	R	Ω	16		
Recommended braking resistor (U _{DBC} = 770 V)	R	Ω	26	22	16
Input, mains side					
Power supply current ²⁾	I	A	42.0	50.0	58.0 ¹⁾
Mains voltage	U	V	320 ... 528		
Mains frequency	f	Hz	45 ... 66		
Fuses	I	A	50	63	
UL type 600 VAC RK5	I	A	50	60	
Mechanical					
Dimensions	HxWxD	mm	250x200x260		
Weight approx.	m	kg	8		
Ingress protection rating	-	-	IP20 (EN60529)		
Connection terminals	A	mm ²	up to 25		
Form of assembly	-	-	vertical		
Ambient conditions					
Energy dissipation (2 kHz switching frequency)	P	W	445	535	605
Coolant temperature	T _a	°C	0 ... 40 (3K3 DIN IEC 721-3-3)		

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ³⁾			
Frequency inverter nominal power	Switching frequency		
	2 kHz	4 kHz	8 kHz
18.5 kW	40.0 A	40.0 A	40.0 A
22 kW	45.0 A	45.0 A	45.0 A
30 kW	60.0 A ¹⁾	60.0 A ¹⁾	60.0 A ¹⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance $\geq 1\%$ (see Chapter 7 "Electrical installation")

³⁾ Maximum current in continuous operation

5.10 ACU 401 Size 6 (37.0 to 65.0 kW, 400 V)

Type						
ACU 401			-33	-35	-37	-39
Size			6			
Output, motor side						
Recommended motor shaft power	P	kW	37.0	45.0	55.0	65.0
Output current	I	A	75.0	90.0	110.0	125.0
Long-term overload current (60 s)	I	A	112.5	135.0	165.0	187.5
Short-time overload current (1 s)	I	A	150.0	180.0	220.0	250.0
Output voltage	U	V	Maximum input voltage, three-phase			
Protection	-	-	Short circuit / earth fault proof			
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency			
Switching frequency	f	kHz	2, 4, 8			
Output, braking resistor ⁵⁾						
Min. braking resistance	R	Ω	7.5			
Recommended braking resistor (U _{dBC} = 770 V)	R	Ω	13	11	9	7.5
Input, mains side						
Power supply current ²⁾	I	A	87.0	104.0	105.0 ¹⁾	120.0 ¹⁾
Mains voltage	U	V	320 ... 528			
Mains frequency	f	Hz	45 ... 66			
Fuses	I	A	100	125	125	125
UL type 600 VAC RK5	I	A	100	125	125	125
Mechanical						
Dimensions	HxWxD	mm	400x275x260			
Weight approx.	m	kg	20			
Ingress protection rating	-	-	IP20 (EN60529)			
Connection terminals	A	mm ²	up to 70			
Form of assembly	-	-	vertical			
Ambient conditions						
Energy dissipation (2 kHz switching frequency)	P	W	665	830	1080	1255
Coolant temperature for air cooling ⁶⁾	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)			

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾			
Frequency inverter nominal power	Switching frequency		
	2 kHz	4 kHz	8 kHz
37 kW	75.0 A	75.0 A	75.0 A
45 kW	90.0 A	90.0 A	90.0 A
55 kW	110.0 A ¹⁾	110.0 A ¹⁾	110.0 A ¹⁾
65 kW	125.0 A ^{1) 3)}	125.0 A ^{1) 3)}	125.0 A ^{1) 3)}

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance ≥ 1% (see Chapter 7 "Electrical installation")

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

⁵⁾ As an option, the frequency inverter of this size is available without internal brake transistor.

⁶⁾ Coolant temperature for liquid cooling: see "Operating Instructions Liquid Cooling Supplemental"

5.11 ACU 401 Size 7 (75.0 to 132.0 kW, 400 V)

Type						
ACU 401			-43	-45	-47	-49
Size			7			
Output, motor side						
Recommended motor shaft power	P	kW	75	90	110	132
Output current	I	A	150	180	210	250
Long-term overload current (60 s)	I	A	225	270	315	332
Short-time overload current (1 s)	I	A	270	325	375	375
Output voltage	U	V	Maximum input voltage, three-phase			
Protection	-	-	Short circuit / earth fault proof			
Rotary field frequency	f	Hz	0 ... 599, depending on switching frequency			
Switching frequency	f	kHz	2, 4, 8			
Output, braking resistor ^(external) 5)						
Min. braking resistance	R	Ω	4.5		3.0	
Recommended braking resistor (U _{dB} = 770 V)	R	Ω	6.1	5.1	4.1	3.8
Input, mains side						
Power supply current ²⁾	I	A	143 ¹⁾	172 ¹⁾	208 ¹⁾	249 ¹⁾
Mains voltage	U	V	320 ... 528			
Mains frequency	f	Hz	45 ... 66			
Fuses	I	A	160	200	250	315
Fuses as per UL ⁶⁾ Cooper Bussmann	Type		FWH-250A	FWH-300A	FWH-350A	FWH-400A
Mechanical						
Dimensions	HxWxD	mm	510 x 412 x 351			
Weight approx.	m	kg	45		48	
Ingress protection rating	-	-	IP20 (EN60529)			
Connection terminals	A	mm ²	up to 2 x 95			
Form of assembly	-	-	vertical			
Ambient conditions						
Energy dissipation (2 kHz switching frequency)	P	W	1600	1900	2300	2800
Coolant temperature for air cooling ⁷⁾	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)			

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾			
Frequency inverter nominal power	Switching frequency		
	2 kHz	4 kHz	8 kHz
75 kW	150 A	150 A	150 A
90 kW	180 A	180 A	180 A
110 kW	210 A	210 A	210 A ³⁾
132 kW	250 A	250 A	250 A ³⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance ≥ 1% (see Chapter 7 "Electrical installation")

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

⁵⁾ As an option, the frequency inverter of this size is available without internal brake transistor.

⁶⁾ For UL-compliant fusing, the specified Cooper Bussmann fuses must be used. Other fuses must not be used for UL-conforming fusing.


⁷⁾ Coolant temperature for liquid cooling: see "Operating Instructions Liquid Cooling Supplemental"

5.12 Operation diagrams


The technical data of the frequency inverters refer to the nominal point which was selected to enable a wide range of applications. A functionally and efficient dimensioning (derating) of the frequency inverters is possible based on the following diagrams.

Installation height

Power reduction (Derating),
5%/1000 m above sea level,
 $h_{\max} = 4000$ m




max. coolant temperature,
3.3 °C/1000 m above sea level,




Coolant temperature

Power reduction (Derating)
2.5%/K upper 40 °C, $T_{\max} = 55$ °C



Mains voltage

Reduction of output current at constant output power (Derating)
0.22%/ V upper 400 V, $U_{\max} = 480$ V



6 Mechanical installation

As a standard, the frequency inverters of ingress protection rating IP20 are designed for stationary installation in electrical cabinets.

Apart from the air-cooled standard installation variant described in these Operating Instructions other installation variants are available:

- Feedthrough assembly for sizes 1 through 8, see "Installation Instructions – Feedthrough Assembly"
- ColdPlate for sizes 1 through 5, see "Installation Instructions – ColdPlate"
- Liquid cooling for sizes 6 through 8, see "Operating Instructions Liquid Cooling Supplemental"

During installation, comply with the installation and the safety instructions and note the device specifications.



WARNING

To avoid serious physical injuries or major material damage, only qualified persons are allowed to work on the device.



WARNING

During assembly, make sure that no foreign particles (e.g. chips, dust, wires, screws, tools) can get inside the frequency inverter. Otherwise there is the risk of short circuits and fire.

The frequency inverter complies with IP20 ingress protection rating only if the covers, components and terminals are mounted properly.

Overhead installation or installation in horizontal position is not permissible.



In devices with liquid cooling the coolant hoses must be connected after the mechanical installation procedure. Comply with instructions in the "Operating Instructions Liquid Cooling Supplemental" document.

6.1 Air circulation

NOTICE


Mount the devices with sufficient clearance to other components so that the cooling air can circulate freely. Avoid soiling by grease and air pollution by dust, aggressive gases, etc.

Fan inlet and outlet openings must not be covered.

6.2 Sizes 1 and 2: ACU 201 (up to 3.0 kW) and 401 (up to 4.0 KW)

The frequency inverter is mounted in a vertical position on the assembly panel by means of the standard fittings. The following illustration shows the different mounting possibilities.

Standard installation



For assembly the long side of the fixing plate is inserted in the heat sink and screwed to the assembly panel.


The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]					Assembly dimensions [mm]			
ACU		a	b	c	a1	a2	b1	c1
201	0.25 kW ... 1.1 kW	190	60	178	210 ... 230	260	30	133
	1.5 kW ... 3.0 kW	250	60	178	270 ... 290	315	30	133
401	0.25 kW ... 1.5 kW	190	60	178	210 ... 230	260	30	133
	1.85 kW ... 4.0 kW	250	60	178	270 ... 290	315	30	133

6.3 Sizes 3 and 4: ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)

The frequency inverter is mounted in a vertical position on the assembly panel by means of the standard fittings. The following illustration shows the standard fitting.

Standard installation



For assembly the two fixing brackets are screwed to the heat sink of the frequency inverter and the assembly panel.


The frequency inverters are provided with fixing brackets, which are fitted using four thread-cutting screws. The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]					Assembly dimensions [mm]			
ACU		a	b	c	a1	a2	b1	c1
201	4.0 ... 5.5 kW	250	100	200	270 ... 290	315	12	133
	7.5 ... 9.2 kW	250	125	200	270 ... 290	315	17,5	133
401	5.5 ... 9.2 kW	250	100	200	270 ... 290	315	12	133
	11.0 ... 15.0 kW	250	125	200	270 ... 290	315	17,5	133

6.4 Size 5: ACU 401 (18.5 to 30.0 kW)

The frequency inverter is mounted in a vertical position on the assembly panel by means of the standard fittings. The following illustration shows the standard fitting.

Standard installation



For assembly the two fixing brackets are screwed to the heat sink of the frequency inverter and the assembly panel.

The frequency inverters are provided with fixing brackets, which are fitted using four thread-cutting screws. The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]					Assembly dimensions [mm]			
ACU		a	b	c	a1	a2	b1	c1
401	18.5...30.0 kW	250	200	260	270 ... 290	315	20	160


6.5 Size 6: ACU 401 (37.0 to 65.0 kW) (air-cooled)



For mechanical installation of liquid-cooled size 6 frequency inverters see "Operating Instructions Liquid Cooling Supplemental".

The frequency inverter is mounted in a vertical position on the assembly panel by means of the standard fittings. The following illustration shows the standard fitting.

Standard installation



For assembly the two fixing brackets are screwed to the heat sink of the frequency inverter and the assembly panel.

The frequency inverters are provided with fixing brackets, which are fitted using four thread-cutting screws. The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]					Assembly dimensions [mm]			
ACU		a	b	c	a1	a2	b1	c1
401	37...65 kW	400	275	260	425 ... 445	470	20	160


6.6 Size 7: ACU 401 (75.0 to 132.0 kW)



The illustration shows an example for mechanical installation of air-cooled frequency inverters. The dimensions and fitting elements correspond to those of liquid-cooled size 7 devices.

The frequency inverter is mounted in a vertical position on the assembly panel. The following illustration shows the standard fitting.

Standard installation



The diameter of the fixing holes is 9 mm.

For assembly the back wall of the frequency inverter is screwed to the assembly panel.

The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]				Assembly dimensions [mm]						
ACU	a	b	c	a1	b1	b2	b3	c1	c2	c3
401 75...132 kW	510	412	351	480	392	382	342	338	305	110

7 Electrical installation



WARNING

The electrical installation must be carried out by qualified electricians according to the general and regional safety and installation directives.

The documentation and device specification must be complied with during installation.

Before any assembly or connection work, discharge the frequency inverter. Verify safe isolation from power supply.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time. Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 1 through 7.

Do not connect inappropriate voltage sources. The nominal voltage of the frequency inverter must correspond to the supply voltage.

The frequency inverter must be connected to ground potential.

Do not remove any covers of the frequency inverter while power supply is on.

The connecting cables must be protected externally, considering the maximum voltage and current values of the fuses. The mains fuses and cable cross-sections are to be selected according to EN 602041 and DIN VDE 0298 Part 4 for the nominal operating point of the frequency inverter. According to UL/CSA, the frequency inverter is suitable for operation at a supply network of a maximum of 480 VAC which delivers a maximum symmetrical current of 5000 A (effective value) if protected by fuses of class RK5. Only use copper cables with a temperature range of 60 / 75 °C.

The frequency inverters are to be grounded properly, i.e. large connection area and with good conductivity. The leakage current of the frequency inverters may exceed AC 3.5 mA or DC 10 mA. According to EN 61800-5-1 a permanent connection must be provided. The protective conductor cross-section required for grounding the fixing plate must be selected according to the size of the unit. In these applications, the cross-section must correspond to the recommended cross-section of the wire.



CAUTION

IP20 ingress protection rating is only achieved with terminals plugged and properly mounted covers.

Special connection variants are possible apart from the standard connection variant described in these Operating Instructions:

- Parallel connection (see "Application Manual – Parallel Connection")
- DC supply (if you have any questions on this, contact BONFIGLIOLI Customer Service.)

Connection Conditions

- The frequency inverter is suited for connection to the public or industrial supply mains according to the technical data. If the transformer output of the supply mains is ≤ 500 kVA, a mains commutation choke is only necessary for the frequency inverters identified in the technical data. The other frequency inverters are suitable for connection without a mains commutating choke with a relative mains impedance $\geq 1\%$.
- Check, based on the specifications of EN 61000-3-2, if the devices can be connected to the public supply means without taking additional measures. The frequency inverters ≤ 9.2 kW with integrated EMC filter comply with the emission limits of the product standard EN 61800-3 up to a motor cable length of 10 m, without additional measures being required. Increased requirements in connection with the specific application of the frequency inverter are to be met by means of optional components. Commutating chokes and EMC filters are optionally available for the series of devices.

- Operation on an unearthed mains (IT mains) is admissible after disconnection of the Y capacitors in the interior of the device. For disconnection of the Y capacitors, please contact BONFIGLIOLI.
- Interference-free operation with residual current device is guaranteed at a tripping current ≥ 30 mA if the following points are observed:
 - One-phase power supply (L1/N): Pulse current and alternating current sensitive residual current devices (Type A to EN 61800-5-1)
 - Two-phase power supply (L1/L2) or Three-phase power supply (L1/L2/L3): All-current sensitive residual current devices (Type B to EN 61800-5-1)
 - Use EMC filters with reduced leakage current or, if possible, do not use EMC filters at all.
 - The length of the shielded motor cable is ≤ 10 m and there are no additional capacitive components between the mains or motor cables and PE.

**WARNING**

Please note (according to EN61800-5-1): This product may cause direct current in the protective earth conductor. Where residual current devices (RCD) or residual current monitors (RCM) are used as a protection against direct or indirect contact, only RCDs / RCMs of Type B are permissible on the power supply side of this product.


- The fuses to be used are to be selected depending on the specific application. The safety recommendations in the Technical Data are valid for continuous operation without overload.


7.1 EMC information

The frequency inverters are designed according to the requirements and limit values of product norm EN 61800-3 with an interference immunity factor (EMI) for operation in industrial applications. Electromagnetic interference is to be avoided by expert installation and observation of the specific product information.

Measures

- Install the frequency inverters and commutating chokes on a metal mounting panel. Ideally, the mounting panel should be galvanized, not painted.
- Provide proper equipotential bonding within the system or plant. Plant components such as electrical cabinets, control panels, machine frames must be connected by means of PE cables, i.e. sufficient area and with good conductivity.
- The shield of the control cables is to be connected to ground potential properly, i.e. with good conductivity, on both sides (shield clamp). Mount shield clamps for cable shields close to the unit.
- Connect the frequency inverter, the commutating choke, external filters and other components to an earthing point via short cables.
- Excessive cable length and loosely suspended cabling must be avoided.
- Contactors, relays and solenoids in the electrical cabinet are to be provided with suitable interference suppression components.





A Mains connection

The length of the mains supply cable is not limited. However, it must be installed separate from the control, data and motor cables.

B DC-link connection

The frequency inverters are to be connected to the same mains potential or a common direct voltage source. Cables longer than 300 mm are to be shielded. The shield must be connected to the mounting panel on both sides.

C Control connection

Keep control and signal cables physically separate from the power cables. Analog signal lines are to be connected to the shield potential on one side. Install sensor cables separate from motor cables.

D Motor and braking resistor

The shield of the motor cable is to be connected to ground potential properly on both sides. On the motor side use a metal compression gland. On the frequency inverter side an appropriate shield clamp is to be used. The signal cable used for monitoring the motor temperature must be kept separate from the motor cable. Connect the shield of this line on both sides. If a braking resistor is used, the connection cable must also be shielded, and the shield is to be connected to earth potential on both sides.

E Relay

The relay enables using high-energy signals.

Line choke

Line chokes reduce mains harmonics and reactive power. In addition, a longer service life of the frequency inverter is possible. When using a line choke, note that line chokes may reduce the maximum output voltage of the frequency inverter.

The line choke must be installed between the mains connection and the input filter.

Input filter

Input filters reduce grid-bound, high-frequency radio interference voltage.


Install the input filter on the mains side upstream of the frequency inverter.



CAUTION

The frequency inverters meet the requirements of the low-voltage directive 2006/95/EC and the requirements of the EMC directive 2004/108/EC. The EMC product standard EN 61800-3 relates to the drive system. The documentation provides information on how the applicable standards can be complied if the frequency inverter is a component of the drive system. The declaration of conformity is to be issued by the supplier of the drive system.

7.2 Block diagram



A Relay connection S3OUT

Change-over contact, response time approx. 40 ms,

- Make contact AC 5 A / 240 V, DC 5 A (ohmic) / 24 V
- Break contact AC 3 A / 240 V, DC 1 A (ohmic) / 24 V

B Voltage output/input

Bidirectional, DC 20 V voltage output ($I_{\max}=180$ mA) or input for external power supply DC 24 V $\pm 10\%$

C Digital input S1IND/STOA

Digital signal, STOA (1st shut-down path for safety function STO – “Safe Torque Off”), response time: approx. 10 ms (On), 10 μ s (Off), U_{\max} = DC 30 V, 10 mA at DC 24 V, PLC compatible

D Digital inputs S2IND ... S6IND

Digital signal: Response time approx. 2 ms, U_{\max} = DC 30 V, 10 mA at 24 V, PLC compatible, frequency signal: DC 8...30 V, 10 mA at DC 24 V, f_{\max} = 150 kHz

E Digital input S7IND/STOB

Digital signal, STOB (2nd shut-down path for safety function STO – “Safe Torque Off”), response time: approx. 10 ms (on), 10 μ s (off), U_{\max} = DC 30 V, 10 mA at DC 24 V, PLC compatible

F Digital output S1OUT

Digital signal, DC 24 V, I_{\max} = 50 mA, PLC compatible, overload and short-circuit proof

G Multifunction Output MFO1

Analog signal: DC 24 V, I_{\max} = 50 mA, pulse-width modulated, f_{PWM} = 116 Hz,
 Digital signal: DC 24 V, I_{\max} = 50 mA, PLC compatible,
 Frequency signal: DC 0...24 V, I_{\max} = 40 mA, f_{\max} = 150 kHz,
 overload and short-circuit proof

H Multifunction input MFI1

Analog signal: Resolution 12 bit, DC 0...10 V (R_i = 70 k Ω), 0...20 mA (R_i = 500 Ω),
 Digital signal: Response time approx. 4 ms, U_{\max} = DC 30 V, 4 mA at DC 24 V,
 PLC compatible

7.3 Optional components

Due to modular hardware components, the frequency inverters can be integrated in the automation concept easily. The standard and optional modules are recognized during the initialization, and the controller functionality is adjusted automatically. For the information required for installation and handling of the optional modules, refer to the corresponding documentation.




WARNING

The hardware modules at slots B and C may only be assembled and disassembled after the frequency inverter has been disconnected safely from power supply. Work on the device may only be started once the DC link capacitors have discharged. The discharge time is at least 3 minutes in the case of sizes 1 through 7.

The unit may only be connected with the power supply switched off.

Verify safe isolation from power supply.

Hardware modules



A Control unit KP500

Connection of the optional control unit KP500 or an interface adapter KP232.

B Communication module CM

Slot for connection to various communication protocols:

- CM-232: RS232 interface
- CM-485: RS485 interface
- CM-PDP: Profibus-DP interface
- CM-CAN: CANopen interface
- Other communication modules, see Chapter 1.1 "Instruction Manuals".

C Extension module EM

Slot for customer-specific adaptation of the control inputs and outputs to various applications:

- EM-ENC: extended speed sensor evaluation
- EM-RES: Resolver evaluation
- EM-ABS: Absolute encoder evaluation
- EM-IO, analog and digital inputs and outputs
- EM-SYS: System Bus

(system bus in combination with CM-CAN communication module upon request)



CAUTION

If two optional components with CAN-Protocol controller are installed, the system bus interface in the EM extension module is deactivated!

7.4 Connection of Unit

7.4.1 Dimensioning of conductor cross-section

The connecting cables must be protected externally, considering the maximum voltage and maximum current values of the fuses. The line fuses and cable cross-sections must be dimensioned according to EN 602041 and DIN VDE 0298 Part 4 for the nominal operating point of the frequency inverter.

HINWEIS

The fuses must be chosen depending on the individual application. The values recommended in the technical Data apply for the continuous rated operation without overload.

The cable dimensions should be selected according to the current load and voltage drop to be expected. Select the cable cross-section of the cables such that the voltage drop is as small as possible. If the voltage drop is too great, the motor will not reach its full torque. Also comply with any additional national and application-specific regulations and the separate UL instructions. For typical mains fuses, refer to chapter 5 "Technical data".

According to EN61800-5-1, the cross-sections of the PE conductor shall be dimensioned as follows:

Mains cable	Protective conductor
Mains cable up to 10 mm ²	Install two protective conductors of the same size as the mains cable, or one protective conductor of a size of 10 mm ² .
Mains cable 10...16 mm ²	Install one protective conductor of the same size as the mains feeder.
Mains cable 16...35 mm ²	Install one protective conductor of a size of 16 mm ² .
Mains cable > 35 mm ²	Install one protective conductor of half the size of the mains feeder.

The following tables provide an overview of typical cable cross-sections (copper cable with PVC insulation, 30 °C ambient temperature, continuous mains current max. 100% rated input current, installation variant C). Actual mains cable cross-section requirements may deviate from these values depending on actual operating conditions.

7.4.1.1 Typical cross-sections Size 1 through 7 (0.25 kW ... 132 kW)

The following tables provide an overview of typical cable cross-sections (copper cable with PVC insulation, 30 °C ambient temperature, continuous mains current max. 100% rated input current, installation variant B2). Actual mains cable cross-section requirements may deviate from these values depending on actual operating conditions.

230 V: One-phase (L/N) and two-phase (L1/L2) connection

201	Mains cable	PE-conductor	Motor cable
-01 0.25 kW -03 0.37 kW -05 0.55 kW -07 0.75 kW -09 1.1 kW	1.5 mm ²	2x1.5 mm ² or 1x10 mm ²	1.5 mm ²
-11 1.5 kW -13 2.2 kW -15 3 kW	2.5 mm ²	2x2.5 mm ² or 1x10 mm ²	1.5 mm ²
-18 4 kW	4 mm ²	2x4 mm ² or 1x10 mm ²	4 mm ²

230 V: Three-phase connection (L1/L2/L3)

201		Mains cable	PE-conductor	Motor cable
-01	0.25 kW	1.5 mm ²	2x1.5 mm ² or 1x10 mm ²	1.5 mm ²
-03	0.37 kW			
-05	0.55 kW			
-07	0.75 kW			
-09	1.1 kW			
-11	1.5 kW			
-13	2.2 kW			
-15	3 kW			
-18	4 kW	4 mm ²	2x4 mm ² or 1x10 mm ²	4 mm ²
-19	5.5 kW			
-21	7.5 kW	6 mm ²	2x6 mm ² or 1x10 mm ²	6 mm ²
-22	9.2 kW	10 mm ²	1x10 mm ²	10 mm ²

400V: Three-phase connection (L1/L2/L3)

401		Mains cable	PE-conductor	Motor cable
-01	0.25 kW	1.5 mm ²	2x1.5 mm ² or 1x10 mm ²	1.5 mm ²
-03	0.37 kW			
-05	0.55 kW			
-07	0.75 kW			
-09	1.1 kW			
-11	1.5 kW			
-12	1.85 kW			
-13	2.2 kW			
-15	3 kW			
-18	4 kW			
-19	5.5 kW	2.5 mm ²	2x2.5 mm ² or 1x10 mm ²	2.5 mm ²
-21	7.5 kW			
-22	9.2 kW	4 mm ²	2x4 mm ² or 1x10 mm ²	4 mm ²
-23	11 kW			
-25	15 kW	6 mm ²	2x6 mm ² or 1x10 mm ²	6 mm ²
-27	18.5 kW	10 mm ²	1x10 mm ²	10 mm ²
-29	22 kW	16 mm ²	1x16 mm ²	16 mm ²
-31	30 kW			
-33	37 kW	35 mm ²	1x16 mm ²	25 mm ²
-35	45 kW	50 mm ²	1x25 mm ²	35 mm ²
-37	55 kW	50 mm ²	1x25 mm ²	50 mm ²
-39	65 kW	70 mm ²	1x35 mm ²	70 mm ²
-43	75 kW	70 mm ²	1x50 mm ²	95 mm ²
-45	90 kW	95 mm ²	1x70 mm ²	2x70 mm ²
-47	110 kW	2x70 mm ²	1x70 mm ²	2x70 mm ²
-49	132 kW	2x70 mm ²	1x70 mm ²	2x70 mm ²

7.4.2 Mains connection



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify safe isolation from power supply.

Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 1 through 7.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

The mains fuses and cable cross-sections are to be selected according to EN 602041 and DIN VDE 0298 Part 4 for the nominal operating point of the frequency inverter. According to UL/CSA, approved Class 1 copper lines with a temperature range of 60/75 °C and matching mains fuses are to be used for the power cables. The electrical installation is to be done according to the device specifications and the applicable standards and directives.



CAUTION

The control, mains and motor lines must be kept physically separate from one another.

The cables connected to the frequency inverters may not be subjected to high-voltage insulation tests unless appropriate circuitry measures are taken before.

7.4.3 Motor connection



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify safe isolation from power supply.

Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 1 through 7.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

Bonfiglioli Vectron MDS GmbH recommends using shielded cables for the connection of the motor and the braking resistor to the frequency inverter. The shield is to be connected to PE potential properly, i.e. with good conductivity, on both sides. The control, mains and motor lines must be kept physically separate from one another. The user must comply with the applicable limits stipulated in the relevant national and international directives as regards the application, the length of the motor cable and the switching frequency.

7.4.3.1 Length of motor cables, without filter

Permissible length of motor cable without output filter		
Frequency inverter	unshielded cable	shielded cable
0.25 kW ... 1.5 kW	50 m	25 m
1.85 kW ... 4.0 kW	100 m	50 m
5.5 kW ... 9.2 kW	100 m	50 m
11.0 kW ... 15.0 kW	100 m	50 m
18.5 kW ... 30.0 kW	150 m	100 m
37.0 kW ... 65.0 kW	150 m	100 m
75.0 kW ... 132.0 kW	150 m	100 m
160.0 kW ... 400.0 kW	150 m	100 m

The specified lengths of the motor cables must not be exceeded if no output filter is installed.



Frequency inverters ≤ 9.2 kW with integrated EMC filter comply with the emission limits stipulated in EN 61800-3 if the motor cable is no longer than 10 m. Frequency inverters ≤ 9.2 kW of Design 3 with integrated EMC filter comply with EN 61800-3 if the motor cable is no longer than 20m. Customer-specific requirements can be met using an optional filter.

7.4.3.2 Motor cable length, with output filter dU/dt

Longer motor cables can be used after taking appropriate technical measures, e.g. use of low-capacitance cables and output filters. The following table contains recommended values for the use of output filters.

Motor cable length with output filter		
Frequency inverter	unshielded cable	shielded cable
0.25 kW ... 1.5 kW	upon request	upon request
1.85 kW ... 4.0 kW	150 m	100 m
5.5 kW ... 9.2 kW	200 m	135 m
11.0 kW ... 15.0 kW	225 m	150 m
18.5 kW ... 30.0 kW	300 m	200 m
37.0 kW ... 65.0 kW	300 m	200 m
75.0 kW ... 132.0 kW	300 m	200 m
160.0 kW ... 400.0 kW	300 m	200 m

7.4.3.3 Motor cable length, with sinus filter

Motor cables can be much longer if sinus filters are used. By conversion in sinus-shaped currents, high-frequency portions which might limit the cable length are filtered out. Also consider the voltage drop across the cable length and the resulting voltage drop at the sinus filter. The voltage drop results in an increase of the output current. Check that the frequency inverter can deliver the higher output current. This must be considered in the projecting phase already.

If the motor cable length exceeds 300 m, please consult BONFIGLIOLI.

7.4.3.4 Group drive

In the case of a group drive (several motors at one frequency inverter), the total length shall be divided across the individual motors according to the value given in the table. Please note that group drive with synchronous servomotors is not possible.

Use a thermal monitoring element on each motor (e.g. PTC resistor) in order to avoid damage.

7.4.3.5 Speed sensor connection

Install sensor cables physically separate from motor cables. Comply the sensor manufacturer's specifications.

Connect the shield close to the frequency inverter and limit the length to the necessary minimum.

7.4.4 Connection of a braking resistor

Install a braking resistor if feedback of regenerative energy is expected. Overvoltage shutdowns can be avoided by this.



⚠ DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify safe isolation from power supply.

Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 1 through 7.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.



⚠ WARNING

The surface of the braking resistor may reach a high temperature during operation and may remain hot for some time after operation. Do not touch the braking resistor while the frequency inverter is in operation or ready for operation. Non-compliance may result in burns. Install a safeguard to prevent touching or provide a warning sign.

Do not install the braking resistor near inflammable or heat-sensitive materials.

Do not cover the braking resistor.




⚠ CAUTION

Bonfiglioli Vectron MDS GmbH recommends using a temperature switch. Depending on the resistor selected, the temperature switch is integrated as a standard or available as an option. The temperature switch disconnects the frequency inverter from mains supply if the braking resistor is overloaded.

Using braking resistors without temperature switches may result in critical situations.

Braking resistors are connected via terminal X2.



Limit the length of the braking resistor cables to the necessary minimum.

7.5 Connection by size

7.5.1 Sizes 1 and 2: ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)

Frequency inverters are connected to mains via plug-in terminal X1. The motor and braking resistor are connected to the frequency inverter via plug-in terminal X2. IP20 ingress protection rating (EN60529) is only guaranteed with the terminals plugged.



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.


Verify safe isolation from power supply.

Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 1 and 2.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.


Switch off power supply before connecting or disconnecting the keyed plug-in terminals **X1** and **X2**.

Mains connection ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)








- ① With a mains current above 10 A, the mains power connection 230 V 1ph/N/PE and the mains power connection 230 V 2ph/N/PE are to be done on two terminals.

Motor connection ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)




Phoenix ZEC 1,5/.. ST7,5


	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16




Delta connection




Star connection







Connection of brake resistor with temperature switch



X2



Phoenix ZEC 1,5/.. ST7,5

	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16

7.5.2 Sizes 3 and 4: ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.



Verify safe isolation from power supply.

Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 3 and 4.


When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

Switch off power supply before connecting or disconnecting the mains cable to/from terminal **X1**, the motor cables and the brake resistor to/from terminal **X2**.

Mains connection ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)



ACTIVE Cube 201-18 (4.0 kW):



4.0 kW ... 9.2 kW
6qmm / RM7,5

	0.2 ... 6 mm ² AWG 24 ... 10
	0.2 ... 6 mm ² AWG 24 ... 10
	0.25 ... 4 mm ² AWG 22 ... 12
	0.25 ... 4 mm ² AWG 22 ... 16


11 kW ... 15 kW
16qmm / RM10+15

	0.2 ... 16 mm ² AWG 24 ... 6
	0.2 ... 16 mm ² AWG 24 ... 6
	0.25 ... 10 mm ² AWG 22 ... 8
	0.25 ... 10 mm ² AWG 22 ... 8





ACU 201-18 (4,0 kW): one and three-phase connection possible

ACU 201-19 (5,5 kW) and higher: three-phase connection possible





Motor connection ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)




4.0 kW ... 9.2 kW
6qmm / RM7,5

	0.2 ... 6 mm ² AWG 24 ... 10
	0.2 ... 6 mm ² AWG 24 ... 10
	0.25 ... 4 mm ² AWG 22 ... 12
	0.25 ... 4 mm ² AWG 22 ... 16





11.0 kW ... 15.0 kW
16qmm / RM10+15

	0.2 ... 16 mm ² AWG 24 ... 6
	0.2 ... 16 mm ² AWG 24 ... 6
	0.25 ... 10 mm ² AWG 22 ... 8
	0.25 ... 10 mm ² AWG 22 ... 8





Connection of brake resistor with temperature switch



4.0 kW ... 9.2 kW
6qmm / RM7,5

	0.2 ... 6 mm ² AWG 24 ... 10
	0.2 ... 6 mm ² AWG 24 ... 10
	0.25 ... 4 mm ² AWG 22 ... 12
	0.25 ... 4 mm ² AWG 22 ... 16

11.0 kW ... 15.0 kW
16qmm / RM10+15

	0.2 ... 16 mm ² AWG 24 ... 6
	0.2 ... 16 mm ² AWG 24 ... 6
	0.25 ... 10 mm ² AWG 22 ... 8
	0.25 ... 10 mm ² AWG 22 ... 8

7.5.3 Size 5 ACU 401 (18.5 to 30.0 kW)



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.


Verify safe isolation from power supply.

Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of size 5.


When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

Switch off power supply before connecting or disconnecting the mains cable to/from terminal **X1**, the motor cables and the brake resistor to/from terminal **X2**.


Mains connection ACU 401 (18.5 to 30.0 kW)



X1



3ph / 400V AC




2.5 Nm
22.1 lb-in


18.5 kW ... 30.0 kW
PHOENIX MKDSP 25/ 6-15,00-F

	0.5 ... 35 mm ² AWG 20 ... 2
	0.5 ... 25 mm ² AWG 20 ... 4
	1.00 ... 25 mm ² AWG 18 ... 4
	1.5 ... 25 mm ² AWG 16 ... 4

Motor connection ACU 401 (18.5 to 30.0 kW)



Connection of brake resistor with temperature switch



7.5.4 Size 6 ACU 401 (37.0 to 65.0 kW)



⚠ DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify safe isolation from power supply.




Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of size 6.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

Switch off power supply before connecting or disconnecting the mains cable to/from terminal **X1**, the motor cables and the brake resistor to/from terminal **X2**.


The following illustrations show the air-cooled variant of an ACU 401 frequency inverter size 6 as an example. Illustrations of the corresponding liquid-cooled device are given in the "Operating Instructions Liquid Cooling Supplemental". The electrical interfaces for both variants are basically the same.

Mains connection ACU 401 (37.0 to 65.0 kW)




37.0 kW ... 65.0 kW
threaded bolt M8x25
wire cross section up to 70 mm²

Motor connection ACU 401 (37.0 to 65.0 kW)



Connection of brake resistor with temperature switch



Optionally, devices of this size are available without brake chopper. These devices are designed without connecting terminals for the braking resistor.

7.5.5 Size 7 ACU 401 (75.0 to 132.0 kW)



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.


Verify safe isolation from power supply.

Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of size 7.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.


Switch off power supply before connecting or disconnecting the mains cable, the motor cables and the brake resistor.

Mains connection ACU 401 (75.0 to 132 kW)




Threaded bolt M8x20

Motor connection ACU 401 (75.0 to 132 kW)



Connection of brake resistor with temperature switch



Optionally, devices of this size are available without brake chopper. These devices are designed without connecting terminals for the braking resistor.

7.6 Control terminals

The control and software functionality is freely configurable to ensure a reliable and economical operation. The operating instructions describe the factory settings of the standard connections in the relevant *Configuration 30* as well as the software parameters to be set up.

CAUTION




The unit may only be connected with the power supply switched off.





Verify safe isolation from power supply.

Switch off power supply before connecting or disconnecting the control inputs and outputs. Otherwise, components may be damaged.

Control terminals



Wieland DST85 / RM3,5

	0.14 ... 1.5 mm ² AWG 30 ... 16
	0.14 ... 1.5 mm ² AWG 30 ... 16
	0.25 ... 1.0 mm ² AWG 22 ... 18
	0.25 ... 0.75 mm ² AWG 22 ... 20

0.2 ... 0.3 Nm
1.8 ... 2.7 lb-in

Control terminal X210A

Term.	Description
1	- voltage output 20 V, $I_{\max}=180$ mA ¹⁾ or - input for external power supply DC 24 V $\pm 10\%$
2	GND 20 V and GND 24 V (ext.)
3	Digital input STOA (1. shut-down path for "Safe Torque Off" function), $U_{\max}=\text{DC } 30$ V, 10 mA at DC 24 V, input resistance: 2.3 k Ω , PLC compatible, response time approx. 10 ms
4	Digital input S2IND, $U_{\max}=\text{DC } 30$ V, 10 mA at DC 24 V, Input resistance: 2.3 k Ω , PLC compatible, response time approx. 2 ms
5	Digital input S3IND, $U_{\max}=\text{DC } 30$ V, 10 mA at DC 24 V, Input resistance: 2.3 k Ω , PLC compatible, response time approx. 2 ms
6	Digital input S4IND, $U_{\max}=\text{DC } 30$ V, 10 mA at DC 24 V, Input resistance: 2.3 k Ω , PLC compatible, Frequency signal: 0...30 V, 10 mA at 24 V, $f_{\max}=150$ kHz
7	Digital input S5IND, $U_{\max}=\text{DC } 30$ V, 10 mA at DC 24 V, Input resistance: 2.3 k Ω , PLC compatible, Frequency signal: 0...30 V, 10 mA at 24 V, $f_{\max}=150$ kHz

Control terminal X210B	
Term.	Description
1	Digital input S6IND, U_{\max} =DC 30 V, 10 mA at 24 V, input resistance: 2.3 k Ω , PLC compatible, response time approx. 2 ms
2	Digital input STOA (2nd shut-down path for "Safe Torque Off" function), U_{\max} =30 V, 10 mA at DC 24 V, input resistance: 2.3 k Ω , PLC-compatible, response time approx. 10 ms
3	Digital output S1OUT, U =24 V, I_{\max} =50 mA, overload and short-circuit proof
4	Multifunction output MFO1, Analog signal: U = 24 V, I_{\max} = 50 mA, pulse-width modulated, f_{PWM} = 116 Hz, Digital signal: U =24 V, I_{\max} =50 mA, overload and short-circuit proof, Frequency signal: 0...24 V, I_{\max} =50 mA, f_{\max} =150 kHz
5	Reference output 10 V, I_{\max} =4 mA
6	Multifunction input MFI1, Analog signal: resolution 12 Bit, 0...+10 V (R_i =70 k Ω), 0...20 mA (R_i = 500 Ω), Digital signal: response time approx. 4 ms, U_{\max} =30 V, 4 mA at 24 V, PLC compatible
7	Ground / GND 10 V

- ¹⁾ The power output on terminal X210A.1 may be loaded with a maximum current of I_{\max} = 180 mA. The maximum current available is reduced by the digital output S1OUT and multifunction output MFO1.

	Level:
Digital inputs (X210A.3 ... X210B.2)	Low: 0 V ... 3 V, High: 12 V ... 30 V
Digital output (X210B.3)	

7.6.1 External DC 24 V power supply

The bidirectional control terminals X210A.1/ X210A.2 can be used as a voltage output or voltage input. By connecting an external power supply of DC 24 V $\pm 10\%$ to terminals X210A.1/X210A.2, the function of inputs and outputs as well as the communication can be maintained.

Requirements to be met by external power supply	
Input voltage range	DC 24 V $\pm 10\%$
Rated input current	Max. 1.0 A (typically 0.45 A)
Peak inrush current	Typically: < 20 A
External fuse	Via standard fuse elements for rated current, characteristic: slow
Safety	Safety extra low voltage (SELV) according to EN 61800-5-1

NOTICE

The digital inputs and the DC 24 V terminal of the electronic control equipment can withstand external voltage up to DC 30 V. Avoid higher voltage levels. Higher voltages may destroy the unit.

Use suitable external power supply units with a maximum output current of DC 30 V or use appropriate fuses to protect the unit.



The application manual "Safe Torque Off STO" must be complied with, particularly if the safety function described there is used.

7.6.2 Relay output


By default, the freely programmable relay output is linked to the monitoring function (factory setting). The logic link to various functions can be freely configured via the software parameters. Connection of the relay output is not absolutely necessary for the function of the frequency inverter.

Relay output	
	Phoenix ZEC 1,5/3ST5,0
	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16

Control terminal X10	
Term.	Description
1 ... 3	Relay output, floating change-over contact, response time approx. 40 ms, maximum contact load: make contact: AC 5 A / 240 V, DC 5 A (ohmic) / 24 V break contact: AC 3 A / 240 V, DC 1 A (ohmic) / 24 V

7.7 X13 connection in ACU 501 and ACU 601

When an ACU 501 or ACU 601 device is used, connection of AC 3x400 V at X13 is required. The illustration shows the X13 terminal on an air-cooled device as an example.



Auxiliary voltage terminal X13	
1 ... 6	Not used
7	⊕ PE
8	L1
9	L2
10	L3
Connection	
Connected load	≥ 1.2 kW
Supply voltage	400 V +- 10 %
Supply frequency	50 / 60 Hz

7.7.1 Motor Thermo-Contact

The ACU frequency inverters can evaluate the thermal switch of motor. By default, terminal X210B.1 (S6IND) is configured as an input for this evaluation. Connect the thermal switch to the digital input and the DC 24 V supply unit X210A.1. For parameterization, refer to Sections 14.6 "Motor temperature" and 16.4.5 "Thermocontact".

7.7.2 Control terminals – Wiring diagrams of configurations

The control hardware and the software of the frequency inverter are freely configurable to a great extent. Certain functions can be assigned to the control terminals, and the internal logic of the software modules can be freely selected.

Thanks to the modular design, the frequency inverter can be adapted to a great range of different driving tasks.

The demands made of the control hardware and software are well known in the case of standard driving tasks. This control terminal logic and internal function assignments of the software modules are available in standard configurations. These assignments can be selected via *Configuration 30*. The configurations are described in the following section.



The ACU devices of the ACTIVE Cube series feature the integrated STO function ("Safe Torque Off"). If this function is not required, the "Controller release" signal must be connected to inputs S1IND/STOA and S7IND/STOB.

Inputs S1IND/STOA and S7IND/STOB are connected in series.



⚠ WARNING

The digital inputs S1IND/STOA and S2IND are driven by the same signal, safe disconnection of energy supply to the motor as per the STO safety function ("Safe Torque OFF") is not guaranteed.

7.8 Configurations overview

Refer to following table in order to learn which combinations of functions and control methods are possible. Configurations „Standard“, „Technology Controller“ and „Torque Control“ will be described in the following sections. For configurations „Electronic Gear“, „Positioning“ and „Brake Control“, please refer to the corresponding application manuals.

Configurations:

Function	V/f	Sensorless vector	Speed controlled	Servo	Sensorless vector
Standard	110	410	210	510	610
Technology controller	111	411	211	511	611
Electronic gear with position controller ¹⁾	115	415	215	515	
Electronic gear + index controller ¹⁾	116		216	516	
Torque control		430	230	530	630
Positioning ²⁾		440	240	540	640
Brake control ³⁾	160	460	260	560	

Refer to the following manuals:

- 1) Application manual: Electronic Gear, Position Control and Index Control
- 2) Application Manual: Positioning
- 3) Application Manual: Hoisting Gear Drives and Load Estimation



Control methods 2xx can be used with **HTL** encoders (with or without reference pulse) at basic device or an extension module.


In order to use control methods 2xx with **TTL** encoders, an extension module is required.

An extension module EM-RES for evaluation of resolver signals is required for operation of a synchronous machine (control method 5xx).

An extension module EM-ABS for signal evaluation is required for operation with absolute encoders (Hiperface, EnDat2.1, SSI).

7.8.1 Configuration 110 – Sensorless Control

Configuration 110 contains the functions for variable-speed control of a 3-phase machine in a wide range of standard applications. The motor speed is set according to the selected ratio of the reference frequency to the necessary voltage.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1. shut-down path of STO safety function)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Data Set Change-Over 1
X210A.7	Data Set Change-Over 2

Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOA (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0 ...+10 V
X210B.7	Ground 10 V

7.8.2 Configuration 111 – Sensorless Control with Technology Controller

Configuration 111 extends the functionality of the sensorless control by software functions for easier adaptation to the customer's requirements in different applications. The Technology Controller enables flow rate, pressure, level or speed control.



Control terminal X210A

X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Fixed Percent Change-Over 1
X210A.5	Fixed Percent Change-Over 2
X210A.6	Data Set Change-Over 1
X210A.7	Data Set Change-Over 2


Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V
X210B.6	Actual percentage value 0 ...+10 V

X210B.7 | Ground 10 V

7.8.3 Configuration 410 – Sensorless Field-Oriented Control

Configuration 410 contains the functions for sensorless, field-oriented control of an asynchronous machine. The current motor speed is determined from the present currents and voltages in combination with the machine parameters. Separate control of torque and flux-forming current enables a high drive dynamism at a high load moment.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Data Set Change-Over 1
X210A.7	Data Set Change-Over 2

Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0 ...+10 V
X210B.7	Ground 10 V

7.8.4 Configuration 411 –Sensorless Field-Oriented Control with Technology Controller

Configuration 411 extends the functionality of the sensorless field-oriented control of Configuration 410 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



Control terminal X210A

X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Fixed Percent Change-Over 1
X210A.5	no function assigned
X210A.6	Data Set Change-Over 1
X210A.7	Data Set Change-Over 2


Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal

X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V
X210B.6	Actual percentage value 0 ...+10 V
X210B.7	Ground 10 V

7.8.5 Configuration 430 – Sensorless Field-Oriented Control, speed and torque controlled

Configuration 430 extends the functionality of the sensorless field-oriented control of Configuration 410 by a Torque Controller. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Control terminal X210A

X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Start of clockwise operation
X210A.5	n-/M change-over control function
X210A.6	Data Set Change-Over 1
X210A.7	Data Set Change-Over 2

Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0...+10 V or reference torque as percentage
X210B.7	Ground 10 V

7.8.6 Configuration 210 – Field-Oriented Control, Speed Controlled




Control methods 2xx can be used with **HTL** encoders (with or without reference pulse) at basic device or an extension module.

In order to use control methods 2xx with **TTL** encoders, an extension module is required.

An extension module EM-ABS for signal evaluation is required for operation with absolute encoders (Hiperface, EnDat2.1, SSI).

Configuration 210 contains the functions for speed-controlled, field-oriented control of a 3-phase machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Speed sensor track B
X210A.7	Speed sensor track A

Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0 ...+10V
X210B.7	Ground 10 V

7.8.7 Configuration 211 – Field-Oriented Control with Technology Controller

Configuration 211 extends the functionality of the speed-controlled, field-oriented control of Configuration 210 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Fixed Percent Change-Over 1
X210A.5	no function assigned
X210A.6	Speed sensor track B
X210A.7	Speed sensor track A

Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V
X210B.6	Actual percentage value 0 ...+10 V
X210B.7	Ground 10 V

7.8.8 Configuration 230 – Field-Oriented Control, Speed and Torque Controlled

Configuration 230 extends the functionality of Configuration 210 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Control terminal X210A

X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Start of clockwise operation
X210A.5	n-/M change-over control function
X210A.6	Speed sensor track B
X210A.7	Speed sensor track A

Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer

X210B.6	Reference speed 0...+10 V or reference torque as percentage
X210B.7	Ground 10 V

7.8.9 Configuration 510 – Field-Oriented Control of Synchronous Machine, Speed Controlled




An extension module EM-RES for evaluation of resolver signals is required for operation of a synchronous machine (control method 5xx).

An extension module EM-ABS for signal evaluation is required for operation with absolute encoders (Hiperface, EnDat2.1, SSI).

For connection of the resolver or absolute encoder, also refer to operating instructions of extension module.

Configuration 510 contains the functions for speed-controlled, field-oriented control of a synchronous machine with resolver feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The necessary resolver feedback results in a precise speed and torque performance.




Control terminal X210A	
X210A.1	Voltage output +20 V or input for external power supply DC 24 V ±10%
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Data Set Change-Over 1
X210A.7	Data Set Change-Over 2

Control terminal X210B	
X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0 ...+10V
X210B.7	Ground 10 V

7.8.10 Configuration 511 –Field-Oriented Control of Synchronous Machine with Technology Controller

Configuration 511 extends the functionality of the field-oriented control of a synchronous machine of Configuration 510 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Fixed Percent Change-Over 1
X210A.5	no function assigned
X210A.6	Data Set Change-Over 1
X210A.7	Data Set Change-Over 2

Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V
X210B.6	Actual percentage value 0 ...+10 V
X210B.7	Ground 10 V

7.8.11 Configuration 530 – Field-Oriented Control of a Synchronous Machine Speed and Torque Controlled

Configuration 530 extends the functionality of Configuration 510 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Control terminal X210A

X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shut-down path of STO safety function)
X210A.4	Start of clockwise operation
X210A.5	n-/M change-over control function
X210A.6	Data Set Change-Over 1
X210A.7	Data Set Change-Over 2


Control terminal X210B

X210B.1	Motor therm. contact
X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer

X210B.6	Reference speed 0...+10 V or reference torque as percentage
X210B.7	Ground 10 V


7.8.12 Configuration 610 – Sensorless Field-Oriented Control of Synchronous Machine, Speed Controlled

Configuration 610 contains the functions for sensorless field-oriented control of a synchronous machine with resolver feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The missing resolver feedback results in slightly lower dynamism and speed quality compared to Configuration 510.



7.8.13 Configuration 611 – Sensorless Field-Oriented Control of Synchronous Machine with Technology Controller


Configuration 611 extends the functionality of the sensorless field-oriented control of a synchronous machine of Configuration 610 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



X210B.2	Digital input STOB (2nd shut-down path of STO safety function)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V
X210B.6	Actual percentage value 0 ...+10 V
X210B.7	Ground 10 V

7.8.14 Configuration 630 – Sensorless Field-Oriented Control of a Synchronous Machine Speed and Torque Controlled

Configuration 630 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Torque Controller. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



7.9 Notes on installation as per UL508c

Thermal motor protection as per UL508c can be realized in devices marked with "TM included" under the nameplate. For ACU devices without the "TM included" label, the following applies as per UL508c: Motor overtemperature identification not featured by the device.

For connection and parameterization of the thermal motor evaluation, refer to Chapter 14.6 "Motor temperature", 16.4.5 "Thermocontact" and 19.5 "Motor circuit breaker".

For installation as per UL508c, the mains feeder may only be protected using approved fuses. For approved fuses, refer to Chapter 5 "Technical data".

For installation as per UL508c, the maximum temperatures specified in Chapter 5 "Technical data" must not be exceeded.

For installation as per UL508c, only copper cables with a rated current of 60/75°C may be used.


For installation as per UL508c, the devices may only be used in "Pollution Degree 2" environments.

According to UL508c, warnings and markings/labels must not be removed.

8 Control unit KP500

The optional KP500 control unit is a practical tool for controlling the frequency inverter and setting and displaying the frequency inverter parameters.

The control unit is not absolutely necessary for the operation of the frequency inverter and can be plugged on when required.



Buttons


A	RUN	Used for starting the drive and opening the CTRL menu. Press the RUN key to open the motor potentiometer function.
	STOP	Used for opening the CTRL menu, stopping the drive and acknowledging faults
J	▲ ▼	Navigate in menu structure and select parameters. Increase or reduce parameter values.
	ENT	Open parameters or switch within the menu structure. Confirm the selected function or parameter.
	ESC	Used for aborting parameters or switching back to the previous menu within the menu structure. Cancel the function or reset parameter value.
	FUN	Used for switching over the key function, access to special functions.

Display

B	Three-digit 7-segment display to show the parameter number.
C	One-digit 7-segment display for display of the active data record, direction of rotation etc.
D	Display selected menu branch:
	VAL Show actual values.
	PARA Select parameters and adjust parameter values.
	CTRL Select a function for adjustment and/or display via the operating unit: SETUP Guided commissioning. Ctrl motor potentiometer and jog function.
	CPY Copy parameters via the control unit: ALL All parameter values are copied. Act Active parameter values are copied only. FOr Control unit memory is formatted and deleted.
E	Status and operating messages:
	WARN Warning about a critical operating behavior.
	FAULT Message indicating that the unit was switched off due to a fault.
	RUN Flashing: signalizes readiness for operation Lighting signalizes operation and release of the power part
	REM Active remote control via interface connection.
F	Function switch-over with the FUN key.
G	Five-digit 7-segment display for display of parameter value and sign.
H	Physical unit of parameter value displayed.
I	Active acceleration or deceleration ramp.
L	Current direction of rotation of the drive.

8.1 Menu structure

The menu structure of the control unit is arranged as shown in the following illustration. Use the arrow keys as well as ESC and ENT to navigate through the menu. The software contains the full set of information and enables a flexible use of the parameter setting and control options.




8.2 Main Menu

The various parameters and information of the frequency inverter can be displayed by means of the control unit. The different functions and parameters are grouped together in four menu branches. From any point in the menu structure you can return to the main menu by pressing the ESC key either continuously or repeatedly.

NOTICE

In the following description of the key functions, a plus (+) between the key symbols indicates that the keys have to be pressed at the same time.

A comma (,) between the key symbols indicates that the keys have to be pressed one after the other.



Use the arrow keys to select the required menu branch. The selected menu branch is displayed (flashing).


Select the menu branch by pressing the ENT key. The first parameter or the first function in the selected menu branch will be displayed.

If you press the ESC key you will return to the main menu of the control unit.

Buttons	
▲ ▼	Navigate through the menu structure and select a menu branch
ENT	Open the selected menu branch
ESC	Quitting the menu branch and return to the main menu.

8.3 Actual Value Menu (VAL)


In the VAL menu branch, the control unit displays a variety of actual values, depending on the configuration selected and the options installed. The parameters and basic software functions linked to the corresponding actual value are documented in the operating instructions.



- A** Use the arrow keys to select the required number from the actual values displayed in numerical order.
- When you have reached the highest parameter number, the smallest parameter number is displayed once you press the ▲ button.
- When you have reached the smallest parameter number, the highest parameter number is displayed once you press the ▼.
- In the current data set, the data set related actual value parameters are displayed, including the corresponding data set number. The seven-segment display shows data record 0 if the actual values in the four data sets are identical.
- | Buttons | |
|---------|---|
| ▲ + ▼ | Display the actual value parameter upon startup. |
| FUN , ▲ | Display last actual value parameter (highest number). |
| FUN , ▼ | Display first actual value parameter (lowest number). |
- B** Use the ENT key to select the actual value. The parameter is displayed including its current value, unit and the active data set.
- C** During commissioning, operation and error analysis, it is possible to monitor each actual value parameter specifically.
- Some of the actual value parameters are arranged in the four available data sets. If the parameter values in the four data records are identical, the actual value is displayed in data record 0. If the actual values in the four data set are different, diFF is displayed in data set 0.
- | Buttons | |
|-----------|---|
| ▲ , ▼ | Switch to another of the data set in the case of related actual values. |
| FUN , ▲ | Determine minimum value and display it permanently. |
| FUN , ▼ | Determine and display minimum actual value permanently. |
| FUN , ENT | Display of mean value of the actual value during the monitoring period. |
- D** Use the ENT key to save the selected actual value as a parameter displayed at switch-on. The message SEt (with parameter number) is displayed for a short time. When the frequency inverter is switched on the next time, this actual value will be displayed automatically.
- E** After saving the parameter, you can monitor and display the value again. Use the ESC key to switch to the parameter selection of the VAL menu branch.

8.4 Parameter Menu (PARA)

The parameters to be configured during the guided commissioning procedure were selected from common applications and can be supplemented as required by further settings in the PARA menu branch. The parameters and basic software functions linked to the corresponding actual value are documented in the operating instructions.



A	<p>Use the arrow keys to select the required number from the parameters displayed in numerical order. The parameter number is displayed with the active data set (flashes).</p> <p>When you have reached the highest parameter number, the smallest parameter number is displayed once you press the ▲ button.</p> <p>When you have reached the smallest parameter number, the highest parameter number is displayed once you press the ▼.</p> <p>In the case of parameter numbers > 999, the first digit will be displayed in hexadecimal form (999, A00 ... B5 ... C66).</p> <p>In the current data set, the related parameters are displayed, including the corresponding data set number. The seven-segment display shows data set 0 if the parameter values in the four data sets are identical.</p> <table border="1" data-bbox="252 1064 1402 1205"> <thead> <tr> <th colspan="2">Buttons</th></tr> </thead> <tbody> <tr> <td>▲ + ▼</td><td>Change to the last parameter edited.</td></tr> <tr> <td>FUN , ▲</td><td>Display of last parameter (highest number).</td></tr> <tr> <td>FUN , ▼</td><td>Display of first parameter (lowest number).</td></tr> </tbody> </table>	Buttons		▲ + ▼	Change to the last parameter edited.	FUN , ▲	Display of last parameter (highest number).	FUN , ▼	Display of first parameter (lowest number).		
Buttons											
▲ + ▼	Change to the last parameter edited.										
FUN , ▲	Display of last parameter (highest number).										
FUN , ▼	Display of first parameter (lowest number).										
B	<p>Use the ENT key to select the parameter. The parameter is displayed including its value, unit and the active data set. If settings are edited in data set 0, the parameter values are changed in the four data sets.</p>										
C	<p>Use the arrow keys to adjust the parameter value or to select an operation mode. The adjustment possibilities you have depend on the parameter.</p> <p>Keep the arrow keys pressed for a while to change the displayed values quickly. If you release the keys again, the speed at which the values change is reduced again.</p> <p>If the parameter value starts to flash, the speed at which the values change is reset to the initial value again.</p> <table border="1" data-bbox="252 1550 1402 1729"> <thead> <tr> <th colspan="2">Buttons</th></tr> </thead> <tbody> <tr> <td>▲ + ▼</td><td>Set parameter to factory setting.</td></tr> <tr> <td>FUN , ▲</td><td>Set parameter to highest value.</td></tr> <tr> <td>FUN , ▼</td><td>Set parameter to smallest value.</td></tr> <tr> <td>FUN , ENT</td><td>Change of the data set in the case of data set related parameters.</td></tr> </tbody> </table>	Buttons		▲ + ▼	Set parameter to factory setting.	FUN , ▲	Set parameter to highest value.	FUN , ▼	Set parameter to smallest value.	FUN , ENT	Change of the data set in the case of data set related parameters.
Buttons											
▲ + ▼	Set parameter to factory setting.										
FUN , ▲	Set parameter to highest value.										
FUN , ▼	Set parameter to smallest value.										
FUN , ENT	Change of the data set in the case of data set related parameters.										
D	<p>Use the ENT key to save the parameter. For a short time, the message SET including the parameter number and the data set is displayed. To leave the parameter unchanged, press the ESC key.</p> <table border="1" data-bbox="252 1848 1402 1989"> <thead> <tr> <th colspan="2">Messages</th></tr> </thead> <tbody> <tr> <td>Err1: EEPrO</td><td>Parameter has not been saved.</td></tr> <tr> <td>Err2: StOP</td><td>Parameter can only be read (i.e. not edited) when the unit is in operation.</td></tr> <tr> <td>Err3: Error</td><td>Other error.</td></tr> </tbody> </table>	Messages		Err1: EEPrO	Parameter has not been saved.	Err2: StOP	Parameter can only be read (i.e. not edited) when the unit is in operation.	Err3: Error	Other error.		
Messages											
Err1: EEPrO	Parameter has not been saved.										
Err2: StOP	Parameter can only be read (i.e. not edited) when the unit is in operation.										
Err3: Error	Other error.										
E	<p>After saving the parameter, you can edit the value again or return to the parameter selection menu by pressing the ESC key.</p>										

8.5 Copy Menu (CPY)

With the copy function of the control unit you can copy parameter values from the frequency inverter to a non-volatile memory of the control unit (upload) and store (download) them to a frequency inverter again.


The copy function makes the parameterization of recurring applications much easier. The function archives all parameter values, regardless of access control and value range. The memory space available in the control unit for the files is dynamically scaled to match the scope of the data.




The Copy Menu (CPY) is accessible in control level 3. The control level can be adjusted, if necessary, via parameter *Control Level* **28**.

8.5.1 Reading the Stored Information

When you open the CPY menu branch, the data stored in the control unit are read out. This process takes a few seconds. During this time, **init** and a progress indicator will be displayed. After the initialization in the copy menu, the function can be selected.




If the information stored in the control unit is not valid, the initialization is stopped and an error message is displayed.




In this case, the memory in the control unit must be formatted as follows:

- Use the ENT key to confirm the error message.
- Use the arrow keys to select the function **FOr**.
- Use the ENT key to confirm the selection.
During the formatting process, **FCOPY** and a progress indicator are displayed.




The process takes a few seconds. When the process is complete, the message **rdY** is displayed.



- Confirm the message by pressing the ENT key.

Now, you can select the copy function as described in the following.




8.5.2 Menu structure

The copy menu CPY contains three main functions. Use the arrow keys to select the required function. Select the source and the destination for the process. The memory space available in the non-volatile memory of the control unit is displayed as a percentage on the three-digit seven-segment display.

Function – FOr


Use the function For to format and delete the memory in the control unit. This may be necessary if a new control unit is used for the first time.



Function – ALL


All readable and writable parameter values are transferred.

- Confirm this selection by pressing the ENT key and continue by selecting the source.



Function – Act

The active parameter values of the frequency inverter are copied to the control unit only. The number of active parameter values depends in the current or selected configuration of the frequency inverter.



When copying the data from the control unit to the frequency inverter, all stored parameter values are transmitted, like in the case of the ALL function.

- For the copy operation, confirm the selection **Act** by pressing the ENT button and selecting the source.

8.5.3 Selecting the Source

The parameters of the ALL and Act sub-function in the CPY menu branch can be parameterized to meet the requirements of the specific application. The available memory space of the control unit is shown on the seven-segment display.

- Use the arrow keys to select the data source (Src.) for the copy operation (upload). The data sets of the frequency inverter (Src. x) or the files of the control unit (Src. Fy) can be used as the data source.
- Confirm the data source selected by pressing the ENT key and continue by selecting the target.

Display	Description
Src. 0	The data of the four data sets of the frequency inverter are copied.
Src. 1	The data of data set 1 of the frequency inverter are copied.
Src. 2	The data of data set 2 of the frequency inverter are copied.
Src. 3	The data of data set 3 of the frequency inverter are copied.
Src. 4	The data of data set 4 of the frequency inverter are copied.
Src. E	An empty data set for deletion of a file in the control unit.
Src. F1	File 1 is transferred from the memory of the control unit. ¹⁾
Src. F2	File 2 is transferred from the memory of the control unit. ¹⁾
Src. F3	File 3 is transferred from the memory of the control unit. ¹⁾
Src. F4	File 4 is transferred from the memory of the control unit. ¹⁾
Src. F5	File 5 is transferred from the memory of the control unit. ¹⁾
Src. F6	File 6 is transferred from the memory of the control unit. ¹⁾
Src. F7	File 7 is transferred from the memory of the control unit. ¹⁾
Src. F8	File 8 is transferred from the memory of the control unit. ¹⁾

¹⁾ Empty files not yet filled with data will not be offered as signal source. The memory of the control unit is managed dynamically (Chapter 8.5 "Copy Menu (CPY)").

8.5.4 Selecting the Destination

Select the destination (dSt.) of the copy operation (application-specific). The data source is transferred to the selected target (download).

- Use the arrow keys to select the destination (dSt.) of the copied data (download). Depending on the data source selected, either the data sets of the frequency inverter (dSt. x) or still empty files of the control unit (dSt. F y) are available as the target.
- Confirm your selection by pressing the ENT key. The copy operation will start and **COPY** will be displayed.

Display	Description
dSt. 0	The four data sets of the frequency inverter are overwritten.
dSt. 1	The data are copied to data set 1 of the frequency inverter.
dSt. 2	The data are copied to data set 2 of the frequency inverter.
dSt. 3	The data are copied to data set 3 of the frequency inverter.

Display	Description
dSt. 4	The data are copied to data set 4 of the frequency inverter.
dSt. F1	The data are copied to file 1 of the control unit. ¹⁾
dSt. F2	The data are copied to file 2 of the control unit. ¹⁾
dSt. F3	The data are copied to file 3 of the control unit. ¹⁾
dSt. F4	The data are copied to file 4 of the control unit. ¹⁾
dSt. F5	The data are copied to file 5 of the control unit. ¹⁾
dSt. F6	The data are copied to file 6 of the control unit. ¹⁾
dSt. F7	The data are copied to file 7 of the control unit. ¹⁾
dSt. F8	The data are copied to file 8 of the control unit. ¹⁾

¹⁾ Already existing files will not be offered as copy target.

8.5.5 Copy Operation




Before the parameter settings are transferred to the frequency inverter, the individual parameter values are checked.

The value range and the parameter settings can differ according to the power range of the frequency inverter. Parameter values which are outside of the value range will trigger a copy error message. In case a device error is triggered as a result of copying, the device error will only be displayed once the copying has been completed.


While the copy operation is in process, the message **COPY** and, as a progress indicator, the number of the currently copied parameter will be displayed

In the case of the Act function, the active parameter values are copied only. Using the ALL function, parameters which are not relevant to the selected configuration are copied, too.




Depending on the configuration selected (ALL or Act), the copy operation will be completed after approx. 100 seconds and the message **rdY** will be displayed.

Press the ENT key to switch to the copy menu. Use the ESC key to switch to the target selection menu.




If the ESC key is pressed during the copy operation, the copy operation is aborted before the transmission of the data is complete. The message **Abr** and the number of the last parameter which was copied are displayed.

Press the ENT key to return to the selection in the copy menu. Use the ESC key to switch to the target selection menu.




8.5.6 Error messages

The copy function archives all parameters, regardless of the access control and the value range. Some of the parameters are only writable if the frequency inverter is not in operation. The controller enable input (S1IND, S7IND) may not be activated during the copy operation, otherwise the data transmission is aborted. The message **StO** and the number of the last parameter which was copied are displayed. If the controller enable input is deactivated again, the aborted copy operation is continued.



The data transmission from the selected source to the destination is continuously monitored by the copy function. If an error occurs, the copy operation is aborted and the message **Err** and an error code are displayed.



Error messages		
Key		Meaning
0	1	Write error in memory of control unit; repeat the copy operation. If error message is displayed again, format the memory.
	2	Read error in memory of control unit; repeat the copy operation. If error message is displayed again, format the memory.
	3	The size of the memory of the control unit was not determined correctly. If this error occurs repeatedly, replace the control unit.
	4	Not enough memory; the data are incomplete. Delete the incomplete file and data no longer needed from the control unit.
	5	The communication has been disturbed or interrupted; repeat the copy function, delete the incomplete file if necessary.
1	0	Invalid identification of a file in the operating unit; delete faulty file and format memory if necessary.
	2	The memory space of the selected target file is occupied; delete file or use different target file in the operating unit.
	3	The source file to be read in the control unit is empty; only files containing reasonable data should be selected as a source.
	4	Defective file in the control unit; delete defective file and format memory if necessary.
2	0	The memory in the control unit is not formatted; format the memory via the FOr function in the copy menu.
3	0	Error during reading of a parameter from the frequency inverter; check connection between the control unit and the frequency inverter and repeat reading operation.
	1	Error during writing of a parameter in the frequency inverter; Check connection between the control unit and the frequency inverter and repeat the writing operation.
	2	Unknown parameter type; delete faulty file and format memory if necessary.
4	0	The communication has been disturbed or interrupted; repeat the copy function, delete the incomplete file if necessary.

8.6 Reading Data From Control Unit

„Parameter transmission“ enables the transmission of parameter values from the control unit KP 500 to the frequency inverter. In this operation mode, all other functions of the control unit are disabled, except for the COPY function. Transmission from the frequency inverter to the control unit is also disabled.

Activation of the control unit KP 500 for parameter transfer is prepared via parameter *Program 34*. The control unit KP 500 must be connected to the frequency inverter.

Program 34	Function
111 - Parameter transmission	Control unit P 500 is prepared for parameter transmission. A connected frequency inverter can receive data from the control unit.
110 - Standard operation	Resetting of control unit KP 500 to standard operation mode.



Parameter transmission mode can be activated on the control unit KP 500 only if at least 1 file is stored in the control unit. Otherwise, the error message **FOA10** will be displayed as soon as activation is attempted.

8.6.1 Activation

The control unit KP 500 can be configured both via the keys of the KP 500 and via any available CM communication module. For configuration and activation of the KP 500 control unit, proceed as follows:

Activation via keyboard of control unit

- In the parameter menu PARA, use the arrow keys to select *parameter Program 34*, and confirm your selection by pressing the ENT key.
- Use the arrow keys to set value **111** – Parameter transmission and confirm your selection by pressing the ENT key.
Now the control unit is ready for activation.

Before data transmission, the control unit must be initialized:

- Unplug the control unit from the frequency inverter and connect again to the same or another frequency inverter.
The initialization is started. During the time of initialization, **init** and a progress indicator are displayed. After initialization, the control unit KP°500 is ready for transfer of data to the frequency inverter.



Adjustment of parameter *Program 34* to value **111** – Parameter transmission, can be undone via the control unit, provided that the control unit has not been initialized yet.

In Parameter *Program 34* use the arrow keys to set the value **110** – Normal operation again and confirm by pressing the ENT key.

Activation via communication module CM



Activation of the control unit through a communication connection is possible only if the frequency inverter is fitted with an optional communication module CM, and communication takes place via this module. The control unit must be connected to the frequency inverter.

- Establish connection to frequency inverter.
- Start communication and select parameter *Program 34* via the communication interface.
- Via the communication interface, enter value 111 in parameter *Program 34* and confirm this value.
- Via the communication interface in parameter *Program 34*, enter 123 and confirm this value.
The frequency inverter is re-initialized. The display of the control unit reads **rESet**. After that, the unit is initialized.

8.6.2 Data transfer

In order to transmit a file from the control unit to the frequency inverter, proceed as follows:

- Connect control unit KP 500 to the frequency inverter.
After initialization, the data sources available for transmission are displayed.
- Use the arrow keys to select the data source (Src. Fy) for the transmission to the frequency inverter.
The files stored in the control unit are available as data sources.



The files stored in the control unit contain all information and parameters stored according to the selected copy function ALL or Act (see Chapter 8.5 "Copy Menu (CPY)") in the control unit.

- Confirm your selection by pressing the ENT key.
The copy process is started. While the copy operation is in process, **COPY** and, as a progress indicator, the number of the currently copied parameter will be displayed.
As soon as the copy operation is complete, the control unit will be re-initialized.

8.6.3 Resetting to Normal Operation

A control unit KP500 activated for parameter transmission can be reset to full functionality (standard operation) via a specific key code on the control unit or via each available communication module CM.

Resetting on control unit

- Press RUN and STOP keys on control unit simultaneously for approx. 1 second.
When the process is complete, – – – – – is displayed briefly. Then the top menu level of the control unit is available.
- In the parameter menu PARA, use the arrow keys to select parameter *Program 34*, and confirm your selection by pressing the ENT key.
- Use the arrow keys to set value **110** – Normal operation and confirm your selection by pressing the ENT key.
The control unit is set to normal operation.

Resetting via communication module CM and/or using control software VPlus



Resetting of the control unit through a communication connection is possible only if the frequency inverter is fitted with an optional communication module CM, and communication takes place via this module.

- Establish connection to frequency inverter.
- Start communication and select parameter *Program 34* via the communication connection.
- Via the communication connection, enter value 110 in parameter *Program 34* and confirm this value.
- Via the communication connection enter value 123 in parameter *Program 34* and confirm this value by pressing Enter.
The frequency inverter is reset. The display of the control unit reads **rESet**.
After resetting, the control unit is available again with full functionality.

8.7 Control Menu (CTRL)



In order to be able to control the drive via the control unit, the digital inputs S1IND/STOA and S7IND/STOB must be connected for enabling the output.



⚠ CAUTION

The unit may only be connected with the power supply switched off.

Verify safe isolation from power supply.

Switch off power supply before connecting or disconnecting the control inputs and outputs. Otherwise, components may be damaged.

In the CTRL menu branch, various functions are available which make commissioning easier and enable the control of the inverter via the control unit.

The frequency inverters can be controlled by means of the control unit and/or a communication module.

If you want to control the frequency inverter via an optional communication module, the necessary adjustments can be made via parameter *Local/Remote 412*. Via this parameter, you can specify which functions will be available to the controller. Depending on the operation mode selected, only some of the control menu functions are available. Refer to chapter 19.3 "Bus controller" for a detailed description of parameter *Local/Remote 412*.

8.8 Controlling the Motor via the Control Unit

The operating unit enables control of the connected motor in accordance with the selected operating mode of the parameter *Local/Remote* **412**.



In order to be able to control the drive via the control unit, the digital inputs S1IND/STOA (STOA/terminal X210A.3) and S7IND/STOB (STOB/terminal X210B.2) must be connected for enabling the output. These are the inputs for the shut-down paths of the ST= safety function "Safe Torque Off".


CAUTION



The unit may only be connected with the power supply switched off.


Verify safe isolation from power supply.

Switch off power supply before connecting or disconnecting the control inputs and outputs. Otherwise, components may be damaged.




UU: When the RUN key was pressed, the drive was in operation already.


The CTRL menu branch can be accessed via the navigation within the menu structure. The Ctrl function contains sub-functions which are displayed according to the operating point of the frequency inverter.




Pressing the RUN key leads to a direct change from anywhere within the menu structure to the motorpoti function **PotF** for clockwise rotation or **Potr** for anticlockwise rotation.



If the drive is already running, the display reads **intF** (forward, clockwise) / **intr** (backward, anticlockwise) for the internal reference value function or **inPF** (forward, clockwise) / **inPr** (backward, anticlockwise) for the "Motorpoti (KP)" function.




The function „Motorpoti (KP)“ enables linking to other reference sources in the reference frequency channel. The function is described in Chapter 15.10.2 "Motorpoti (KP)".




Motor potentiometer function **Pot**

Using the arrow keys, you can adjust the output frequency of the frequency inverter from the *Minimum Frequency* **418** to the *Maximum Frequency* **419**. The acceleration corresponds to the factory settings (2 Hz/s) for parameter *Ramp Keypad-Motorpoti* **473**. Parameters *Acceleration (Clockwise)* **420** and *Deceleration (Clockwise)* **421** are considered in the case of low acceleration values.




Internal reference value **int**

The drive is in operation, i.e. output signals are present at the frequency inverter and the current actual value is displayed. Press an arrow key to switch to the motor potentiometer function **Pot**. The current frequency value is taken over in the motor potentiometer function **Pot**.




Function Motorpoti (KP) **inP**

Using the arrow keys, you can adjust the output frequency from *Minimum Frequency* **418** to *Maximum Frequency* **419**. The frequency value adjusted via the control unit can be linked to other reference values via the *Reference Frequency Source* **475** (Chapter 15.4 "Frequency reference channel" and 15.10.2 "Motorpoti (KP)").



JOG-Frequency **JOG**

This function is useful for manual setup and positioning of a machine. The frequency of the output signal is set to the entered value if the FUN key is pressed.



- Press FUN key to switch from the internal reference value **int** or the motor potentiometer function Pot to parameter *JOG-Frequency* **489**.
- While keeping the FUN key pressed, press the arrow keys to adjust the required frequency.
(The last frequency value set will be saved in parameter *JOG-Frequency* **489**.)
- Release the FUN key to stop the drive.
(The display returns to the previous function **Pot** or **int**. or **inP** if function "Motorpoti (KP)" is activated).

Key functions

ENT	Reversal of the sense of rotation independent of the control signal on the terminals Clockwise S2IND or Anticlockwise S3IND.
ESC	Cancel function and return to the menu structure.
FUN	Switch from internal reference value int or motor potentiometer function Pot to JOG-Frequency; the drive will start. Release the key to switch to the sub-function and stop the drive.
RUN	Start drive; alternative to control signal S2IND or S3IND.
STOP	Stop drive; alternative to control signal S2IND or S3IND.



CAUTION

If you press the ENT key, the **Sense of Rotation** is changed independent of the signal on the terminals Clockwise S2IND or Anticlockwise S3IND.

If the *Minimum Frequency* **418** is set to 0.00 Hz, the **sense of rotation** of the motor changes as soon as the sign of the reference frequency value changes.

9 Commissioning of frequency inverter

NOTICE

If filters (e.g. dU/dt filters or sine filters) are used between the frequency inverter and machine, the following must be noted.

For configurations with sensor feedback (2xx, 5xx):

- Carry out the installation with the filter connected. Note the filter manufacturer's specifications concerning permissible switching frequencies. During setup note that the filter may be overloaded thermally.

For configurations without sensor feedback (1xx, 4xx, 6xx):

- Carry out the installation without connected filters. After setup, connect the filters between the frequency inverter and the motor.

NOTICE

In liquid-cooled devices:

- Vent the cooling circuit.
- Initiate the cooling circuit.

See instructions in the "Operating Instructions Liquid Cooling Supplemental" document.

9.1 Turn mains voltage on

After completion of the installation work, make sure to check all control and power connections again before switching on the mains voltage. When all electrical connections are correct, make sure that the frequency inverter is not enabled (control inputs S1IND/STOA and S7IND/STOB open). After power-up, the frequency inverter carries out a self-test and the relay output (X10) reports "Fault".

After a few seconds, the frequency inverter self-test is complete, the relay (X10) picks up and signals "no fault".

If the unit is in "as-delivered" condition or after resetting the unit to the factory settings, the guided commissioning procedure is started automatically. On the control unit, the "SetUP" menu from the menu branch CTRL is displayed.

9.2 Setup Using the Control Unit

The guided commissioning of the frequency inverter determines all parameter settings relevant to the required application. The available parameters were selected based on known standard drive applications. This facilitates the selection of the important parameters. After successful completion of the SETUP routine, the actual value *Actual Frequency* **241** from the VAL menu branch is displayed on the control unit. Now, the user should check whether further parameters are relevant for the application.



The guided commissioning contains the function for parameter identification. The parameters are determined by way of measurement and set accordingly. Guided commissioning must be carried out when the machine is cold, since a part of the machine data depends on the operating temperature.

WARNING



For control of a synchronous machine and setting parameter *Configuration 30* to "510 - FOC Syn. Speed Controlled", you will have to cancel the guided commissioning first by pressing the ESC key after the "SETUP" message and set parameter *Offset 382*. To do this, proceed according to the operating instructions for the extension module EM-RES or EM-ABS-01 installed. Otherwise, personal or machine damage may occur.

When the unit is in "as-delivered" condition, the guided commissioning procedure is started automatically. After successful commissioning, the guided commissioning can be carried out again later via the sub-menu CTRL.

Use the ENT key to switch to the CTRL sub-menu.

In the CTRL sub-menu, select the menu item "SetUP" and confirm by pressing the ENT key.

Use the ENT button to select parameter *Configuration 30*.

The available configurations are displayed automatically depending on the selected *Control Level 28*.

Use the arrow keys to enter the number of the required configuration. (for a description of the configurations, refer to the following chapter)


If the setup was changed, the hardware and software functionality will be configured. The message "SETUP" is displayed again.

Confirm this message by pressing the ENT key in order to continue the commissioning procedure.

Switch to the next parameter.

After initialization, confirm the selected configuration by pressing the ENT key.


Continue the guided commissioning procedure according to the following chapters.



9.2.1 Configuration


Configuration 30 determines the assignment and basic function of the control inputs and outputs as well as the software functions. The software of the frequency inverter offers several configuration options. These differ with respect to the way in which the drive is controlled. Analog and digital inputs can be combined and complemented by optional communication protocols as further reference value sources. The Operating Instructions describe the configurations and relevant parameters on the third *Control Level 28* (Set parameter *Control Level 28* to value 3). Please also comply with the following manuals:

Manual	Configuration
Application Manual – Electronic Gear	(x15, x16)
Application Manual: Positioning	(x40)
Application Manual – Hoisting Gear Drives	(x60)




Configuration 110, sensor-less control (SLC)

Configuration 110 contains the functions for variable-speed control of a 3-phase machine in a wide range of standard applications. The motor speed is set according to the V/f characteristic in accordance with the voltage/frequency ratio.




Configuration 111, SLC w. Technology Contr.

Configuration 111 extends the functionality of the sensorless control by software functions for easier adaptation to the customer's requirements in different applications. The Technology Controller enables flow rate, pressure, level or speed control.




Configuration 410, sensorless field-oriented control

Configuration 410 contains functions for sensorless, field-oriented control of a 3-phase machine. The current motor speed is determined from the present currents and voltages in combination with the machine parameters. In this configuration, parallel connection of several 3-phase motors is possible to a limited extent only.




Configuration 411, DMR w. Technology Contr

Configuration 411 extends the functionality of Configuration 410 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.




Configuration 430, DMR N or M Controlled

Configuration 430 extends the functionality of Configuration 410 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Configuration 210, FOC Speed Controlled

Configuration 210 contains the functions for speed-controlled, field-oriented control of a 3-phase machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.




Configuration 211, FOC w. Technology Contr.

Configuration 211 extends the functionality of Configuration 210 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.




Configuration 230, FOC N or M Controlled

Configuration 230 extends the functionality of Configuration 210 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.




Configuration 510, FOC Syn. Speed Controlled

Configuration 510 contains the functions for speed-controlled, field-oriented control of a synchronous machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.



Configuration 511, FOC Syn. Speed Controlled w. Technology Contr.

Configuration 511 extends the functionality of Configuration 510 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



Configuration 530, FOC Syn.

N or M Controlled

Configuration 530 extends the functionality of Configuration 510 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Configuration 610, DMR for PMSM

Configuration 610 contains the functions for sensorless field-oriented control of a synchronous machine with resolver feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The missing resolver feedback results in slightly lower dynamism and speed quality compared to Configuration 510.



Configuration 611, DMR PMSM w. Technology Contr.

611,


Configuration 611 extends the functionality of Configuration 610 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



Configuration 630 – DMR PMSM N or M Controlled

Configuration 630 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Torque Controller. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

9.2.2 Data Set




The data set change-over function enables the selection of one of four data sets for storing parameter settings.

If data set 0 is selected (factory setting), the parameter values saved in data set 0 are copied to data sets 1 through 4. In this way, all values determined during the guided commissioning procedure are saved in all data sets. In the factory settings, the frequency inverter uses data set 1 as the active data set. (For information on data set change-over via logic signals, refer to the chapter 16.4.7 "Switch data set") For example, if data set 2 is selected for guided commissioning ("SETUP"), all values which were determined or entered are saved in this data set. The other data sets will still contain the default values. For the operation of the frequency inverter, data set 2 must be selected as the active data set in this case.

Data Set Setup	
dS	Function
0	All data sets (DS0)
1	Data set 1 (DS1)
2	Data set 2 (DS2)
3	Data set 3 (DS3)
4	Data set 4 (DS4)

9.2.3 Motor Type



The properties of the control functions and methods to be set vary depending on the motor which is connected. Parameter *Motor Type* **369** offers a range of motor variants with the corresponding values. The verification of the entered rated values and the guided commissioning are carried out on the basis of the parameterized motor type. The selection of motor types varies according to the applications of the different control methods. In operating instructions the functionality and operating performance are described for 3-phase motors.

Motor Type 369	Function
0 - Unknown	The motor is not a standard type.
1 - Asynchronous	Three-phase asynchronous motor, squirrel cage
2 - Synchronous	Three-phase synchronous motor
3 - Reluctance	Three-phase reluctance motor
10 - Transformer ¹⁾	Transformer with three primary windings.

¹⁾ No parameter identification is performed for setting Parameter *Motor Type* **369** to Operation Mode "10 - Transformer".


NOTICE

Query and setting of parameter values depends on the operation mode selected for parameter *Motor Type* **369**.

If the motor type is not entered correctly, the drive may be damaged.

When the motor type is specified, the machine data must be entered. This is described in the following chapter. The data is queried in accordance with the table in this chapter.

9.2.4 Machine data



The machine data to be entered during the guided commissioning procedure are indicated on the type plate or the data sheet of the motor. The factory settings of the machine parameters are based on the nominal data of the frequency inverter and the corresponding four-pole three-phase motor. The entered and calculated machine data are checked for plausibility during the guided commissioning procedure. The user should verify the factory-set rated data of the three-phase motor.

U_{FIN} , I_{FIN} , P_{FIN} are rated values of the frequency inverter.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
370	Rated Voltage	$0.17 \cdot U_{FIN}$	$2 \cdot U_{FIN}$	U_{FIN}
371	Rated Current	$0.01 \cdot I_{FIN}$	$10 \cdot I_{FIN}$	I_{FIN}
372	Rated Speed	96 min^{-1}	$60\,000 \text{ min}^{-1}$	n_N
374	Rated Cosinus Phi	0.01	1.00	$\cos(\varphi)_N$
375	Rated Frequency	10.00 Hz	599.00 Hz	50.00
376	Rated Mech. Power	$0.01 \cdot P_{FIN}$	$10 \cdot P_{FIN}$	P_{FIN}

Use the arrow keys to select the required parameter and edit the parameter value.

Use the ENT key to confirm the selected parameter and the parameter values entered.




The rated data of the motor are to be entered according to the specifications on the rating plate for the motor connection type used (star or delta connection). If the data entered deviate from the rating plate, the parameters will not be identified correctly. Parameterize the rated data according to the rating plate of the motor for the wiring of the motor winding. Consider the increased rated current of the connected three-phase motor.

Example: BONFIGLIOLI BN 90LA Motor

	Parameter	Star	Delta
370	Rated Voltage	400 V	230 V
371	Rated Current	3.7 A	6.4 A
372	Rated Speed	1410 min ⁻¹	1410 min ⁻¹
374	Rated Cosinus Phi	0.77	0.77
375	Rated Frequency	50 Hz	50 Hz
376	Rated Mech. Power	1.5 kW	1.5 kW

9.2.5 Plausibility check



After the machine data (and the speed sensor data, if applicable) have been entered, the calculation or examination of the parameters is started automatically. The display changes over to "CALC" for a short time. If the verification of the machine data is successful, the guided commissioning procedure continues with the identification of the parameters.

Verification of the machine data should only be skipped by experienced users. The configurations contain complex control processes which depend to a large degree on the correctness of the machine parameters entered.


The warning and error messages displayed during the verification process have to be observed. If a critical condition is detected during the guided commissioning, it is displayed by the control unit. Depending on the deviation from the expected parameter value, either a warning or an error message is displayed.

To ignore the warning or error messages, press the ENT key. The guided commissioning is continued. However, it is recommended that the data be checked and corrected if necessary.

To correct the entered parameter values after the warning or error message, press the ESC key. Use the arrow keys to switch to the parameter value which is to be corrected.

If an error message is displayed, the rated values must be checked and corrected. The guided commissioning procedure is the rated values have been entered correctly. Aborting the guided commissioning procedure by pressing ESC key should only be done by expert users because it may be possible that rated values have not been entered or determined correctly.

9.2.6 Parameter identification



In addition to the parameterized rated data, the selected configuration demands knowledge of further machine data not stated on the rating plate of the three-phase machine. In addition to entering the rated motor parameters or as an alternative, the required machine data can also be measured during the guided commissioning process. The machine data are measured while the drive is at a standstill. The measured values are entered in the parameter automatically either directly or after the calculation. The procedure and the duration of the parameter identification depend on the type of machine connected and the device.


After checking the machine data entered, the guided commissioning switches to the parameter identification.

Confirm the display "PAidE" by pressing the ENT key.

During the parameter identification, the connected load is measured.



No parameter identification is performed for setting Parameter *Motor Type* **369** of Operation Mode "10 - Transformer".



The safety functions of the frequency inverter avoid enabling of the power unit if no signal is present at digital input S1IND/STOA (terminal X210A.3) and S7IND/STOB (terminal X210B.2). If signals were already applied at the beginning of the guided commissioning, the "StO" message is not displayed.



In order to be able to control the drive via the control unit, the digital inputs S1IND/STOA (terminal X210A.3) and S7IND/STOB (terminal X210B.2) must be connected for enabling the output.



WARNING

The electrical installation must be carried out by qualified electricians according to the general and regional safety and installation directives.

The documentation and device specification must be complied with during installation.

Before any assembly or connection work, discharge the frequency inverter. Verify safe isolation from power supply.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time. Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 1 through 7.

Do not connect inappropriate voltage sources. The nominal voltage of the frequency inverter must correspond to the supply voltage.

The frequency inverter must be connected to ground potential.

Do not remove any covers of the frequency inverter while power supply is on.



Confirm the final "rEAdY" message by pressing the ENT key.

Canceling the operation with the ESC key or withdrawing the enable signal S1IND/STOA or S7IND/STOP results in an incomplete take-over of the values.



Guided commissioning must be carried out when the machine is cold, since a part of the machine data depends on the operating temperature.

After completion of the parameter identification, warning messages may be displayed. Depending on the warning message code, the following instructions should be followed and the measures indicated should be taken.

9.2.7 Status messages during commissioning (SS...)

The following status messages are possible when Setup is run:

Status message		Meaning
SS000	OK	Auto set-up routine has been carried out.
SS001	PC Phase 1	The plausibility check (PC) of the motor data is active.
SS002	PC Phase 2	The calculation of dependent parameters is active.
SS003	STO	The parameter identification requires release on digital input STOA and STOB.
SS004	Parameter Identification	The rated motor values are checked by the parameter identification feature.
SS010	Setup already active	The setup routine via the control panel is being carried out.
SS030	No Release	The parameter identification demands the controller release on digital input STOA and STOB.
SS031	Error – check P. 259	Error during the auto set-up routine. Check value of <i>Current Error</i> 259 .
SS032	Warning Phase Asymmetry	The parameter identification feature diagnosed an unbalance during the measurements in the three motor phases.
SS099	Setup not carried out yet.	Self-setup has not yet been carried out.

9.2.8 Warnings during commissioning (SA...)

Warning messages	
Code	Measures / Remedy
SA000	No warning message present. This message can be read out via an optional communication board.
SA001	The value of the parameter <i>Rated Voltage</i> 370 is out of the rated voltage range of the frequency inverter. The maximum reference voltage is indicated on the nameplate of the frequency inverter.
SA002	For a three-phase motor, the calculated efficiency is in the limit range. Check the values entered for parameters <i>Rated Voltage</i> 370 , <i>Rated Current</i> 371 and <i>Rated Mech. Power</i> 376 .
SA003	The value entered for parameter <i>Rated Cosinus Phi</i> 374 is outside of normal range (0.6 to 0.95). Check the value.
SA004	For three-phase motor, the calculated slip is in the limit range. Check the values for parameters <i>Rated Speed</i> 372 and <i>Rated Frequency</i> 375 .
SA011	Current Controller non typical value; also see Chapter 18.5.1.
SA012	Current Controller non typical value with 2kHz; also see Chapter 18.5.1.
SA014	Current Controller non typical value with 4 kHz; also see Chapter 18.5.1.
SA018	Current Controller non typical value with 8 kHz; also see Chapter 18.5.1.
SA021	Stator Resistance very high. The following causes are possible: <ul style="list-style-type: none"> – The motor cable cross-section is not sufficient. – The motor cable is too long. – The motor cable is not connected correctly. – The contacts are not in a proper condition (corrosion).
SA022	Rotor Resistance very high. The following causes are possible: <ul style="list-style-type: none"> – The motor cable cross-section is not sufficient. – The motor cable is too long. – The motor cable is not connected correctly. – The contacts are not in a proper condition (corrosion).

SA031	Shorten Motor Line using Switchfrequ. 16 kHz.
SA032	Shorten Motor Line using Switchfrequ. 12 kHz and higher.
SA033	Shorten Motor Line using Switchfrequ. 8 kHz and higher.
SA041	The slip speed was not determined correctly. Check the values for parameters Rated Speed 372 and Rated Frequency 375 .
SA042	The slip speed was not determined correctly. Check the values for parameters Rated Speed 372 and Rated Frequency 375 .
SA051	The machine data for star connection were entered, the motor, however, is connected in delta. For star operation, change the motor cable connection. For delta operation, check the entered rated motor values. Repeat the parameter identification
SA052	The machine data for delta connection were entered, the motor, however, is connected in star. For delta operation, change the motor cable connection. For star operation, check the entered rated motor values. Repeat the parameter identification
SA053	A phase asymmetry was measured. Check the cables at the terminals of the motor and the frequency inverter for proper connection and check the contacts for corrosion.
SA054	Resolver offset not adjusted.

9.2.9 Error messages during commissioning (SF...)

After completion or during the parameter identification, error messages may be displayed. Depending on the error code, the following instructions should be followed and the measures indicated should be taken.

Error messages	
Code	Measures / Remedy
SF000	No Error
SF001	The value entered for parameter <i>Rated Current</i> 371 is too low. Correct the value.
SF002	The value for parameter <i>Rated Current</i> 371 is too high, referred to parameters <i>Rated Mech. Power</i> 376 and <i>Rated Voltage</i> 370 . Correct the values.
SF003	The value entered for parameter
SF004	The calculated slip frequency is negative. Check and, if necessary, correct the values for parameters <i>Rated Speed</i> 372 and <i>Rated Frequency</i> 375 .
SF005	The calculated slip frequency is too high. Check and, if necessary, correct the values for parameters <i>Rated Speed</i> 372 and <i>Rated Frequency</i> 375 .
SF006	The calculated total output of the drive is lower than the rated power. Check and, if necessary, correct the value entered for parameter <i>Rated Mech. Power</i> 376 .
SF007	The set configuration is not supported by the auto set-up routine.
SF011	The main inductance measurement has failed because the motor has a high slip. Correct the rated motor values in parameters 370, 371, 372, 374, 375 and 376 . Carry out the guided commissioning once again. In case an error message is displayed again, enter value 110 for <i>parameter Configuration</i> 30 (sensor-less control (SLC) according to V/f characteristic) if value 410 was set so far. Carry out the guided commissioning once again.
SF012	The leakage inductance measurement has failed because the motor has a high slip. Correct the rated motor values in parameters 370, 371, 372, 374, 375 and 376 . Carry out the guided commissioning once again. In case an error message is displayed again, enter value 110 for <i>parameter Configuration</i> 30 (sensor-less control (SLC) according to V/f characteristic) if value 410 was set so far. Carry out the guided commissioning once again.
SF021	The measurement of the stator resistance did not deliver a plausible value. Check the cables at the terminals of the motor and the frequency inverter for proper connection and check the contacts for corrosion and safe contact. Repeat the parameter identification
SF022	The measurement of the rotor resistance did not deliver a plausible value. Check the cables at the terminals of the motor and the frequency inverter for proper connection and check the contacts for corrosion and safe contact. Repeat the parameter identification
SF026	Setup aborted

9.2.10 Application data

Other parameters must be checked due to the great variety of drive applications and the resulting parameter settings. The parameters queried during the guided commissioning procedure were selected from standard applications. After completion of commissioning, further parameters can be set in the PARA menu branch.



In the KP500 control unit, parameter numbers > 999 are shown in hexadecimal form (999, A00 ... B5 ... C66).

9.2.10.1 Acceleration and deceleration

The settings define how fast the output frequency changes after a reference value change or a start, stop or brake command.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
420	Acceleration (Clockwise)	0.00 Hz/s	9999.99 Hz/s	5.00 Hz/s
421	Deceleration (Clockwise)	0.00 Hz/s	9999.99 Hz/s	5.00 Hz/s

NOTICE

The deceleration of the drive is monitored in the default parameter *Operation Mode Voltage Controller* **670**. The deceleration ramp can be extended in the case of an increase in the DC link voltage during regenerative operation and/or during the braking process.

9.2.10.2 Set points at multifunction input


Multifunction input MFI1 can be parameterized for a reference value signal in *Operation Mode* **452**. Operation Mode 3 should only be selected by expert users for drive control via *Fixed Frequency 1* **480** and *Fixed Frequency 2* **481**.

Operation Mode 452	Function
1 - Voltage Input	voltage signal (MFI1A), 0 V ... 10 V
2 - Current Input	current signal (MFI1A), 0 ...20 mA.
3 - Digital input	digital signal (MFI1D), 0 V ... 24 V




Use multifunction input MFI1 as digital input for slow signals. For rapidly and regularly changing signals, use a digital input S2IND...S6IND or a digital input of an extension module EM.

9.2.11 Quitting commissioning



Confirm the "End" display by pressing the ENT key.

The guided commissioning of the frequency inverter is terminated via a reset and the initialization of the frequency inverter. Relay output X10 reports a fault due to default setting *Op. Mode Digital Output 3* **532** = „103 - Inv. Error Signal" (Inv: inverted).



After successful initialization of the frequency inverter, the factory-set parameter *Actual Frequency* **241** is displayed.

The drive is accelerated to the set *Min. Frequency* **418** (default: 3.50 Hz in Configurations 110, 111, 410, 411, 430 or 0.00 Hz in Configurations 210, 211, 230, 510) by:

- signals at digital inputs S1IND/STOA (STOA) and S7IND/STOB (STOB) and
- Start clockwise by rising signal edge at S2IND or Start anticlockwise by rising signal edge at S3IND

Status signals

160 -	Standby Message	¹⁾ Signals that frequency inverter has been initialized and is ready for operation.
-------	-----------------	--

1 -	Ready or Standby Signal	2)	
161 -		1)	Signals that start command has been released and is present (output frequency present).
2 -	Run Message	2)	Signals that start command has been released and is present (output frequency present). Factory setting: Message via digital output S1OUT.
162 -		1)	Monitoring function signals operating error with display in Parameter
3 -	Error Signal	2)	<i>Current Error</i> 259 .

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.

9.2.12 Selection of an actual value for display

After commissioning, the value of parameter *Actual Frequency* **241** is displayed at the control unit KP500.

If another actual value is to be displayed after a restart, make the following settings:

- Use the arrow keys to select the actual value to be displayed as from now.
- Use the ENT key to display the value of the parameter.
- Press the ENT key again. "SEt" is displayed for confirmation.
As from now, the selected actual value is displayed after each restart.

If the parameter settings were made via the optional control software or in the PARA menu branch of the operating unit, the display of the selected actual value must be activated manually. Use the ESC key to switch to the selection of the actual value for display again.

9.3 Check direction of rotation



WARNING

Before any assembly or connection work, discharge the frequency inverter. Verify safe isolation from power supply.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time. Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 1 through 7 .

To check if the reference value and the actual direction of rotation of the drive correspond to one another, proceed as follows:

- Operate the drive at low speed, i. e. specify a reference value of approx. 10%.
- Switch on release of frequency inverter briefly:
Connect digital inputs S1IND/STOA and S7IND/STOB as well as S2IND (Start Clockwise) or digital inputs S1IND/STOA and S7IND/STOB as well as S3IND (Start Anticlockwise) .
- Check if the motor shaft turns in the required direction.
In case the sense of rotation is wrong, exchange two motor phases, e.g. U and V at the terminals of the frequency inverter. The mains-side connection of the frequency inverter does not affect the sense of rotation of the drive. In addition to checking the drive, the corresponding actual values and operating messages can be read out by means of the operating unit.



The commissioning of the frequency inverter is complete and can be complemented by further settings in the PARA menu. The set parameters have been selected in such a way that they are sufficient for commissioning in most applications. The other settings which are relevant to the application can be checked according to the operating instructions.

The power output stage is deactivated by disabling frequency inverter control at S1IND/STOA and S7IND/STOB. The motor will coast to a stop or a brake will be activated, if installed.

9.4 Speed sensor

In some configurations, an incremental speed sensor must be connected. Depending in the type of speed sensor , it is connected to the basic device or an extension module. In some cases, speed sensors are connected to both the basic device and the extension module.



The actual speed source is selected via parameter *Actual Speed Source* **766**. In the default setting, Speed Sensor 1 is used as the source of actual speed. If Speed Sensor 2 of an extension module is to deliver the actual value signal for the speed controller, Speed Sensor 2 must be selected as the source.

Actual Speed Source 766	Function
1 - Speed Sensor 1	The actual speed source is speed sensor 1 of the basic device (factory setting).
2 - Speed Sensor 2	The actual speed source is speed sensor 2 of an extension module. ¹⁾

¹⁾ Only available if extension module is installed

Depending on the application and speed sensors used, the parameter settings must be adjusted according to the following table:

Parameter		Only Speed Sensor 1	Only Speed Sensor 2	Both Speed sensor
490	Operation Mode Speed Sensor 1	> 0	0 - off	> 0
491	Division Marks, Speed Sensor 1	1...8192	X	1...8192
493	Operation Mode Speed Sensor 2	0 - off	> 0	> 0
494	Division Marks, Speed Sensor 2	X	1...8192	1...8192
495	Level	X	Selection	Selection
766	Act. Speed Source	1	2	1 or 2

X Value is not evaluated, any value is possible.

The parameters listed above can be selected depending on the configuration selected and/or if an extension module is available.



Two speed sensors are required in some applications. The *Actual Speed Source* **766** must be set to the motor sensor for motor control. The other speed sensor is used as external sensor. Refer to application manuals "Electronic Gear" and "Positioning".

9.4.1 Speed Sensor 1

The track signals of the speed sensor are to be connected to digital inputs S5IND (track A), S4IND (track B) and S6IND (track Z).

The speed sensor type and evaluation required are set via *Operation Mode* **490** of Speed Sensor 1. For detailed setting options, refer to Chapter 11.4 "11.4".

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
490	Operation Mode Speed Sensor 1	Selection		
491	Division Marks, Speed Sensor 1	1	8192	1024



Depending on *Operation Mode 490* of Speed Sensor 1, digital inputs S4IND, S5IND and S6IND are disabled for other functions. The functions are not evaluated. For the current speed and frequency of Speed Sensor 1, check parameters **217** and **218**.

9.4.2 Speed Sensor 2

Speed sensor 2 is connected to an extension module. Refer to the relevant extension module operating instructions for information on connection, functions and detailed parameter descriptions.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
493	Operation Mode Speed Sensor 2	Selection		
494	Division Marks, Speed Sensor 2	1	8192	1024
495	Level	Selection		

Parameters 493, 494 and 495 can be selected depending on the extension module used.



Depending on *Operation Mode 493* of Speed Sensor 2, certain digital inputs are disabled for other functions. The functions are not evaluated. For the current speed and frequency of Speed Sensor 2, check parameters **219** and **220**.

9.5 Set-up via the Communication Interface

Parameter-setting and commissioning of the frequency inverter via one of the optional communication interfaces include the plausibility check and the parameter identification functions. The parameters can be adjusted by qualified users. The parameter selection during the guided commissioning procedure includes the basic parameters. These are based on standard applications of the corresponding configuration and are therefore useful for commissioning.



WARNING

Parameter settings may only be changed by skilled personnel. Before starting the commissioning process, read the documentation carefully and comply with the safety instructions.

Parameter *SETUP Select 796* defines the function which is carried out directly after the selection (if controller enabling signal is present at digital inputs S1IND and S7IND). The operation modes include functions which are also carried out automatically one after the other during the guided commissioning procedure.

SETUP Select 796	Function
0 - Clear status	The auto set-up routine does not perform a function.
1 - Continue	The warning message is acknowledged and the auto set-up routine is continued.
2 - Abort	The auto set-up routine is stopped and a RESET of the frequency inverter is performed.
10 - Complete Setup, DS0	The auto set-up routine is performed in data set 0 and the parameter values are stored in all of the four data sets identically.
11 - Complete Setup, DS1	The parameter values of the auto set-up are stored in data set 1.
12 - Complete Setup, DS2	The parameter values of the auto set-up are stored in data set 2.
13 - Complete Setup, DS3	The parameter values of the auto set-up are stored in data set 3.

SETUP Select 796	Function
14 - Complete Setup, DS4	The parameter values of the auto set-up are stored in data set 4.
20 - Plaus.-Check Machine Data, DS0	The auto set-up routine checks the rated motor parameters in the four data sets.
21 - Plaus.-Check Machine Data, DS1	The rated motor parameters in data set 1 are checked for plausibility.
22 - Plaus.-Check Machine Data, DS2	The rated motor parameters in data set 2 are checked for plausibility.
23 - Plaus.-Check Machine Data, DS3	The rated motor parameters in data set 3 are checked for plausibility.
24 - Plaus.-Check Machine Data, DS4	The rated motor parameters in data set 4 are checked for plausibility.
30 - Calculation and Para-Ident., DS0	The auto set-up routine determines extended motor data via the parameter identification feature, calculates dependent parameters and stores the parameter values in all of the four data sets identically.
31 - Calc. and Para-Ident., DS1	Further motor data are measured, dependent parameters are calculated and the parameter values are saved in data set 1
32 - Calc. and Para-Ident., DS2	Further motor data are measured, dependent parameters are calculated and the parameter values are saved in data set 2
33 - Calc. and Para-Ident., DS3	Further motor data are measured, dependent parameters are calculated and the parameter values are saved in data set 3
34 - Calc. and Para-Ident., DS4	Further motor data are measured, dependent parameters are calculated and the parameter values are saved in data set 4
40 - Para-Ident., Machine Data only, DS0	Extended motor data are measured and saved identically in all data sets.
41 - Para-Ident., Machine Data only, DS1	Extended motor data are measured and saved data set 1.
42 - Para-Ident., Machine Data only, DS2	Extended motor data are measured and saved data set 2.
43 - Para-Ident., Machine Data only, DS3	Extended motor data are measured and saved data set 3.
44 - Para-Ident., Machine Data only, DS4	Extended motor data are measured and saved data set 4.
110 Complete Setup w/o Para-Ident., DS0	The auto set-up routine is performed in data set 0 and the parameter values are stored in all of the four data sets identically. Extended motor data are not measured.
111 Complete Setup w/o Para-Ident., DS1	The parameter values of the auto set-up are stored in data set 1. Extended motor data are not measured.
112 Complete Setup w/o Para-Ident., DS2	The parameter values of the auto set-up are stored in data set 2. Extended motor data are not measured.
113 Complete Setup w/o Para-Ident., DS3	The parameter values of the auto set-up are stored in data set 3. Extended motor data are not measured.
114 Complete Setup w/o Para-Ident., DS4	The parameter values of the auto set-up are stored in data set 4. Extended motor data are not measured.



In the "Extended motor data" settings, the current controller settings are changed, too.

The individual steps of the auto set-up routine can be monitored and checked via parameter *SETUP Status 797*. The setup routine via the communication interface continuously updates the status parameter which can be read out via the interface.



For auto-setup status messages, refer to

Chapter 9.2.7 "Status messages during commissioning (SS...)"

Chapter 9.2.8 "Warnings during commissioning (SA...)"

Chapter 9.2.9 "Error messages during commissioning (SF...)"

10 Inverter data

The series ACU frequency inverters are suited for a wide range of applications. The modular hardware and software structure enables customer-specific adaptation. The available hardware functionality of the frequency inverter is displayed in the control unit and the optional control software VPlus. The software parameters can be adjusted to meet the requirements of the specific application.

10.1 Serial Number

Serial Number 0: 603409000 ; 06053980 (part no.; serial no.)
Rating plate: Type: ACU 401 – 09 ; Serial No.: 06053980

10.2 Optional Modules

Modular extension of the hardware is possible via the plug-in slots. The *Optional Modules 1* detected by the frequency inverter and the corresponding designations are displayed on the control unit and in the optional control software VPlus after initialization. For the parameters required for the extension module, refer to the corresponding operating instructions.

CM-232 ; EM-IO-01

10.3 Inverter Software Version

The firmware stored in the frequency inverter defines the available parameters and functions of the software. The software version is indicated in parameter *Inverter Software Version 12*. In addition to the version, the 6-digit software key is printed on the rating plate of the frequency inverter.

Inverter Software Version 12 : 5.4.0
Rating plate : Version: 5.4.0 ; Software: 15 000 190
Copyright 15 (C) 2013 BONFIGLIOLI VECTRON

10.4 Set Password

As a protection against unauthorized access, parameter *Set Password 27* can be set such that anyone who wants to change parameters must enter this password before. A change of parameter is only possible if the password is entered correctly. If parameter *Set Password 27* is set to zero, no password is required for access to the parameters. The previous password is deleted.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
27	Set Password	0	999	0

10.5 Control Level

The *Control Level 28* defines the scope of the functions to be parameterized. The operating instructions describe the parameters on the third control level. These parameters should only be set by qualified users.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
28	Control Level	1	3	1

10.6 User Name

The *User Name 29* can be entered via the optional control software VPlus. ???

32 alphanumeric characters

10.7 Configuration

Configuration 30 determines the assignment and basic function of the control inputs and outputs as well as the software functions. The software of the frequency inverters offers various configuration options. These differ with respect to the way in which the drive is controlled. Analog and digital inputs can be combined and complemented by optional communication protocols. The Operating Instructions describe the following configurations and the relevant parameters in the third *Control Level 28* (set parameter *Control Level 28* to value 3).

Configuration 110, sensor-less control (SLC)

Configuration 110 contains the functions for variable-speed control of a 3-phase machine in a wide range of standard applications. The motor speed is set according to the V/f characteristic in accordance with the voltage/frequency ratio.

Configuration 111, SLC w. Technology Contr.

Configuration 111 extends the functionality of the sensorless control by software functions for easier adaptation to the customer's requirements in different applications. Depending on the application, the technology controller may be used, which enables the control of flow rate, pressure, contents level or speed.

Configuration 410, DMR

Configuration 410 contains the functions for sensorless, field-oriented control of an asynchronous machine. The current motor speed is determined from the present currents and voltages in combination with the machine parameters. In this configuration, parallel connection of several 3-phase motors is possible to a limited extent only.

Configuration 411, DMR w. Technology Contr

Configuration 411 extends the functionality of Configuration 410 by a Technology Controller, which enables a control based on parameters such as flow rate, pressure, contents level or speed.

Configuration 430, DMR with speed/torque control

Configuration 430 extends the functionality of Configuration 410 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

Configuration 210, FOC

Configuration 210 contains the functions for speed-controlled, field-oriented control of a 3-phase machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.

Configuration 211, FOC w. Technology Contr.

Configuration 211 extends the functionality of Configuration 210 by a Technology Controller, which enables a control based on parameters such as flow rate, pressure, contents level or speed.

Configuration 230, FOC with speed/torque control

Configuration 230 extends the functionality of Configuration 210 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

Configuration 510, FOC Syn. Speed Controlled

Configuration 510 contains the functions for speed-controlled, field-oriented control of a synchronous machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.

Configuration 511 – FOC Syn. Speed Controlled w. Technology Contr.

Configuration 511 extends the functionality of Configuration 510 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.

Configuration 530, FOC Syn.**with speed/torque control**

Configuration 530 extends the functionality of Configuration 510 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

Configuration 610, DMR for PMSM

Configuration 610 contains the functions for sensorless field-oriented control of a synchronous machine with resolver feedback. The separate control of torque and flux-forming current enables high drive dynamism with a high load moment. The missing resolver feedback results in slightly lower dynamism and speed quality compared to Configuration 510.

Configuration 611 – DMR PMSM w. Technology Contr.

Configuration 611 extends the functionality of Configuration 610 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.

Configuration 630 – DMR PMSM N or M Controlled

Configuration 630 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Torque Controller. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

In the table, you will find a list of functions which are available in the different configurations.

Function	Chapter	Configuration							
		V/f		Field-oriented control					
		Sensorless 1xx		Sensorless 4xx			Sensor 2xx		
		110	111	410	411	430	210	211	230
Speed control	18.5.4			x	x	x	x	x	x
Torque control	18.5.2					x			x
Switch-over speed /torque control	16.4.6					x			x
Dynamic voltage pre-control	17.1	x	x						
Intelligent current limits	18.1	x	x	x	x	x	x	x	x
Voltage controller	18.2	x	x	x	x	x	x	x	x
Technology controller:	18.3		x		x			x	
Pressure control	18.3		x		x			x	
Flow rate control	18.3		x		x			x	
Contents level control	18.3		x		x			x	
Speed control	18.3		x		x			x	
Slip compensation	18.4.1	x							
Current limit value controller	18.4.2	x	x						
Current controller	18.5.1			x	x	x	x	x	x
Limit value sources	18.5.3.3			x	x	x	x	x	x
Acceleration pre-control	18.5.5			x	x	x	x	x	x
Field controller	18.5.6			x	x	x	x	x	x
Modulation controller	18.5.7			x	x	x	x	x	x
Starting behavior:	13.1	x	x	x	x	x	x	x	x
Starting current impression	13.1.1.1	x	x	x	x	x			
Flux formation	13.1.2			x	x	x	x	x	x
Stopping behavior:	13.2	x	x	x	x	x	x	x	x
Direct current brake	13.3	x	x						
Auto start	13.4	x	x	x	x	x	x	x	x
Search run	13.5	x	x	x	x	x	x	x	x
Reference point positioning	13.6.1	x		x			x		
Axis positioning	13.6.2						x		
Frequency reference channel	15.4	x		x		x	x		x
Reference percentage channel	15.5		x		x	x		x	x
Fixed frequencies	15.6.1	x	x	x	x	x	x		x
Fixed percentages	15.6.3		x		x	x		x	x
Block frequencies	15.9	x		x		x	x		x
PWM-/repetition frequency input	15.11	x	x	x	x	x	x	x	x
Brake chopper	19.4	x	x	x	x	x	x	x	x
Motor circuit breaker	19.5	x	x	x	x	x	x	x	x
V-belt monitoring	19.6	x	x	x	x	x	x	x	x
Motor chopper	19.7.1			x	x	x	x	x	x
Temperature Adjustment	19.7.2			x	x	x	x	x	x
Speed sensor monitoring	19.7.3						x	x	x

Function	Chapter	Configuration					
		Field-oriented control					
		Servo 5xx			Servo sensorless 6xx		
		510	511	530	610	611	630
Speed control	18.5.4	x	x	x	x	x	x
Torque control	18.5.2			x			x
Switch-over speed /torque control	16.4.6			x			x
Dynamic voltage pre-control	17.1						
Intelligent current limits	18.1	x	x	x	x	x	x
Voltage controller	18.2	x	x	x	x	x	x
Technology controller:	18.3		x			x	
Pressure control	18.3		x			x	
Flow rate control	18.3		x			x	
Contents level control	18.3		x			x	
Speed control	18.3		x			x	
Slip compensation	18.4.1						
Current limit value controller	18.4.2						
Current controller	18.5.1	x	x	x	x	x	x
Limit value sources	18.5.3.3	x	x	x	x	x	x
Acceleration pre-control	18.5.5	x	x	x	x	x	x
Field controller	18.5.6						
Modulation controller	18.5.7						
Starting behavior:	13.1	x		x	x	x	x
Starting current impression	13.1.1.1				x	x	x
Flux formation	13.1.2						
Stopping behavior:	13.2	x	x	x	x	x	x
Direct current brake	13.3						
Auto start	13.4	x	x	x	x	x	x
Search run	13.5	x	x	x	x	x	x
Reference point positioning	13.6.1	x			x		
Axis positioning	13.6.2	x					
Frequency reference channel	15.4	x		x	x		x
Reference percentage channel	15.5		x	x		x	x
Fixed frequencies	15.6.1	x	x	x	x	x	x
Fixed percentages	15.6.3		x	x		x	x
Block frequencies	15.9	x		x	x		x
PWM-/repetition frequency input	15.11	x	x	x	x	x	x
Brake chopper	19.4	x	x	x	x	x	x
Motor circuit breaker	19.5	x	x	x	x	x	x
V-belt monitoring	19.6	x	x	x	x	x	x
Motor chopper	19.7.1						
Temperature Adjustment	19.7.2						
Speed sensor monitoring	19.7.3						

10.8 Language

The parameters are stored in the frequency inverter in various languages. The parameter description is displayed by the PC control software (e.g. VPlus) in the selected *Language 33*.

Language 33	Function
0 - Deutsch	Parameter description in German
1 - English	Parameter description in English
2 - Italiano	Parameter description in Italian
100 -	The Language is set via VPlus (ACU Firmware as from 5.2.0)



Up to ACU Firmware 5.1.11, the language is set via *Language 33* = 0,1,2, as from ACU Firmware Version 5.2.0, the parameter texts are managed by the VPlus PC software. If *Language 33* is set to 100, settings 0,1 and 2 are disabled.

As from Firmware Version 5.2.0, you will need a suitable VPlus Version (VPlus 7.38 or higher).

10.9 Programming

Parameter *Program 34* enables acknowledgment of a error signal and resetting to the factory settings. The display of the control unit reads "dEFLt" or "rESEt" and the LEDs indicate the status of the frequency inverter.

Program 34	Function
111 - Parameter transfer	Control unit P 500 is prepared for parameter transmission. A connected frequency inverter can receive data from the control unit.
110 - Standard operation	Resetting of control unit KP 500 to standard operation mode.
123 - Reset	The current error message can be acknowledged via digital input S1IND/STOA or the software parameter. The display of the control unit reads "rESEt".
4444 - Default	The parameters of the selected configuration, except for a few exceptions, are reset to the default settings. The display of the control unit reads "dEFLt".



Parameters *Control Level 28* and *Configuration 30* are not changed when reset to default setting (*Program 34* = 4444).

11 Machine data

The input of the machine data is the foundation for the functionality of the control functions and methods. In the course of the guided commissioning, the necessary parameters are queried according to the selected *Configuration 30*.

11.1 Rated motor parameters

Configure the rated motor parameters according to the rating plate of the motor or the motor data sheet. The default settings of the machine parameters are based on the nominal data of the frequency inverter and a four-pole asynchronous motor. The machine data required for the control functions and methods are checked for plausibility and calculated in the course of the commissioning.

- Check the default ratings.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
370	Rated Voltage	$0.17 \cdot U_{FIN}$	$2 \cdot U_{FIN}$	U_{FIN}
371	Rated Current	$0.01 \cdot I_{FIN}$	$10 \cdot o \cdot I_{FIN}$	I_{FIN}
372	Rated Speed	96 min^{-1}	60000 min^{-1}	n_N
373	No. of pole pairs	1	24	2
374	Rated Cosinus (φ)	0.01	1.00	$\cos(\varphi)_N$
375	Rated Frequency	10.00 Hz	599.00 Hz	50.00 Hz
376	Rated Mech. Power	$0.01 \cdot P_{FIN}$	$10 \cdot P_{FIN}$	P_{FIN}

U_{FIN} = Rated frequency inverter voltage, typically 400 V or 230 V

I_{FIN} = Rated frequency inverter output current

P_{FIN} = Rated frequency inverter power

o: Overload capacity of frequency inverter.



Parameter *Rated Cosinus (φ) 374* is not available in Configurations 5xx and 6xx (synchronous motor).

In the case of asynchronous machines, the speed can be increased at a constant torque if the motor winding can be switched over from star to delta connection. The change-over leads to a modification of the dependent rated figures by a square root of three.

NOTICE

The rated data of the motor are to be entered according to the specifications on the rating plate for the motor connection type used (star or delta connection). If the data entered deviate from the rating plate, the parameters will not be identified correctly. Parameterize the rated data according to the rating plate of the motor for the wiring of the motor winding. Consider the increased rated current of the connected three-phase motor.

11.2 Further motor parameters

In particular the field-oriented control requires the determination of further data which cannot be read off the rating plate of the 3-phase machine for the precise calculation of the machine model. In the course of the guided commissioning, the parameter identification was carried out to measure the further motor parameters.

11.2.1 Stator resistance

The resistance of the stator winding is measured during the guided commissioning. The measured value is saved as a phase value in parameter *Stator Resistance* **377** and is 3 times smaller than the winding resistance in delta connection.

By default, the equivalent stator resistance of a standard motor was entered to match the reference output of the frequency inverter.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
377	Stator Resistance ¹⁾	0 mΩ	65535 mΩ	R _{SN}
1190	Stator Resistance ²⁾	0.001 Ω	100.000 Ω	10.000 Ω

¹⁾ In settings 1xx, 2xx, 4xx of Parameter *Configuration* **30**.

²⁾ In settings 5xx and 6xx of Parameter *Configuration* **30**.

Stator resistance asynchronous motor:

The stator resistance of an asynchronous motor can be optimized while the machine is in no-load operation. At the stationary operating point, the torque-forming current *Isq* **216** and/or the estimated *Active Current* **214** should be zero. Due to the temperature-dependent of the stator resistance, the adjustment should be done at a winding temperature which is also reached during normal operation.

A correct measurement will optimize the control functions.

Stator resistance synchronous motor:

The stator resistance value of a synchronous machine is entered during commissioning. The stator resistance is needed for the current controller settings and should be available and entered as exactly as possible for this reason. The *Stator Resistance* **1190** is referred to the value between two motor phases and can typically be applied directly from the motor data sheet.

11.2.2 Leakage coefficient

The leakage coefficient of the machine defines the ratio of the leakage inductance to the main inductance. The torque and flux-forming current components are thus coupled via the leakage coefficient. Optimization of the leakage coefficient within the field-oriented control systems demands an acceleration to various operating points of the drive. The flux-forming current *Isd* **215** should be largely independent of the load torque (unlike the torque-forming current *Isq* **216**). The flux-forming current component is inversely proportional to the leakage coefficient. If the leakage coefficient is increased, the torque-forming current increases and the flux-forming component drops. The adjustment should result in a relatively constant actual current *Isd* **215** matching the set *Rated Magnetising Current* **716**, regardless of the load on the drive.

The sensorless control system uses the parameter *Leakage Coeff.* **378** in order to optimize the synchronization to one drive.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
378	Leakage coefficient	1.0 %	20.0 %	7.0 %

11.2.3 Magnetizing Current

The *Rated Magnetising Current* **716** is a measure of the flux in the motor and thus of the voltage which is present at the machine in no-load condition depending on the speed. The guided commissioning determines this value at approx. 30% of the *Rated Current* **371**. This current can be compared to the field current of an externally excited direct current machine.

In order to optimize the sensorless field-oriented control system, the machine must be operated without load at a rotational frequency which is below the *Rated Frequency* **375**. The accuracy of the optimization increases with the adjusted *Switching Frequency* **400** and when the drive is in no-load operation. The flux-forming actual current value *I_{sd}* **215** to be read out should roughly match the set *Rated Magnetising Current* **716**.

The field-oriented control with speed sensor feedback uses the parameterized *Rated Magnetising Current* **716** for the flux in the motor.

The dependence of the magnetizing on the frequency and voltage at the corresponding operating point in question is taken into account by a magnetizing characteristic. The characteristic is calculated via three points, in particular in the field weakening area above the rated frequency. The parameter identification has determined the magnetizing characteristic and set the parameters *Magnetising Current 50% Flux* **713**, *Magnetising Current 80% Flux* **714** and *Magnetising Current 110% Flux* **715**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
713	Magnetizing current 50%	1.00 %	50.00 %	31.00 %
714	Magnetizing current 80%	1.00 %	80.00 %	65.00 %
715	Magnetizing current 110%	110.00 %	197.00 %	145.00 %
716	Rated magnetizing current	$0.01 \cdot I_{FIN}$	$0 \cdot I_{FIN}$	$0.3 \cdot I_{FIN}$

11.2.4 Rated slip correction factor

The rotor time constant results from the inductance of the rotor circuit and the rotor resistance. Due to the temperature-dependence of the rotor resistance and the saturation effects of the iron, the rotor time constant is also dependent on temperature and current. The load behavior and thus the rated slip depend on the rotor time constant. The guided commissioning determines the machine data during the parameter identification and sets the parameter *Rated Slip Correction Factor* **718** accordingly. For the fine adjustment or a check of the rotor time constant, proceed as follows: Load the machine at fifty percent of the *Rated Frequency* **375**. As a result, the voltage must be approximately fifty percent of the *Rated Voltage* **370** with a max. deviation of 5%. If this is not the case, the correction factor must be changed accordingly. The larger the correction factor is set, the stronger the voltage drop when the machine is loaded. The software-calculated rotor time constant value can be read via actual value *Act. Rotor Time Constant* **227**. The adjustment should be done at a winding temperature which is also reached during normal operation of the motor.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
718	Rated slip correction factor	0.01 %	300.00 %	100.00 %

11.2.5 Voltage Constant

In Configuration 5xx and 6xx for control of synchronous machines, the control behavior can be improved for highly dynamic requirements by setting parameter *Voltage Constant* **383**.

For the voltage constant, refer to the motor data sheet. In the motor data sheet, the value may be

indicated in $\frac{V}{1000 \frac{U}{\text{min}}}$.

This value can be applied to parameter *Voltage Constant* **383**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
383	Voltage Constant	0.0 mVmin	850.0 mVmin	0.0 mVmin

If guided commissioning (Setup) is not used, the self-setup should be performed to improve the drive behavior, especially for small speeds, via parameter *SETUP Select* **796**. Select one of the settings 10 ... 14 for *SETUP Select* **796**.

During guided commissioning (via control panel and VPlus) of BONFIGLIOLI motors, the Voltage Constant is preset.

In the case of non-BONFIGLIOLI motors, the voltage constant should be entered if known. If you don't know the voltage constant, set *Voltage Constant* **383** to 0 mV before commissioning, to enable automatic calculation and measurement.

The voltage constant should be optimized after the guided commissioning procedure: In no-load operation, set 50% of the rated speed. Change the voltage constant in small steps until parameter *Rotor Flux* **225** reads 101% ($\pm 0.5\%$).



In the case of motors with a very high number of pole pairs (e.g. higher than 20), it is possible that the maximum setting range of the parameter is not sufficient. In this case, divide the voltage constant by 10 and enter the value. The division by 10 is considered internally.

11.2.6 Stator inductance

In Configuration 5xx for control of synchronous machines, the control behavior can be improved for highly dynamic requirements by setting parameter *Stator Inductance* **384**.

The *Stator Inductance* **384** is referred to the value between two motor phases and can typically be applied directly from the motor data sheet.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
384	Stator inductance	0.1 mH	500.0 mH	1.0 mH

11.2.7 Peak current

Parameter *Peak Current* **1192** is used during motor commissioning in order to set the Isq setpoint limit in the frequency inverter. This is to protect the connected synchronous motor. The value can be taken from the motor rating plate or the motor data sheet. Exceeding the value specified by the manufacturer may result in motor damage.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
1192	Peak current	0.01 % $I_{FU,N}$	100 000 % $o \cdot I_{FU,N}$	100 % $I_{FU,N}$

$I_{FU,N}$: Nominal value of frequency inverter

o: Overload capacity of frequency inverter.

11.2.8 Reverse sense of rotation

Parameter *Change Sense of Rotation* **1199** reverses the sense of motor rotation.

Change Sense of Rotation 1199		Positive setpoint	Negative setpoint
0 - off		Motor turning right (clockwise)	Motor turning left (anti-clockwise)
1 - On		Motor turning left (anti-clockwise)	Motor turning right (clockwise)



BONFIGLIOLI VECTRON MDS GmbH definition: clockwise sense of rotation with positive setpoint, looking to the A-side of motor, provided that motor phases are connected correctly. Upon reversal of the sense of rotation, the direction of rotation is reversed while the setpoint remains the same. Any gears which might be installed must be taken into consideration.



Change Sense of Rotation can only be edited with the output stage disabled.



Via *Change Sense of Rotation* **1199**, the sense of rotation of the whole system (motor control and sensor evaluation) is reversed.

If the senses of rotation of the motor and the sensor are different, this can be changed in two ways:

By exchanging Track A and Track B the sensor inputs at ACU.

- 1.) Change sense of rotation of connected sensor via parameters **490** or **493**.

11.3 Internal values

The following parameters are used for internal calculation of motor data and do not require any set-up.

Parameter	
No.	Description
399	Internal value 01
402	Internal value 02
508	Internal value 03
702	Internal value 04
703	Internal value 05
704	Internal value 06
705	Internal value 07

Parameter	
No.	Description
706	Internal value 08
707	Internal value 09
708	Internal value 10
709	Internal value 11
745	Internal value 12
798	Internal value 13

11.4 Speed Sensor 1

The frequency inverters are to be adapted to the application depending on the requirements. Some of the available *Configurations 30* require continuous measurement of the actual speed for the control functions and methods. The necessary connection of an incremental speed sensor is done on the digital control terminals S5IND (track A) and S4IND (track B) of the frequency inverter.



With extension modules EM and sensor input modules, it is also possible to connect and evaluate sensors as speed sensor 2. Please refer to the corresponding operating instructions. Speed sensor 1 and speed sensor 2 are configured independently from one another.

11.4.1 Operation Mode Speed Sensor 1

Operation Mode 490 for speed sensor 1 can be selected according to the connected incremental speed sensor. A unipolar speed sensor is to be connected to the standard control terminals.

<i>Operation Mode 490</i>	Function
0 - off	Speed measurement is not active; the digital inputs are available for other functions.
1 – Single Evaluation	Two-channel speed sensor with recognition of direction of rotation via track signals A and B; one signal edge is evaluated per division mark.
4 – Quadruple Evaluation	Two-channel speed sensor with recognition of direction of rotation via track signals A and B; four signal edges are evaluated per division mark.
11 – Single Evaluation unsigned	One-channel speed sensor via track signal A; the actual speed value is positive. One signal edge is evaluated per division mark. The digital input S4IND is available for further functions.
12 – Double Evaluation unsigned	One-channel speed sensor via track signal A; the actual speed value is positive. Two signal edges are evaluated per division mark. The digital input S4IND is available for further functions.
31 – Single evaluation, sense of rot. via contact	Single-channel speed sensor via track signal A. The actual speed value is positive for signal "Low" and negative for signal "High" at digital input S4IND. One signal edge is evaluated per division mark.
32 – Double Evaluation, Dir. via contact	Single-channel speed sensor via track signal A. The actual speed value is positive for signal "Low" and negative for signal "High" at digital input S4IND. Two signal edges are evaluated per division mark.
101 – Single evaluation inverted	Like Operation Mode 1. The actual speed value is inverted. (Alternative to exchanging the track signals)
104 – Quadruple evaluation inverted	Like Operation Mode 4. The actual speed value is inverted. (Alternative to exchanging the track signals)
111 – Single Evaluation negative	Like Operation Mode 11. Actual speed is negative.
112 – Double Evaluation negative	Like Operation Mode 12. Actual speed is negative.
131 – Single evaluation, sense of rot. Cont. inverted	Single-channel speed sensor via track signal A. The actual speed value is negative for signal "Low" and positive for signal "High" at digital input S4IND. One signal edge is evaluated per division mark.
132 – Double Evaluation, Dir. Cont. inverted	Single-channel speed sensor via track signal A. The actual speed value is negative for signal "Low" and positive for signal "High" at digital input S4IND. Two signal edges are evaluated per division mark.

Operation Mode 490	Function
1001 – Single Evaluation w. Ref.-Pulse	Two-channel speed sensor with recognition of direction of rotation via track signals A and B, reference track via digital input S6IND. One signal edge is evaluated per division mark.
1002 – Double Evaluation w. Ref.-Pulse	Two-channel speed sensor with recognition of direction of rotation via track signals A and B, reference track via digital input S6IND. Two signal edges are evaluated per division mark.
1004 – Quadruple Evaluation w. Ref.-Pulse	Two-channel speed sensor with recognition of direction of rotation via track signals A and B, reference track via digital input S6IND. Four signal edges are evaluated per division mark.
1011 – Single Evaluation unsigned w. Ref.-Pulse	One-channel speed sensor via track signal A; the actual speed value is positive. The reference track is connected to digital input S6IND. One signal edge is evaluated per division mark. The digital input S4IND is available for further functions.
1012 – Double Evaluation unsigned w. Ref.-Pulse	One-channel speed sensor via track signal A; the actual speed value is positive. The reference track is connected to digital input S6IND. Two signal edges are evaluated per division mark. The digital input S4IND is available for further functions.
1031 – Single Evaluation, Dir. Cont. w. Ref.-Pulse	Single-channel speed sensor via track signal A. The actual speed value is positive for signal "Low" and negative for signal "High" at digital input S4IND. One signal edge is evaluated per division mark. The reference track is connected to digital input S6IND.
1032 – Double Evaluation, Dir. Cont. w. Ref.-Pulse	Single-channel speed sensor via track signal A. The actual speed value is positive for signal "Low" and negative for signal "High" at digital input S4IND. Two signal edges are evaluated per division mark. The reference track is connected to digital input S6IND.
1101 – Single Evaluation inverted w. Ref.-Pulse	Like Operation Mode 1001. Actual speed is negative.
1102 – Double Evaluation inverted w. Ref.-Pulse	Like Operation Mode 1002. Actual speed is negative.
1104 – Quadruple Evaluation inverted w. Ref.-Pulse	Like Operation Mode 1004. Actual speed is negative.
1111 – Single Evaluation inverted unsigned w. Ref.-Pulse	Like Operation Mode 1011. Actual speed is negative.
1112 – Double Evaluation inverted unsigned w. Ref.-Pulse	Like Operation Mode 1012. Actual speed is negative.
1131 – Single Evaluation, Dir. Cont. inverted w. Ref.-Pulse	Single-channel speed sensor via track signal A. The actual speed value is negative for signal "Low" and positive for signal "High" at digital input S4IND. One signal edge is evaluated per division mark. The reference track is connected to digital input S6IND.
1132 – Double Evaluation, Dir. Cont. inverted w. Ref.-Pulse	Single-channel speed sensor via track signal A. The actual speed value is negative for signal "Low" and positive for signal "High" at digital input S4IND. Two signal edges are evaluated per division mark. The reference track is connected to digital input S6IND.



In configurations 210, 211 and 230, digital input S4IND is by default set for the evaluation of a speed sensor signal (track B).

If an operation mode without sign is selected (Operation Mode 11 or Operation Mode 12), this input is not set for the evaluation of a speed sensor signal and can be used for other functions.

11.4.2 Division Marks, Speed Sensor 1

The number of increments of the connected speed sensor can be adjusted via parameter *Division Marks Speed Sensor 1* **491**. Select the division marks of the speed sensor according to the speed range of the application.

The maximum number of division marks S_{\max} is defined by the frequency limit of $f_{\max}=150$ kHz of the digital inputs S5IND (track A) and S4IND (track B).

$$S_{\max} = f_{\max} \cdot \frac{60}{n_{\max}}$$

f_{\max} = 150000 Hz
 n_{\max} = max. speed of the motor in RPM

for example:

$$S_{\max} = 150000 \text{ Hz} \cdot \frac{60 \text{ s}}{1500} = 6000$$

To guarantee true running of the drive, an encoder signal must be evaluated at least every 2 ms (signal frequency $f = 500$ Hz). The minimum number of division marks S_{\min} of the incremental encoder for a required minimum speed n_{\min} can be calculated from this requirement.

$$S_{\min} = f_{\min} \frac{60}{A \cdot n_{\min}}$$

n_{\min} = min. speed of the motor in RPM = evaluation (1, 2, 4)
 A

for example:

$$S_{\min} = 500 \text{ Hz} \cdot \frac{60 \text{ s}}{2 \cdot 10} = 1500$$


Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
491	Division Marks, Speed Sensor 1	1	8192	1024

11.4.3 Gear factor speed sensor 1

Setting of parameters *EC1 Gear Factor Numerator* **511** and *EC1 Gear Factor Denominator* **512** is required if a gear is installed between the speed sensor and the motor shaft. The parameters define the mechanical transmission ratio between the speed sensor and the motor side. The parameters must be set such that the gear factor numerator corresponds to the motor rotations and the gear factor denominator corresponds to the sensor rotations.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
511	EC1 Gear Factor Numerator	-300.00	300.00	1.00
512	EC1 Gear Factor Denominator	0.01	300.00	1.00

Example: The motor shaft turns twice while the load shaft rotates once (16/8).



$$\frac{\text{Revolutions of motor axis}}{\text{Revolutions of load axis}} = \frac{\text{EC1 Gear Factor Numerator } \mathbf{511}}{\text{EC1 Gear Factor Denominator } \mathbf{512}}$$

In this example, parameter *EC1 Gear Factor Numerator* **511** must be set to 2 and parameter *EC1 Gear Factor Denominator* **512** must be set to 1.



For optimum motor control, BONFIGLIOLI VECTRON MDS GmbH recommends installing a speed sensor directly at the motor.

11.4.4 Filter time constant, Speed Sensor 1

EC1 Filter time constant **1193** can be used in order to filter the speed of speed sensor 1. This filter can be used in situations where the speed sensor fluctuates (e.g. for mechanical reasons).

BONFIGLIOLI VECTRON MDS GmbH recommends changing the value in small steps and checking the individual results. Do not change the value in great steps.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
1193	EC1 Filter time constant	0 us	32000 us	0 us

11.5 Sensor evaluation

In the field of drive engineering, TTL and HTL sensors with 512, 1024 or 2048 division marks are widely used. However, other division mark values are used, too. These division marks (often also referred to as „increments“) determine the resolution (accuracy) at which a plant can be operated. A “division mark” is defined as a pulse including the pause following the pulse – the pulse-duty factor is typically 1:1, i.e. with each revolution, a track delivers the number of increments for evaluation. Depending on the characteristics of the sensor and the requirements in the plant, different degrees of sensor evaluation are possible. Typical evaluation accuracy levels include:

Single evaluation: One edge of a pulse of a track is counted and evaluated.

Double evaluation: Two edges (the positive and the negative edge) of a pulse of a track are counted and evaluated.


Quadruple evaluation: A second (offset) track delivers additional edges which can be evaluated. Any status change of the two tracks is registered and evaluated. Thanks to the offset arrangement of the tracks, the direction of rotation can be detected additionally. The two tracks are commonly referred to as A and B. Depending on when the edges occur, it can be determined if the motor rotates in clockwise or in anticlockwise direction.

With double or quadruple evaluation, internal calculation for motor control is improved. The number of division marks does not change.

In addition to tracks A and B, sensors often feature a reference track (also referred to as Z track, zero track, C track). The reference track delivers one pulse per revolution. This track is used for plausibility checking or for additional functions.



If an operation mode with reference track is selected for the speed sensor, the frequency inverter will make sure that the Z track occurs according to the parameterized *Division Marks Speed Sensor 1 491*. If the evaluation is not consistent, a reaction as per parameter *Operation Mode 760* is triggered.



Example (quadruple evaluation):

Each edge 1, 2, 3 and 4 is an evaluated signal within the pulse-pause cycle of Track A. After that, the cycle is restarted. The type of edges indicates the direction of rotation:

Clockwise direction of rotation: A rising edge of A (1) is followed by a rising edge of B (2).

Anticlockwise direction of rotation A rising edge of A (1) is followed by a falling edge of B (2).

Track Z: One pulse per revolution



HTL encoders can be connected to the basic device. For connection of TTL encoders, you will need a type EM-ENC encoder module. For connection of SinCos encoders or absolute encoders, you will need a type EM-ABS encoder module.

12 System data

The various control functions and methods according to the selected *Configuration 30* are supplemented by control and special functions. For monitoring the application, process parameters are calculated from electrical control parameters.

12.1 Actual value system

Parameter *Factor Actual Value System 389* can be used if the drive is monitored via actual value *Actual Value System 242*.

The *Actual Frequency 241* to be monitored is multiplied by the *Factor Actual Value System 389* and can be read out via Parameter *Actual Value System 242*, i. e. *Actual Frequency 241* x *Factor Actual Value System 389* = *Actual Value System 242*.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
389	Factor Actual Value System	-100.000	100.000	1.000


12.2 Volume Flow and Pressure

Parameterization of factors *Nominal Volumetric Flow 397* and *Nominal Pressure 398* is necessary if the matching actual values *Volumetric Flow 285* and *Pressure 286* are used for drive monitoring. The conversion is done using the electrical control parameters.

Volumetric Flow 285 and *Pressure 286* are referred to *Active Current 214* in the case of sensor-less control methods. In the case of the field-oriented control methods, they are referred to the torque-forming current component *Isq 216*.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
397	Nominal Volumetric Flow	1 m ³ /h	99999 m ³ /h	10 m ³ /h
398	Nominal pressure	0.1 kPa	999.9 kPa	100.0 kPa

Line mains or channel characteristic:



Point A in the figure describes the rating point of a pump. The transition to partial load operation mode B1 can be effected at a constant pressure H (change of conveying flow Q, pressure H remains constant). The transition to partial load operation mode B2 can be effected according to the bad point method (change of pressure H and conveying flow Q). Both methods can be realized with the integrated technology controller in configurations 111, 211, 411 and 611. The actual values displayed are calculated according to the bad point method independently of the selected *Operation Mode 440* of the technology controller.

13 Operating behavior

The operational behavior of the frequency inverter can be adjusted to the application by setting the parameters appropriately. In particular the acceleration and deceleration behavior can be selected according to the selected *Configuration 30*. Additionally, features such as Auto Start, and the synchronization and positioning functions facilitate the integration in the application.

13.1 Starting behavior

The start of the 3-phase machine can be parameterized in accordance with the control functions and methods. In contrast to the sensorless control method, the field-oriented control methods only require the definition of the limit values *Max. Flux-Formation Time 780* and *Current during Flux-Formation 781* for the adjustment of the acceleration behavior. The acceleration behavior of the sensorless control method in configurations 110 and 111 can be selected as described in the following chapter.

13.1.1 Starting Behavior of Sensorless Control System

Parameter *Operation Mode 620* for the starting behavior is available in Configurations 110 and 111. Depending on the operation mode selected, the machine is magnetized first or a starting current is impressed. The voltage drop across the stator resistance which reduces the torque in the lower frequency range can be compensated by the IxR compensation.

To ensure the correct function of the IxR compensation, the stator resistance is determined during the guided commissioning. The IxR compensation is only activated when the stator resistance was determined correctly.

Operation Mode 620	Starting behavior
0 - off	During startup, at an output frequency of 0 Hz, the voltage is set via parameter <i>Starting Voltage 600</i> . After this, the output voltage and the output frequency are changed according to the control method. The break-away torque and the current at the start is determined by the adjusted starting voltage. It may be necessary to optimize the starting behavior via the parameter <i>Starting Voltage 600</i> .
1 - Magnetization	In this operation mode, the <i>Current during Flux-Formation 781</i> for magnetization is impressed into the motor after release. The output frequency is kept at 0 Hz for the <i>Max. Flux-Formation Time 780</i> . After this time has expired, the output frequency follows the adjusted V/f characteristic. (see operation mode 0- Off)
2 - Magnetisation+Current Impr.	Operation mode 2 includes operation mode 1. Once the <i>Max. Flux-Formation Time 780</i> has elapsed, the output frequency is increased according to the set acceleration. If the output frequency reaches the value set with the parameter <i>Frequency Limit 624</i> the <i>Starting Current 623</i> is withdrawn. There is a smooth transition to 1.4 times the frequency limit to the set V/f characteristic. As from this operating point, the output current depends on the load.
3 - Magnetization + IxR compensation	Operation mode 3 includes operation mode 1 of the start function. When the output frequency reaches the value set with parameter <i>Frequency Limit 624</i> , the increase of the output voltage by the IxR compensation becomes effective. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.

Operation Mode 620	Starting behavior
4 - Magnetization + current impr.+ I*R-Comp.	In this operation mode, the current set with the parameter <i>Current during Flux-Formation</i> 781 is impressed into the motor for magnetization after release. The output frequency is kept at 0 Hz for the <i>Max. Flux-Formation Time</i> 780 . Once this time has elapsed, the output frequency is increased according to the set acceleration. Once the output frequency reaches the value set with parameter <i>Frequency Limit</i> 624 , the <i>Starting Current</i> 623 is withdrawn. There is a smooth transition to the V/f characteristic, and a load-dependent output current is obtained. At the same time, the increase of the output voltage by the IxR compensation becomes effective as from this output frequency. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.
12 - Magn.+ Curr.Imp. w. Ramp Stop	Operation mode 12 contains an additional function to guarantee a starting behavior under difficult conditions. The magnetization and starting current impression are done according to operation mode 2. The ramp stop takes the current consumption of the motor at the corresponding operating point into account and controls the frequency and voltage change by stopping the ramp. The <i>Controller Status</i> 275 signals intervention of the controller by displaying message "RSTP".
14 - Magn.+ Curr.Imp. w. RS.+ I*R-Comp.	In this operation mode, the functions of operation mode 12 are extended by the compensation of the voltage drop across the stator resistance. When the output frequency reaches the value set with parameter <i>Frequency Limit</i> 624 , the increase of the output voltage by the IxR compensation becomes effective. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.

In contrast to field-oriented control systems, sensorless control systems feature a current controller which controls the starting behavior. The PI controller controls the current impress of parameter *Starting Current* **623**. The proportional and integrating part of the current controller can be set via parameters *Amplification* **621** and *Integral Time* **622**. The control functions can be deactivated by setting the parameters to 0.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
621	Amplification	0.01	10.00	1.00
622	Integral Time	1 ms	30 000 ms	50 ms

13.1.1.1 Starting current

The *Starting Current* **623** ensures, particularly for high-torque start, a sufficient torque until the *Frequency Limit* **624** is reached.

Applications in which high current is permanently needed at a low speed are to be realized using forced-ventilated motors to prevent thermal overload.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
623	Starting current	0.0 A	0·I _{FIN}	I _{FIN}

I_{FIN} = Rated frequency inverter output current

o: Overload capacity of frequency inverter.

In the following settings, the starting current impression is used for the starting behavior:

- *Configuration 30* = 1xx (V/f control of asynchronous motor),
Operation Mode 620 = 2, 4, 12 or 14
- *Configuration 30* = 4xx (FOR of an asynchronous motor)
- *Configuration 30* = 6xx (PSM: sensor-less, field-oriented control - DMR), synchronous motor

13.1.1.2 Frequency Limit

The *Starting Current 623* is impressed in configurations 1xx, 4xx and 6xx for control of the relevant configuration until the *Frequency Limit 624* is reached. Permanent operating points below the frequency limit are only permissible if forced-ventilated motors are used.

The transition to the control method of the selected *Configuration 30* takes place above the frequency limit.

The *Frequency Limit 624* is set automatically during guided motor commissioning in the field-oriented configurations 4xx and 6xx. In V/f control configuration 1xx, parameter *Frequency Limit 624* is not changed during guided motor commissioning.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
624	Frequency Limit	0.00 Hz	100.00 Hz	2.60 Hz

13.1.1.3 Brake release time

In order to protect the motor holding brake against damage, the motor may only start after the brake has been released. Startup to reference speed is effected only after the *Brake Release Time 625* has elapsed. The time should be set such that it is at least as long as the time required for releasing the holding brake. By using negative values for the parameter, release of the brake is delayed. This can be done in order to prevent loads from falling down, for example.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
625	Brake Release Time	-5000 ms	5000 ms	0 ms

13.1.2 Flux formation

Field-oriented control in the configurations 2xx and 4xx are based on separate regulation of the flux-forming and torque-forming current components. Upon startup, the machine is magnetized and a current is impressed first. With parameter *Current during Flux-Formation 781*, the magnetization current I_{sd} is set. With parameter *Max. Flux-Formation Time 780* the maximum current impression time is set.

The current impression is done until the reference value of the rated magnetizing current is reached or the *Max. Flux-Formation Time 780* is exceeded.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
780	Max. Flux-Formation Time	1 ms	10000 ms	300 ms ¹⁾
				1000 ms ²⁾
				50 ms ³⁾
781	Current during flux formation	$0.1 \cdot I_{FIN}$	$0 \cdot I_{FIN}$	I_{FIN}

The factory setting of parameter *Max. Flux-Formation Time 780* depends on parameter *Configuration 30*:

¹⁾ Configurations 1xx

²⁾ Configurations 2xx/4xx

³⁾ Configurations 6xx

The Current during Flux-Formation changes depending on the rotor time constant of the motor. The settings of parameters *Max. Flux-Formation Time* **780** and *Min. Flux-Formation Time* **779** can contribute to obtaining a constant flux formation time. With parameter *Min. Flux-Formation Time* **779**, you can set the minimum current impression time. In this way, the time between a start signal and the start of the drive can be defined. For proper setting of the parameters, you will have to consider the rotor time constant, the starting torque required and parameter *Current during Flux-Formation* **781**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
779	Minimum flux formation time	1 ms	10000 ms	10 ms ¹⁾ 50 ms ²⁾

The factory setting of parameter *Min. Flux-Formation Time* **779** depends on parameter *Configuration* **30**:

¹⁾ Configurations 2xx/4xx

²⁾ Configurations 6xx

<i>Min. Flux-Formation Time</i> 779 = 0	Flux formation is stopped as soon <ul style="list-style-type: none"> – as the reference flux value or the – maximum flux formation time were reached
<i>Min. Flux-Formation Time</i> 779 > 0	Current is impressed for flux formation at least for this time even if the reference flux value was reached.
<i>Min. Flux-Formation Time</i> 779 = <i>Max. Flux-Formation Time</i> 780	Flux formation is stopped after the set flux formation time, regardless of whether the reference flux value was reached or not.
<i>Min. Flux-Formation Time</i> 779 > <i>Max. Flux-Formation Time</i> 780	Flux formation is stopped after the maximum flux formation time.

13.2 Stopping behavior

The stopping behavior of the three-phase machine can be defined via parameter *Operation Mode* **630**. The signal states of the digital inputs or logic signals for parameters *Start Clockwise* **68** and *Start Anticlockwise* **69** will activate stopping procedure. Depending on the setting for *Configuration* **30**, digital inputs or logic signals must be assigned to these parameters or were already set in the factory. By combination of the digital input states or logic signals, the stopping behaviors can be selected from the following table.

Stopping behavior									
<i>Operation Mode</i> 630		Start clockwise = 0 and Start anticlockwise = 0							
		Stopping behavior 0	Stopping behavior 1	Stopping behavior 2	Stopping behavior 3	Stopping behavior 4	Stopping behavior 5	Stopping behavior 6	Stopping behavior 7
Start clockwise = 1 and Start anticlockwise = 1	Stopping behavior 0 (Coasting)	0	1	2	3	4	5	6	7
	Stopping behavior 1 (Shutdown and switch off)	10	11	12	13	14	15	16	17
	Stopping behavior 2 (Shut-down and hold)	20	21	22	23	24	25	26	27
	Stopping behavior 3 (Shut-down and DC brakes)	30	31	32	33	34	35	36	37
	Stopping behavior 4 (Emergency stop and switch off)	40	41	42	43	44	45	46	47
	Stopping behavior 5 (Emergency stop and hold)	50	51	52	53	54	55	56	57
	Stopping behavior 6 (Emergency stop and DC brakes)	60	61	62	63	64	65	66	67
	Stopping behavior 7 (DC brakes)	70	71	72	73	74	75	76	77

Operation Mode **630** of the stopping behavior is to be parameterized according to the matrix. The selection of the operation modes can vary according to the control method and the available control inputs.

Example: The machine is to stop according to stopping behavior 2 if the digital logic signals *Start Clockwise* **68** = 0 and *Start Anticlockwise* **69** = 0.

Additionally, the machine is to stop according to stopping behavior 1 if the digital logic signals *Start Clockwise* **68** = 1 and *Start Anticlockwise* **69** = 1.

To achieve this, parameter *Operation Mode* **630** must be set to 12.

By selecting the stopping behavior you also select the control of a mechanical brake if operation mode „41 - Brake release“ is used for one digital output for controlling the brake.

Stopping behavior	
Stopping behavior Coast to stop	The inverter is disabled immediately. The drive deenergized immediately and coasts freely.
Stopping behavior 1 Stop + off	The drive is brought to a standstill at the set deceleration. As soon as the drive is at a standstill, the inverter is disabled after a after a holding time. The holding time can be set via parameter <i>Holding Time</i> 638 . Depending on the setting of parameter <i>Starting Function</i> 620 , the <i>Starting Current</i> 623 will be impressed or the <i>Starting Voltage</i> 600 will be applied.
Stopping behavior 2 Stop + Hold	The drive is brought to a standstill at the set deceleration and remains permanently supplied with current. Depending on the setting of parameter <i>Starting Function</i> 620 , the <i>Starting Current</i> 623 will be impressed as from standstill, or the <i>Starting Voltage</i> 600 will be applied. In Configurations 2xx, the magnetizing current is used instead of the <i>Starting Current</i> 623 . The magnetizing current results from the <i>Rated Magnetising Current</i> 716 and <i>Reduction Factor Flux</i> 778 .
Stopping behavior 3 Stop + DC brakes	The drive is brought to a standstill at the set deceleration. As from standstill, the DC set via parameter <i>Braking Current</i> 631 is impressed for the <i>Braking Time</i> 632 . Comply with the notes in chapter "Direct current brake". Stopping behaviors 3, 6 and 7 are only available in the configurations of sensor-less V/f control (1xx).
Stopping behavior 4 emergency stop + off	The drive is brought to a standstill at the emergency stop deceleration. As soon as the drive is at a standstill, the inverter is disabled after a after a holding time. The holding time can be set via parameter <i>Holding Time</i> 638 . Depending on the setting of parameter <i>Starting Function</i> 620 , the <i>Starting Current</i> 623 will be impressed or the <i>Starting Voltage</i> 600 will be applied as from standstill.
Stopping behavior 5 Emergency stop + hold	The drive is brought to a standstill at the emergency stop deceleration and remains permanently supplied with current. Depending on the setting of parameter <i>Starting Function</i> 620 , the <i>Starting Current</i> 623 will be impressed or the <i>Starting Voltage</i> 600 will be applied as from standstill.
Stopping behavior 6 Emergency stop + DC brakes	The drive is brought to a standstill at the set emergency stop deceleration. As from standstill, the DC set via parameter <i>Braking Current</i> 631 is impressed for the <i>Braking Time</i> 632 . Comply with the notes in chapter "Direct current brake". Stopping behaviors 3, 6 and 7 are only available in the configurations of sensor-less V/f control (1xx).
Stopping behavior 7 DC brake	DC braking is activated immediately. The direct current set with the parameter <i>Braking Current</i> 631 is impressed for the <i>Braking Time</i> 632 . Comply with the notes in chapter "Direct current brake". Stopping behaviors 3, 6 and 7 are only available in the configurations of sensor-less V/f control (1xx).

Please refer to Chapter 16.3.5 "16.3.5" for information on mechanical brake control.

When a synchronous motor is connected, BONFIGLIOLI VECTRON MDS GmbH recommends setting *Operation Mode* **630** = 22.

13.2.1 Switch-Off Threshold

The *Switch-Off Threshold* **637** defines the frequency as from which a standstill of the drive is recognized. This percentage parameter value is relative to the set *Maximum Frequency* **419**.

The switch-off threshold is to be adjusted according to the load behavior of the drive and the device output, as the drive must be controlled to a speed below the switch-off threshold.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
637	Switch-Off Threshold	0.0 %	100.0 %	1.0 %



WARNING

If the motor builds up a stopping torque, it may be possible that the switch-off threshold stop function is not reached due to the slip frequency and the standstill of the drive is not recognized. In this case, increase the value of the *Switch-Off Threshold* **637**.

13.2.2 Holding Time

The *Holding Time* **638** is considered in stopping behavior 1, 3, 4 and 6. Control to Zero speed results in the motor heating up and should only be done for a short period in the case of internally ventilated motors.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
638	Holding time stop function	0.0 s	200.0 s	1.0 s

13.3 Direct current brake

Stopping behaviors 3, 6, 7 and the search run function include the direct current brake. Depending on the setting of the stop function, a direct current is impressed into the motor either directly or, when it is at a standstill, after the demagnetization time. The impression of the *Braking Current* **631** results in the motor heating up and should only be done for a short period in the case of internally ventilated motors.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
631	Braking current	0.00 A	$\sqrt{2} \cdot I_{FIN}$	$\sqrt{2} \cdot I_{FIN}$

I_{FIN} : Rated value of frequency inverter

The setting of the parameter *Braking Time* **632** defines the time-controlled stopping behavior. Contact-controlled operation of the direct current brake is activated by entering the value zero for the *Braking Time* **632**.

Time controlled:

The direct current is controlled by the status of the signals Start clockwise and Start anticlockwise. The current set by the parameter *Braking Current* **631** flows until the time set by the parameter *Braking Time* **632** has elapsed.

For the duration of the braking time, the control signals Start clockwise and Start anticlockwise are logical 0 (Low) or 1 (High).

Contact-controlled:

If parameter *Braking Time* **632** is set to the value 0.0 s, the direct current brake is controlled by the Start clockwise and Start anticlockwise signals. The time monitoring and limitation by *Braking Time* **632** are deactivated. The braking current will be impressed until the controller enable control signal (S1IND/STOA and S7IND/STOB) becomes logical 0 (low).

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
632	Braking time	0.0 s	200.0 s	10.0 s

To avoid current surges, which can possibly lead to an error switch-off of the frequency inverter, a direct current may only be impressed into the motor after the motor has been demagnetized. As the demagnetization time depends on the motor used, it can be set with the parameter *Demagnetizing Time* **633**.

The selected demagnetizing time should be approximately three times the *Act. Rotor Time Constant* **227**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
633	Demagnetizing time	0.1 s	30.0 s	5.0 s

The selected stopping behavior is supplemented by a current controller to control the direct current brake. The compensated proportional regulator controls the current impression of the parameterized *Braking Current* **631**. The proportional and integrating part of the current controller can be set via parameters *Amplification* **634** and *Integral Time* **635**. The control functions can be deactivated by setting the parameters to 0.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
634	Amplification	0.00	10.00	1.00
635	Integral Time	0 ms	1000 ms	50 ms

13.4 Auto start



WARNING

Comply with VDE provision 0100 part 227 and provision 0113, in particular Sections 5.4, protection against automatic after main line voltage failure and voltage recovery, and Section 5.5 "Undervoltage protection".

Appropriate measures must be taken to exclude any risk for staff, machines and production goods.

In addition to that, all specific regulations relevant to the application as well all national directives are to be complied with.

When the Autostart function is activated, the operator, in accordance with DIN EN 61800-5-1, shall provide a clear warning/sign in the plant, indicating automatic restart.

The auto start function is suitable for applications which permit a start at mains voltage by their function. By activation of the auto-start function via parameter *Operation Mode* **651**, the frequency inverter accelerates the drive after application of the mains voltage. Control signals STOA and STOB for release and the start command are required as per the regulations. When the motor is switched on, it is accelerated according to the parameterization and the reference value signal.

Operation Mode 651	Function
0 - off	No auto start. The drive is accelerated, after application of the mains voltage, as soon as the release and the start command are present (edge based).
1 - On	The drive is accelerated by the frequency inverter as soon as the mains voltage is applied (level based).

13.5 Search run

The synchronization to a rotating drive is necessary in applications which drive the motor by their behavior or in which the drive is still rotating after an error switch-off. Via *Operation Mode Search Run 645*, the motor speed is synchronized to the current motor speed without an "Overcurrent" error signal. After this, the motor is accelerated to the reference speed at the set acceleration. This synchronization function determines the current rotary frequency of the drive via a search run in operation modes 1 to 5.

The synchronization in operation modes 10 to 15 is accelerated by short test impulses. Torsional frequencies up to 175 Hz are determined within 100 ms to 300 ms. For higher frequencies, a wrong frequency is determined and the synchronization fails. In the "Quick synchronization" operation modes, the search run cannot determine whether a synchronization attempt has failed.

For operation of a synchronous motor, the flux direction can be determined in order to prevent alignment of the motor shaft (jerking) during start-up. Determining the flux direction takes approx. 20 ms. In this process, there are short torque pulses. This method is not suitable for very dynamic drives since the torque pulses result in a rotation of the drive and consequently in wrong measurements. Once the flux direction has been determined, the flux is built up (parameters *Min. Flux-Formation Time 779*, *Max. Flux-Formation Time 780*, *Current during Flux-Formation 781*) in order to improve the starting behavior.

Operation Mode 645	Function
0 - off	The synchronization to a rotating drive is deactivated.
1 - Search Dir. acc. to Preset Val., DCB	The search direction is defined by the sign of the setpoint. If a positive setpoint (clockwise field of rotation) is entered, the search is in a positive direction (clockwise field of rotation), with a negative setpoint, the search is in a negative direction (anticlockwise field of rotation).
2 - First clockw. then anticlockw., DCB	The first attempt is to synchronize to the drive in positive direction (clockwise field of rotation). If this attempt fails, it is tried to synchronize to the drive in negative direction (anticlockwise field of rotation).
3 - First anticlockw. then clockw., DCB	The first attempt is to synchronize to the drive in negative direction (anticlockwise field of rotation). If this attempt fails, it is tried to synchronize to the drive in positive direction (clockwise field of rotation).
4 - Clockw. only, DCB	Synchronization to the drive is only done in positive direction (clockwise field of rotation).
5 - Anticlockw. only, DCB	Synchronization to the drive is only done in negative direction (anticlockwise field of rotation).
10 - Quick Synchronisation	An attempt is made to synchronize to the drive in positive direction (clockwise field of rotation) and in negative direction (anticlockwise field of rotation).
11 - Quick Synch. acc. to Preset Value	The search direction is defined by the sign of the setpoint. If a positive setpoint (clockwise field of rotation) is entered, the search is in a positive direction (clockwise field of rotation), with a negative setpoint, the search is in a negative direction (anticlockwise field of rotation).
14 - Quick Sync., Clockwise Only	Synchronization to the drive is only done in positive direction (clockwise field of rotation).
15 - Quick Sync., Anti-clockwise Only	Synchronization to the drive is only done in negative direction (anticlockwise field of rotation).

Operation modes 1, 4 and 5 define a direction of rotation for the search run and avoid a deviating direction. The search run can accelerate drives by checking the rotary frequency if the drives have a

low moment of inertia and/or a small load moment.

In operation modes 10 to 15, it cannot be ruled out that a wrong direction of rotation is determined in quick synchronization. For example, a frequency not equal to zero may be determined although the drive is at a standstill. If there is no overcurrent, the drive is accelerated accordingly. The direction of rotation is defined in operation modes 11, 14 and 15.

The synchronization changes the parameterized starting behavior of the selected configuration. First, the start command activates the search run in order to determine the rotary frequency of the drive. In operation modes 1 to 5, the *Current / Rated Motor Current* **647** is used for synchronization as a percentage of *Rated Current* **371**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
647	Current / Rated Motor Current	1.00 %	100.00 %	70.00 %

The sensorless control is extended for the search run by a compensated proportional regulator, which regulates the parameterized *Current / Rated Motor Current* **647**. The proportional and integrating part of the current controller can be set via parameters *Amplification* **648** and *Integral Time* **649**. The control functions can be deactivated by setting the parameters to 0.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
648	Amplification	0.00	10.00	1.00
649	Integral Time	0 ms	1000 ms	20 ms

If the *Operation Mode Synchronisation* **645** parameter was set to operation mode 1 to 5 (search run), the search run is not started before the *Demagnetizing Time* **633** has elapsed.

If synchronization to the drive mechanism is not possible, the *Braking Current* **631** is impressed into the motor in operation modes 1 to 5 for the duration of the *Brak. Time after Search Run* **646**. The impression of the direct current set in the parameters of the direct current brake leads to a heating of the motor and should only be done for a short period in internally ventilated motors

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
646	Brak. time after search run	0.0 s	200.0 s	10.0 s

NOTICE

The search run function is designed for operation with motors without brake. Brake motors may not be operated perfectly with the search run function (depending on parameterization and brake control).

13.6 Positioning

Positioning is done in operation mode "Reference positioning" via the definition of the positioning distance or in operation mode "Axis positioning" via the definition of the position angle.

Reference positioning uses a digital reference signal from a selectable signal source for positioning the drive independent of the speed.

Axis positioning uses a digital reference signal from a speed sensor.

The function "Reference positioning" is available in configurations 110, 210, 410, 510 and 610 and is activated by selecting operation mode 1 for parameter *Operation Mode* **458**.

The function "Axis positioning" is available in configurations 210 and 510 (Parameter *Configuration* **30**) and is activated by selecting operation mode 2 for parameter *Operation Mode* **458**.

Operation Mode 458	Function
0 - off	Positioning switched off.
1 - Reference positioning	Positioning from reference point via definition of positioning distance (rotations). The reference point is acquired via a <i>Signal source</i> 459 Available in configurations 110, 210, 410, 510, 610.
2 - Axle Positioning	Reference positioning via definition of the positioning angle, reference signal from speed sensor Available in configurations 210, 510.

13.6.1 Reference Positioning

The feedback of the current position is referred to the revolutions of the motors relative to the time of the reference signal. The accuracy of the positioning for the application to be realized is dependent on the current *Actual Frequency* **241**, *Deceleration (Clockwise)* **421**, the *No. of Pole Pairs* **373**, the selected *Positioning distance* **460** and the parameterized control behavior.

The distance between the reference point and the required position is to be defined in motor revolutions. The calculation of the distance covered is done with the selected *Positioning distance* **460** according to the application.

The setting 0.000 U for *Positioning distance* **460** causes an immediate stop of the drive according to the selected stopping behavior for *Operation Mode* **630**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
460	Positioning distance	0.000 U	1000000.000 U	0.000 U

The actual value parameter *Rotations* **470** facilitates the setting and optimization of the function. The revolutions of the motor displayed should correspond to the *Positioning distance* **460** at the required position.

The minimum number of revolutions needed until the required position is reached depends on the *Actual Frequency* **241** and *Deceleration (Clockwise)* **421** (or *Deceleration Anticlockwise* **423**) as well as the *No. of Pole Pairs* **373** of the motor.

$$U_{\min} = \frac{f^2}{2 \cdot a \cdot p}$$

U_{\min} = min. number of rotations
 f = *Actual Frequency* **241**
 a = *Deceleration* **421 (423)**
 p = *No. of Pole Pairs* **373** of motor

Example: $f = 20 \text{ Hz}$, $a = 5 \text{ Hz/s}$, $p = 2 \Rightarrow U_{\min} = 20$

With an actual frequency of 20 Hz and a delay of 5 Hz/s, at least 20 rotations are needed until standstill at the required position. This is the minimum value for the *Positioning distance* **460**, a shorter positioning distance is not possible. If the number of rotations until the required position is reached is to be lower, the frequency must be reduced, the deceleration increased, or the reference point must be shifted.

The digital signal for registration of the reference point and the logical assignment are to be chosen from a selection of *Signal source* **459**. The link of the digital inputs S2IND, S3IND and S6IND to further functions is to be checked according to selected *Configuration* **30** (e. g. in configurations 110 and 210, digital input S2IND is linked to the function "Start of clockwise operation").

The signals for positioning and a stopping behavior should not be assigned to the same digital input.

Signal source 459	Function
2 - S2IND, neg. edge	The positioning starts with the change of the logic signal from 1 (HIGH) to 0 (LOW) at the reference point.
3 - S3IND, neg. edge	
6 - S6IND, neg. edge	
1x - SxIND, pos. edge	The positioning starts with the change of the logic signal from 0 (LOW) to 1 (HIGH)
2x - SxIND, pos./neg. edge	The positioning begins with the change of the logic signal

The registration of the reference position via a digital signal can be influenced by a variable dead time while the control command is read and processed. The signal running time is compensated by a positive figure for the *Signal correction* **461**. The setting of a negative signal correction decelerates the processing of the digital signal.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
461	Signal correction	-327.68 ms	+327.67 ms	0.00 ms

The influences on the positioning which depend on the operating point can be corrected empirically via the *Load correction* **462** parameter. If the required position is not reached, the deceleration duration is increased by a positive load correction value. The distance between the reference point and the required position is extended. Negative values accelerate the braking process and reduce the positioning distance. The limit of the negative signal correction results from the application and the *Positioning distance* **460**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
462	Load correction	-32768	+32767	0

The behavior of the positioning after the required position of the drive is reached can be defined via the *Activity after positioning* **463** parameter.

Activity after positioning 463	Function
0 - End of positioning	The drive is stopped with the stopping behavior of <i>Operation Mode</i> 630 .
1 - Wait for positioning signal	The drive is stopped until the next signal edge; with a new edge of the position signal, it is accelerated in the previous direction of rotation.
2 - Reversal by new edge	The drive is held until the next signal edge; with a new edge of the position signal, it is accelerated in the opposite direction of rotation.
3 - Positioning; off	The drive is stopped and the power output stage of the inverter is switched off.
4 - Start by time control	The drive is stopped for the <i>Time to wait</i> 464 ; after the waiting time, it is accelerated in the previous direction of rotation.
5 - Reversal by time control	The drive is held for the <i>Time to wait</i> 464 ; after the waiting time, it is accelerated in the opposite direction of rotation.


The position reached can be maintained for the *Time to wait* **464**, then the drive is accelerated according to operation mode 4 or 5.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
464	Delay	0 ms	3600000 ms	0 ms

Positioning, Operation Mode 458 = 1

The diagram shows how the positioning to the set positioning distance is effected. The positioning distance remains constant at different frequency values. At the reference point, the position signal S_{Posi} is generated. Starting from frequency f_{max} the positioning is effected at the set *Deceleration (Clockwise)* **421**. At a lower frequency value f_1 , the frequency remains constant for some time before the drive is stopped at the set deceleration.

If, during acceleration or deceleration of the machine, positioning is started by the signal S_{Posi} , the frequency at the time of the positioning signal is maintained.



Examples of reference positioning as a function of the parameter settings selected.

The reference point is registered according to parameter *Signal source* **459** in operation mode 16–S6IND, pos. edge by a signal on digital input 6.

The *Positioning distance* **460** with parameter value 0.000U (default) defines a direct stop of the drive with the deceleration behavior selected in parameter *Operation Mode* **630**, and the set *Deceleration (Clockwise)* **421**. If a *Positioning distance* **460** is set, positioning is done at the set deceleration.

The *Signal correction* **461** of the signal run time from the measurement point to the frequency inverter is not used if it is set to 0ms.

The *Load correction* **462** can compensate a faulty positioning by the load behavior. By default, this function is deactivated, i.e. set to 0.

The *Activity after positioning* **463** is defined by operation mode 0–End positioning.

The *Time to wait* **464** is not considered because operation mode 0 is selected for parameter *Activity after positioning* **463**.

The actual value *Rotations* **470** enables a direct comparison with the required *Positioning distance* **460**. In the case of deviations, a *Signal correction* **461** or *Load correction* **462** can be performed.

13.6.2 Axle Positioning

For axle positioning, a speed feedback system is required. In most cases, an additional extension module is required for evaluation. The operation mode for parameter *Operation Mode Speed Sensor 2* **493** is to be set to 1004 or 1104. For information on how to set the parameter, refer to the instructions on the optional extension module. The positioning is started if a start signal is received and the frequency drops below an adjustable frequency limit. The machine stops with the selected stopping behavior at the entered position angle.

To ensure the correct function of the axis positioning, the speed controller should be optimized after the guided commissioning. This is described in chapter "Speed controller".

Via parameter *Reference orientation* **469**, the angle between the reference point and the required position is entered.

If this value is changed while the machine is at a standstill, the positioning operation is carried out again at a frequency of 0.5 Hz. For this, a stopping behavior must be selected for the parameter *Operation Mode* **630** which impresses a starting current either permanently when the drive is at a standstill or for the stopping time (refer to chapter "13.2 "13.2").

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
469	Reference orientation	0.0°	359.9°	0.0°

WARNING



During the positioning operation, the direction of rotation of the drive may change, regardless of whether the command Start clockwise or Start anticlockwise was activated.

Make sure that the change of the direction of rotation cannot result in any personal or material damage.

The positioning is started by a start command from a signal source (e.g. digital input), which must be assigned to parameter *Start Positioning of Axle* **37**. The signal source can be selected from the operation modes for digital inputs described in chapter "".

The positioning starts on condition that the *Actual Frequency* **241** of the output signal is smaller than the value entered in parameter *Positioning Frequency* **471**. Due to a stopping behavior, the actual frequency drops below the positioning frequency.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
471	Positioning Frequency	1.00 Hz	50.00 Hz	50.00 Hz

Via parameter *Max. positional error* **472**, the permissible max. deviation from the *Reference orientation* **469** can be set.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
472	Max positional error	0.1°	90.0°	3.0°

Via parameter *time constant positioning contr.* **479**, the time constant for controlling the positional error can be set. The value of the time constant should be increased if oscillations of the drive around the reference orientation occur during the positioning.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
479	time constant positioning contr.	1.00 ms	9999.99 ms	20.00 ms

To make sure that the set position is maintained if a load torque is applied, a stopping behavior should be selected for parameter *Operation Mode* **630** which impresses a starting current either permanently when the drive is at a standstill or for the stopping time.

The status message "60-Target Position Reached" which is displayed when the reference orientation is reached can be assigned to a digital output. The message is output on the following conditions: Operation Mode 2 (axle positioning) for parameter *Operation Mode* **458** is selected.

The controller enable signal at digital inputs S1IND/STOA and S7IND/STOB is switched on.

Enable axis positioning **37** is activated.

The speed sensor monitoring is activated, i. e. operation mode 2 (error message) is selected for parameter *Operation Mode* **760**.

Operation mode 1004 or 1104 (quadruple evaluation with reference impulse) is selected for the speed sensor input.

The Actual Frequency **241** is smaller than Hz.

The deviation of the current position from the reference orientation is smaller than the *Max. positional error* **472**.

The current position after *Start Positioning of Axle 37* is recognized by the frequency inverter as follows:

During commissioning, after switching on the frequency inverter, a search mode is performed for 3 rotations at a rotational frequency of 1 Hz in order to detect the reference signal. As soon as the reference signal was recognized twice, the drive is positioned to the *Reference orientation 469*.

When a resolver is used, search mode will not be used during commissioning.

If the motor was already rotating before axis positioning was enabled, the positioning to the *Reference orientation 469* is performed without search mode because the position of the reference point was already detected by the frequency inverter.

If the positioning is carried out, after controller enabling and start command, when the motor is at a standstill:

The motor is positioned clockwise to the reference orientation if the value for the reference orientation is higher than the value adjusted before.

The motor is positioned anticlockwise to the reference orientation if the value for the reference orientation is smaller than the value adjusted before.

The sense of rotation during the positioning is independent of whether Start Clockwise or Start Anticlockwise was activated.

The time required until the reference orientation is reached depends on:

- Actual Frequency
- Frequency ramp for deceleration
- Rotational angle to reference orientation
- Max positional error
- time constant positioning contr.

14 Error behavior and warning behavior

Operation of the frequency inverter and the connected load are monitored continuously. The monitoring functions are to be parameterized with the corresponding limit values specific to the application. If the limits were set below the switch-off limit of the frequency inverter, an error switch-off can be prevented by suitable measures if a warning message is issued.

The warning message is displayed by the LED's and can be read out on the operating unit via parameter *Warnings* **269** or output via one of the digital control outputs.

14.1 Overload Ixt

The admissible load behavior depends on various technical data of the frequency inverters and the ambient conditions.

The selected *Switching Frequency* **400** defines the rated current and the available overload for one second and sixty seconds, respectively. *The Warning Limit Short Term Ixt* **405** and *Warning Limit Long Term Ixt* **406** are to be parameterized accordingly.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
405	Warning Limit Short Term Ixt	6%	100%	80%
406	Warning Limit Long Term Ixt	6%	100%	80%

Output signals

Reaching of warning limits is reported via digital signals.

165 -	Warning Ixt	¹⁾	<i>Warning Limit Short Term Ixt</i> 405 or
7 -	Ixt warning	²⁾	<i>Warning Limit Long Term Ixt</i> 406 was reached.

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.

14.2 Temperature

The ambient conditions and the energy dissipation at the current operating point result in the frequency inverter heating up. In order to avoid a fault switch-off of the frequency inverter, the *Warning Limit Inside Temp.* **407** for the heat sink temperature and *the Warning Limit Heat Sink Temp.* **408** as an internal temperature limit are to be parameterized. The temperature value at which a warning message is output is calculated from the type-dependent temperature limit minus the adjusted warning limit.

The switch-off limit of the frequency inverter for the maximum temperature is an internal temperature of 65 °C and a heat sink temperature of 80°C – 90°C.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
407	Warning Limit Heat Sink Temp.	-25 °C	0 °C	-5 °C
408	Warning Limit Inside Temp.	-25 °C	0 °C	-5 °C



Minimum temperatures are defined as -10 °C (interior) and 30 °C for the heat sink temperature.

Output signals

Reaching of warning limits is reported via digital signals.

166 - 8 -	Heat sink temperature warning	1) 2)	The value "80 °C minus <i>Warning Limit Heat Sink Temp. 407</i> " was reached.
167 - 9 -	Inside temperature warning	1) 2)	The value "65 °C minus <i>Warning Limit Inside Temp. 408</i> " was reached.
170 - 12 -	Warning overtemperature	1) 2)	The value – "80 °C minus <i>Warning Limit Heat Sink Temp. Tk 407</i> " or – "65 °C minus <i>Warning Limit Inside Temp. Ti 408</i> " was reached.

1) For linking to frequency inverter functions

2) For output via a digital output.

14.3 Controller Status

The intervention of a controller can be indicated via the control unit or LED's. The selected control methods and the matching monitoring functions prevent a switch-off of the frequency inverter. The intervention of the function changes the operating behavior of the application and can be displayed by the status messages with parameter *Controller Status 275*. The limit values and events which result in the intervention by the corresponding controller are described in the corresponding chapters. The behavior during the intervention of a controller is configured with parameter *Controller-Status Message 409*.

Controller-Status Message 409	Function
0 - No message	The intervention of a controller is not reported. The controllers influencing the operating behavior are displayed in the Controller status 275 parameter.
1 – Warning Status	The limitation by a controller is displayed as a warning by the control unit.
11 – Warning status and LED	The limitation by a controller is displayed as a warning by the control unit and the LED's.

Refer to Chapter 16.3.8 "16.3.8" and Chapter 16.3.8 "16.3.8" for a list of controllers and additional controller status evaluation options.

14.4 IDC Compensation Limit

At the output of the frequency inverter a DC component can occur in the output current due to unbalances. This DC voltage component can be compensated by the frequency inverter. The maximum output voltage of the compensation is set with parameter *IDC Compensation Limit 415*. If a higher voltage than the set limit is needed for the compensation of a DC voltage component, error "F1301 IDC COMPENSATION" is triggered.

If this fault occurs, it should be checked whether the load is defective. The voltage limit may have to be increased.

If the parameter *IDC Compensation Limit 415* is reduced to zero, the DC compensation is deactivated.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
415	IDC Compensation Limit	0.0 V	1.5 V	1.5 ¹⁾ 0.0 ²⁾

The factory setting of parameter *IDC Compensation Limit 415* depends on the setting of parameter *Configuration 30* :

¹⁾ Configurations 1xx

²⁾ Configurations 2xx / 4xx / 5xx / 6xx

14.5 Frequency Switch-off Limit

The max. permissible output frequency of the frequency inverter can be set to a low frequency value via parameter *Frequency Switch-off Limit* **417**. If this frequency limit is exceeded by the *Stator Frequency* **210** or the *Actual Frequency* **241**, the frequency inverter is switched off and error signal "F1100" is displayed.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
417	Frequency Switch-off Limit	0.00 Hz	599.00 Hz	599.00 Hz

14.6 Motor temperature

The configuration of the control terminals includes the monitoring of the motor temperature. The monitoring function can be selected via parameter *Motor Temp. Operation Mode* **570**. Integration in the application is improved by an operation mode with delayed shutdown.

Motor Temp. Operation Mode 570	Function
0 - off	Motor temperature monitoring switched off.
1 - Warning only	The critical point of operation is displayed by the control unit and parameter Warnings 269 .
2 - Error switch-off	The fault switch-off is displayed by message F0400. The fault switch-off can be acknowledged via the control unit or the digital input.
3 - Error switch-off 1 min del.	The fault switch-off according to operation mode 2 is delayed by one minute.
4 - Error switch-off 5 min del.	The fault switch-off according to operation mode 2 is delayed by five minutes.
5 - Error switch-off 10 min del.	The fault switch-off according to operation mode 2 is delayed by ten minutes.

Output signals

Warnings are displayed in parameter *Warnings* **269** and output via digital signals.

168 -	Motor temperature	1)	Monitor – selected via <i>Motor Temp. Operation Mode</i> 570 –
10 -	warning	2)	reports critical operating point.

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.

Via parameter *max.Temp. Windings* **617*** you can set the temperature value above which a warning message is output or an error switch-off of the frequency inverter is effected. The operating behavior of the frequency inverter when the value set for *max.Temp. Windings* **617** is exceeded, can be selected via parameter *Motor Temp. Operation Mode* **570**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
617	max.Temp. Windings*	50 °C	200 °C	150 °C

* The parameter is only available if an extension module featuring an input for KTY measuring resistance evaluation, e.g. EM-IO-04, is installed.

Via parameter *Therm. Contact* **204**, a digital input signal can be linked to the *Motor Temp. Operation Mode* **570**.

14.7 Phase failure

If a failure of one of the three motor or mains phases is not noticed, the frequency inverter, the motor and the mechanical drive components may be damaged. In order to prevent these components from being damaged, the phases are monitored for failure. Via parameter *Phase Supervision* **576** the behavior in case of a phase failure can be set.

14.7.1 Settings for sizes 1 to 7

Phase Supervision 576		Function
10 -	Mains: Error switch-off	In the case of a phase failure, the error switch-off takes place after 5 minutes, fault F0703 is displayed. During this time, the warning message A0100 is displayed.
11 -	Mains & Motor: Error switch-off	The phase monitor switches the frequency inverter off: immediately with error message F0403 in the case of a motor phase failure, after 5 minutes with error message F0703 in the case of a mains phase failure.
20 -	Mains: Shutdown	In the case of a mains phase failure, the drive is stopped after five minutes, fault F0703 is displayed.
21 -	Mains & Motor: Shutdown	The drive is stopped: immediately, in the case of a motor phase failure, after 5 minutes in the case of a mains phase failure.

14.8 Automatic acknowledgment of errors/faults

The automatic error acknowledgment enables acknowledgment of the faults Overcurrent F0500, Overcurrent F0507 and Overvoltage F0700 without intervention by an overriding control system or the user. If one of the aforementioned errors occurs, the frequency inverter switches the power semi-conductors off and waits for the time stated with parameter *Restart Delay* **579**. If the error must be acknowledged, the speed of the machine is determined with the quick catching function and synchronized to the rotating machine. The automatic error acknowledgment makes use of "Quick Synchronization" operation mode, regardless of the search run *Operation Mode* **645**. The information given on this function in chapter 13.5 "Search run" must be observed.

With parameter *Allowed No. of Auto-Acknowl.* **578**, you can define the number of automatic error acknowledgments which are permitted within 10 minutes.

An acknowledgment repeated above the permissible number within 10 minutes will result in the frequency inverter being switched off.

The errors Overcurrent F0500, Overcurrent F0507 and Overvoltage F0700 have separate error acknowledgment counters.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
578	Allowed no. of AutoAck.	0	20	5
579	Restart delay	0 ms	1000 ms	20 ms

15 Reference Values

The ACU series frequency inverters can be configured specific to the application and enable customer-specific adaptation of the module hardware and software structure.

15.1 Frequency Limits

The output frequency of the frequency inverter and thus the speed setting range are defined by the parameters *Minimum Frequency* **418** and *Maximum Frequency* **419**. The relevant control methods use the two limit values for scaling and limiting the frequency.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
418	Minimum frequency	0.00 Hz	599.00 Hz	3.50 Hz ¹⁾
				0.00 Hz ²⁾
419	Maximum frequency	0.00 Hz	599.00 Hz	50.00 Hz

The factory settings depend on the setup of parameter *Configuration* **30**:

¹⁾ 3.50 Hz in Configurations 1xx, 4xx; 6xx

²⁾ 0.00 Hz in Configurations 2xx, 5xx

15.2 Slip Frequency

The torque-forming current component and thus the slip frequency of the 3-phase machine depend on the required torque in the case of the field-oriented control methods. The field-oriented control method also includes the parameter *Slip Frequency* **719** to limit the torque in the calculation of the machine model. The rated slip calculated from the rated motor parameters is limited in accordance with the *Slip Frequency* **719** which is parameterized as a percentage.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
719	Slip Frequency	0 %	10000 %	330 %

15.3 Percentage Value Limits

The percentage adjusting range is defined by parameters *Minimum Reference Percentage* **518** and *Maximum Reference Percentage* **519**. The relevant control methods use the two limit values for scaling and limiting of percentages.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
518	Minimum Reference Percentage	0.00 %	300.00 %	0.00 %
519	Maximum Reference Percentage	0.00 %	300.00 %	100.00 %

15.4 Frequency reference channel

The different functions for the defining the reference frequency are connected via the frequency reference value channel. The *Reference Frequency Source* **475** determines the additive assignment of the available reference value sources depending on the hardware installed.

Reference Frequency Source 475	Function
1 - Abs. value analog value MFI1A	Multifunction input 1 in analog <i>Operation Mode</i> 452 is the reference value source.
2 - Abs. Analog Input EM-S1INA ¹⁾	The analog input of the extension module is the reference value source.
4 - Abs. Value MFI1A + EM-S1INA ¹⁾	Combination of operation modes 1 and 2.

10 - Abs. value fixed frequency (FF)	Fixed frequency according to <i>Fixed Frequency Change-Over 1</i> 66 and <i>Fixed Frequency Change-Over 2</i> 67 as well as the current data set.
11 - Abs. value MFI1A + FF	Combination of operation modes 10 and 1.
12 - Abs. Value EM-S1INA + FF ¹⁾	Combination of operation modes 10 and 2.
14 - Abs. Value MFI1A + EM-S1INA+FF ¹⁾	Combination of operation modes 10, 1 and 2.
20 - Abs. value Motorpoti (MP)	Reference value source: Function <i>Frequency Motorpoti Up</i> 62 and <i>Frequency Motorpot. Down</i> 63
21 - Abs. value MFI1A + MP	Combination of operation modes 20 and 1.
22 - Abs. Value EM-S1INA + MP ¹⁾	Combination of operation modes 20 and 2.
24 - Abs. Value MFI1A + EM-S1INA + MP ¹⁾	Combination of operation modes 20, 1 and 2.
30 - Abs.Val. Speed Sensor 1 (F1)	The frequency signals in <i>Operation Mode</i> 490 are evaluated as a reference value.
31 - Abs. value MFI1A + F1	Combination of operation modes 30 and 1.
32 - Abs. Val. Rep. Freq./PWM Inp. (F3)	The frequency signal on the digital input according to <i>Operation Mode</i> 496 for the PWM/repetition frequency input.
33 - Abs. value MFI1A + F3	Combination of operation modes 1 and 32.
34 - Abs.Val. Speed Sensor 2 (F2) ²⁾	The frequency signals of speed sensor 2 are evaluated as a reference value.
35 - Abs. value MFI1A + F2	Combination of operation modes 1 and 35.
40 - Abs. value Motorpoti (KP)	KP 500 is the reference value source, with keys ▲ for increasing the frequency and ▼ for reducing the frequency.
41 - Abs. value MFI1A + KP	Combination of operation modes 40 and 1.
42 - Abs. Value EM-S1INA + KP ¹⁾	Combination of operation modes 40 and 2.
44 - Abs. Value MFI1A + EM-S1INA + KP ¹⁾	Combination of operation modes 40, 1 and 2.
80 - Abs. value MFI1A + FF + KP + F3 + (EM-S1INA) ¹⁾	Combination of operation modes 1, 10, 40, 32 and 2. ¹⁾
81 - Abs. value MFI1A + FF + KP + F1 + F3 + (EM-S1INA) ¹⁾	Combination of operation modes 1, 10, 40, 30, 32 and 2. ¹⁾
82 - Abs. value MFI1A + FF + KP + F3 + (F2) ²⁾ + (EM-S1INA) ¹⁾	Combination of op. modes 1, 10, 40, 32, 34 ²⁾ and 2. ¹⁾
89 - Abs. value MFI1A + FF + KP + F1 + F3 + (F2) ²⁾ + (EM-S1INA) ¹⁾	Combination of op. modes 1, 10, 40, 30, 32, 34 ²⁾ and 2. ¹⁾
90 - Abs. value MFI1A + FF + MP + F3 + (EM-S1INA) ¹⁾	Combination of operation modes 1, 10, 20, 32 and 2. ¹⁾
91 - Abs. value MFI1A + FF + MP + F1 + F3 + (EM-S1INA) ¹⁾	Combination of operation modes 1, 10, 20, 30, 32 and 2. ¹⁾
92 - Abs. value MFI1A + FF + MP + F3 + (F2) ²⁾ + (EM-S1INA) ¹⁾	Combination of the operation modes 1, 10, 20, 32 (+ absolute amount speed sensor 2 (F2)) ²⁾ (+ analog input extension module). ¹⁾
99 - Abs. value MFI1A + FF + MP + F1 + F3 + (F2) ²⁾ + (EM-S1INA) ¹⁾	Combination of operation modes 1, 10, 20, 30, 33, 32 ²⁾ and 2. ¹⁾
101 to 199	Operation modes with signs (+/-).


¹⁾ The reference value source is only available if an extension module with analog input is connected. For information, refer to the extension module operating instructions.

²⁾ The reference value source is only available if an extension module with speed sensor input is connected. For information, refer to the extension module operating instructions.

15.4.1 Block diagram

The following table describes the software switches shown in the circuit diagram as a function of the selected *Reference Frequency Source* **475**.

Switch position on circuit diagram									
Operation Mode	MF11A	FF	MP	F1	F3	KP	EM-S11NA	F2	Sign
1	1								Abs. value
10		1							Abs. value
11	1	1							Abs. value
12		1					1		Abs. value
14	1	1					1		Abs. value
20			1						Abs. value
21	1		1						Abs. value
22			1				1		Abs. value
24	1		1				1		Abs. value
30				1					Abs. value
31	1			1					Abs. value
32					1				Abs. value
33	1				1				Abs. value
34								1	Abs. value
35	1							1	Abs. value
40						1			Abs. value
41	1					1			Abs. value
42						1	1		Abs. value
44	1					1	1		Abs. value
80	1	1			1	1	1		Abs. value
81	1	1		1	1	1	1		Abs. value
82	1	1			1	1	1	1	Abs. value
89	1	1		1	1	1	1	1	Abs. value
90	1	1	1		1		1		Abs. value
91	1	1	1	1	1		1		Abs. value
92	1	1	1		1		1	1	Abs. value
99	1	1	1	1	1		1	1	Abs. value
101...199	Operation modes 1...99 with sign (+/-).								+/-



15.5 Reference percentage channel

The reference percentage channel combines various signal sources for definition of the reference figures. The percentage scaling facilitates integration into the application, taking various process parameters into account.

The *Reference Percentage Source* **476** determines the additive assignment of the available reference value sources depending on the hardware installed.

Reference Percentage Source 476	Function
1 - Abs. value analog value MFI1A	Multifunction input 1 in analog Operation Mode 452 is the reference value source.
2 - Abs. value EM-S1INA ¹⁾	Analog input of EM-S1INA is the reference value source.
4 - Abs. value MFI1 + EM-S1INA ¹⁾	Combination of operation modes 1 and 2.
10 - Abs. value fixed percentage value (FP)	The percentage according to Fixed Percent Change-Over 1 75 , Fixed Percent Change-Over 2 76 and the current data set
11 - Abs. value MFI1A + FP	Combination of operation modes 1 and 10.
12 - Abs. value EM-S1INA + FP ¹⁾	Combination of operation modes 2 and 10.
14 - Abs. value MFI1 + EM-S1INA + FP ¹⁾	Combination of operation modes 1.2 and 10.
20 - Abs. value Motorpoti (MP)	Reference value source: Function Percent Motorpoti Up 72 and Percent Motorpoti Down 73
21 - Abs. value MFI1A + MP	Combination of operation modes 1 and 20.
22 - Abs. value EM-S1INA + MP ¹⁾	Combination of operation modes 2 and 20.
24 - Abs. value MFI1 + EM-S1INA + FP	Combination of operation modes 1.2 and 20.
32 - Abs. value Rep. Freq./PWM Inp. (F3)	The frequency signal on the digital input according to Operation Mode 496 for the PWM/repetition frequency input.
33 - Abs. value MFI1A + F3	Combination of operation modes 1 and 32.
90 - Abs. value MFI1A + FP + MP + F3 (+ EM-S1INA) ¹⁾	Combination of the operation modes 1, 10, 20, 32 (+ analog input of an extension module) ¹⁾
95 - Abs. value Obj. 0x6071 Target Torque	Reference value source: CANopen Object 0x6071.
96 - Abs. value Profibus OUT-PZD3	Reference value source: Profibus OUT-PZD3.
99 - Abs. value FT outp. percentage 1	Reference value source: Output of function table FT-Output Percentage 1.
101 to 199	Operation modes with signs (+/-).


¹⁾ The reference value source is only available if an optional extension module with analog input is connected. For information, refer to the extension module operating instructions.

15.5.1 Block diagram

The following table describes the software switches shown in the circuit diagram as a function of the selected *Reference Percentage Source* **476**.

Switch position on circuit diagram						
Operation Mode	MFI1A	FP	MP	F3	EM-S1INA	Sign
1	1					Abs. value
2					1	Abs. value
4	1				1	Abs. value
10		1				Abs. value
11	1	1				Abs. value
12		1			1	Abs. value
14	1	1			1	Abs. value
20			1			Abs. value
21	1		1			Abs. value
22			1		1	Abs. value
24	1		1		1	Abs. value
32				1		Abs. value
33	1			1		Abs. value
90	1	1	1	1		Abs. value
95	CANopen Object 0x6071					Abs. value
96	Profibus OUT-PZD3					Abs. value
99	Output FT output percentage 1					Abs. value
101...199	Operation modes 1...99 with sign (+/-)					+/-

Circuit diagram of percent reference value channel



15.6 Fixed reference values

The fixed reference values are to be parameterized as fixed frequencies or fixed percentages according to the configuration and function.

The signs of the fixed reference values determine the direction of rotation. A positive sign means a clockwise rotation, a negative sign means an anticlockwise rotation. The direction can only be changed via the sign if the *Reference Frequency Source* **475** or *Reference Percentage Source* **476** is parameterized to an operation mode with sign (+/-). The direction of rotation can also be stated with the digital signal sources assigned to the parameters *Start Clockwise* **68** and *Start Anticlockwise* **69**.

The fixed reference values are to be parameterized in four data sets and are assigned to further sources via the reference value channel. The use of the functions *Data Set Change-Over 1* **70** and *Data Set Change-Over 2* **71** thus enables the setting of 16 fixed reference values.

15.6.1 Fixed frequencies

The four fixed frequencies define reference values which are selected via the *Fixed Frequency Change-Over 1* **66** and *Fixed Frequency Change-Over 2* **67**. The *Reference Frequency Source* **475** defines the addition of the various sources in the reference frequency channel.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
480	Fixed Frequency 1	-599.00 Hz	599.00 Hz	0.00 Hz
481	Fixed Frequency 2	-599.00 Hz	599.00 Hz	10.00 Hz
482	Fixed Frequency 3	-599.00 Hz	599.00 Hz	25.00 Hz
483	Fixed Frequency 4	-599.00 Hz	599.00 Hz	50.00 Hz

By combining the logic states of the fixed frequency change-over modes 1 and 2, fixed frequencies 1 through 4 can be selected:

Selection of fixed frequencies		
<i>Fixed Frequency Change-Over 1</i> 66	<i>Fixed Frequency Change-Over 2</i> 67	Function/active fixed value
0	0	<i>Fixed Frequency 1</i> 480
1	0	<i>Fixed Frequency 2</i> 481
1	1	<i>Fixed Frequency 3</i> 482
0	1	<i>Fixed Frequency 4</i> 483

0 = Contact open

1 = Contact closed



Additional fixed frequencies can be selected if an optional extension module featuring digital inputs is installed. In this case, follow the instructions on the optional extension module.

15.6.2 JOG frequency

The JOG function forms part of the functions for controlling the drive mechanism via the control unit. Use the arrow keys to change the JOG frequency within the function. The frequency of the output signal is set to the entered value if the FUN key is pressed. The drive starts and the machine turns at the set *JOG-Frequency* **489**. If the JOG frequency has been changed using the arrow keys, this value is stored.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
489	JOG frequency	-599.00 Hz	599.00 Hz	5.00 Hz

15.6.3 Fixed percentages

The four fixed percentages define reference values which are selected via the *Fixed Percent Change-Over 1* **75** and *Fixed Percent Change-Over 2* **76**. The *Reference Percentage Source* **476** defines the addition of the various sources in the reference frequency channel.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
520	Fixed Percentage 1	-300.00 %	300.00 %	0.00 %
521	Fixed Percentage 2	-300.00 %	300.00 %	20.00 %
522	Fixed Percentage 3	-300.00 %	300.00 %	50.00 %
523	Fixed Percentage 4	-300.00 %	300.00 %	100.00 %

By combining the logic states of the fixed percentage change-over modes 1 and 2, fixed percentages 1 through 4 can be selected:

Fixed percentage control		
<i>Fixed Percent Change-Over 1</i> 75	<i>Fixed Percent Change-Over 2</i> 76	Function / active fixed value
0	0	<i>Fixed Percentage 1</i> 520
1	0	<i>Fixed Percentage 2</i> 521
1	1	<i>Fixed Percentage 3</i> 522
0	1	<i>Fixed Percentage 4</i> 523

0 = Contact open 1 = Contact closed

15.7 Frequency ramps

The ramps determine how quickly the frequency value is changed if the reference value changes or after a start, stop or brake command. The maximum admissible ramp gradient can be selected according to the application and the current consumption of the motor.

If the settings of the frequency ramps are identical for both directions of rotation, the parameterization via the parameters *Acceleration (Clockwise)* **420** and *Deceleration (Clockwise)* **421** is sufficient. The values of the frequency ramps are applied to *Acceleration Anticlockwise* **422** and *Deceleration Anticlockwise* **423** if these have been parameterized to the factory setting of - 0.01 Hz/s.

The parameter value of 0.00 Hz/s for the acceleration blocks the corresponding direction of rotation.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
420	Acceleration (Clockwise)	0.00 Hz/s	9999.99 Hz/s	5.00 Hz/s
421	Deceleration (Clockwise)	0.01 Hz/s	9999.99 Hz/s	5.00 Hz/s
422	Acceleration Anticlockwise	- 0.01 Hz/s ¹⁾	9999.99 Hz/s	- 0.01 Hz/s
423	Deceleration Anticlockwise	- 0.01 Hz/s ²⁾	9999.99 Hz/s	- 0.01 Hz/s

¹⁾ Value -0.01 Hz/s means that the value of *Acceleration (Clockwise)* **420** is used.


²⁾ Value -0.01 Hz/s means that the value of *Deceleration (Clockwise)* **421** is used.



Setting 0.00 Hz/s will not accelerate nor decelerate the drive due to the limitation of the ramp.

The ramps for *Emergency Stop Clockwise* **424** and *Emergency Stop Anticlockwise* **425** of the drive to be activated via *Operation Mode* **630** for the stopping behavior must be selected according to the application. The non-linear (S-shaped) course of the ramps is not active in the case of an emergency stop of the drive.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
424	Emergency stop clockwise	0.01 Hz/s	9999.99 Hz/s	5.00 Hz/s
425	Emergency stop anti-clockwise	0.01 Hz/s	9999.99 Hz/s	5.00 Hz/s



The parameter *Maximum Leading* **426** limits the difference between the output of the ramp and the current actual value of the drive. The set maximum deviation is a dead time for the control system which should be kept as low as possible.

In case the drive is loaded heavily and high acceleration and deceleration values are selected it is possible, that a set controller limit is reached while the drive is accelerated or decelerated. In this case, the drive cannot follow the defined acceleration or deceleration ramps. With *Maximum Leading* **426**, you can limit the max. leading of the ramp.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
426	Maximum leading	0.01 Hz	599.00 Hz	5.00 Hz


Example: Fixed value at ramp output = 20 Hz, current actual value of drive = 15 Hz, selected *Maximum Leading* **426** = 5 Hz

The frequency at the ramp output is increased to 15 Hz only, it is not increased further. The difference (leading) between the frequency value at the ramp output and the current actual frequency of the drive is limited to 5 Hz in this way.

The load occurring in a linear acceleration of the drive is reduced by the adjustable modification speeds (S curve). The non-linear course of the frequency is defined as a ramp and states the time range in which the frequency is to be guided to the set ramp. The values set with parameters **420** to **423** are maintained regardless of the selected ramp times.

Setting the ramp rise time to 0 ms deactivates the function S curve and enables the use of the linear ramps. The data set change-over of the parameters within an acceleration phase of the drive mechanism demands the defined take-over of the values. The controller calculates the values required in order to reach the reference value from the ratio of the acceleration to the ramp time and uses it until the acceleration phase is complete. With this method, exceeding the reference values is avoided and a data set change-over between extremely deviating values becomes possible.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
430	Ramp rise time clockwise	0 ms	65000 ms	0 ms
431	Ramp fall time clockwise	0 ms	65000 ms	0 ms
432	Ramp rise time anticlockwise	0 ms	65000 ms	0 ms
433	Ramp rise time anticlockwise	0 ms	65000 ms	0 ms



Example: Calculation of the acceleration time in clockwise rotation with an acceleration from 20 Hz to 50 Hz (f_{max}) and an acceleration ramp of 2 Hz/s for parameter *Acceleration (Clockwise)* **420**. The *Ramp Rise Time Clockwise* **430** is set to 100 ms.

$$t_{aufr} = \frac{\Delta f}{a_r}$$

$$t_{aufr} = \frac{50 \text{ Hz} - 20 \text{ Hz}}{2 \text{ Hz/s}} = 15 \text{ s}$$

$$t_{auf} = t_{aufr} + t_{vr}$$

$$t_{auf} = 15 \text{ s} + 100 \text{ ms} = 15,1 \text{ s}$$

t_{aufr} = acceleration time clockwise rotary field
 Δf = change of frequency acceleration ramp
 a_r = Acceleration Clockwise
 t_{vr} = Ramp Rise Time Clockwise
 t_{auf} = Acceleration time + Ramp rise time

15.8 Percentage Value Ramps

The percentage value ramps scale the change of the reference value (in percent) for the corresponding input function. The acceleration and deceleration of the drive are parameterized via the frequency ramps.

The behavior *Gradient Percentage Ramp* **477** corresponds to a function which takes the time behavior of the drive system into account. If the parameter is set to 0 %/s, this function is deactivated and a direct reference value modification for the following function is obtained.

The default value depends on *Configuration* **30**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
477	Gradient Percentage Ramp	0 %/s	60000 %/s	x %/s


15.9 Blocking frequencies

In certain applications, it is necessary to fade out reference frequencies. In this way, resonance points of the system as stationary operating points are avoided. Parameters *1st Blocking Frequency* **447** and *2nd Blocking Frequency* **448** with parameter *Frequency Hysteresis* **449** define two resonance points.

A blocking frequency is active if the parameter values of the blocking frequency and the frequency hysteresis are not equal to 0.00 Hz.

The area faded out as a stationary working point by the hysteresis is passed through as quickly as possible according to the ramp set. If the output frequency is limited as a result of the selected control parameter settings, e.g. if the current limit is reached, the hysteresis is passed through with a delay. The behavior of the reference value can be determined from its direction of movement according to the following diagram.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
447	1. Block frequency	0.00 Hz	599.00 Hz	0.00 Hz
448	2. Block frequency	0.00 Hz	599.00 Hz	0.00 Hz
449	Frequency hysteresis	0.00 Hz	100.00 Hz	0.00 Hz



15.10 Motor potentiometer

Via the motor potentiometer function, the motor speed is controlled via

- digital control signals (function Motorpoti MP) or via
- the keys of the control unit KP°500 (Function Motorpoti KP).

The control up/down commands are assigned the following functions:

Control				
Motorpoti (MP)		Motorpoti (KP)		Function
Up	Down	Up	Down	
0	0	–	–	Output signal does not change
1	0	▲	–	Output value rises at set ramp
0	1	–	▼	Output value drops at set ramp
1	1	▲ + ▼		Output value is reset to initial value

0 = Contact open 1 = Contact closed

▲ ▼ = Arrow keys on control unit KP 500

The motor potentiometer function and its link to other reference value sources can be selected in the corresponding reference value channels with parameters *Reference Frequency Source* **475** or *Reference Percentage Source* **476**.

For a description of the possible links of the reference value sources, refer to chapters "Reference Values", "Reference Values" and "Reference Values".

Availability of functions "Motorpoti (MP)" and "Motorpoti (KP)" differs in the individual reference value channels:

Reference value channel		
	<i>Reference Frequency Source</i> 475	<i>Reference Percentage Source</i> 476
Motorpoti (MP)	X	X
Motorpoti (KP)	X	0

X = Function available 0 = Function not available

Depending on the active reference value channel, the function is assigned to a digital signal via parameters *Frequency Motorpoti Up* **62**, *Frequency Motorpot. Down* **63** or *Percent Motorpoti Up* **72**, *Percent Motorpoti Down* **73**.

For a summary of available digital signals, refer to chapter "Digital Inputs".

The *Operation Mode* **474** of the motor potentiometer function defines the behavior of the function at various operating points of the frequency inverter.

Operation Mode 474	Function
0 - Not Latching	In the operation mode motor potentiometer Not Latching , the drive goes to the set minimum reference value at each start.
1 - Latching	In the operation mode Latching the motor goes to the reference value selected before the switch-off at the start. The reference value is also stored when the device is switched off.
2 - Taking Over	The operation mode Motorpoti Taking Over is to be used for the data set change-over of the reference value channel. The current reference value is used when the motorpoti function is activated.
3 - Taking Over and Latching	This operation mode combines the behavior in operation mode 1 and 2.

15.10.1 Motorpoti (MP)

Function "Motorpoti (MP)" is to be parameterized via parameter *Reference Frequency Source* **475** or *Reference Percentage Source* **476**.

Reference Frequency Channel

Via the digital control inputs, the required functions *Frequency Motorpoti Up* **62** and *Frequency Motorpoti Down* **63** are triggered.

Limitation of the reference values is effected via parameters *Minimum Frequency* **418** and *Maximum Frequency* **419**.

Reference percentage channel

Via the digital control inputs, the required functions *Percent Motorpoti Up* **72** and *Percent Motorpoti Down* **73** are triggered. Limitation of the reference values is effected via parameters *Minimum Reference Percentage* **518** and *Maximum Reference Percentage* **519**.

15.10.2 Motorpoti (KP)


The function „Motorpoti (KP)“ is only available in the reference frequency channel. The function and its link to other reference value sources can be selected via parameter *Reference Frequency Source* **475**.

Via the keys of the control unit KP 500, the required functions *Frequency Motorpoti Up* **62** and *Frequency Motorpoti Down* **63** are triggered.

Limitation of the reference values is effected via parameters *Minimum Frequency* **418** and *Maximum Frequency* **419**.

Operation as described in Chapter 15.10.3 "15.10.3".

If the function Motorpoti (KP) is activated "inPF" will be displayed for clockwise direction of rotation and "inPr" for anticlockwise direction of rotation.



The keys on the control unit have the following functions:

Key functions	
▲ / ▼	Increase / reduce frequency.
ENT	Reversal of the sense of rotation independent of the control signal on the terminals Clockwise S2IND or Anticlockwise S3IND.
ENT (1 sec)	Save the selected function as default value. The direction of rotation is not changed.
ESC	Cancel function and return to the menu structure.
FUN	Switch from internal reference value inP to JOG-Frequency; drive starts. Release the key to switch to the sub-function and stop the drive.
RUN	Start drive; alternative to control signal S2IND or S3IND.
STOP	Stop drive; alternative to control signal S2IND or S3IND.

15.10.3 Controlling the Motor via the Control Unit

Parameter *Reference Frequency Source* **475** enables linking of the reference sources in the reference frequency channel. The operation modes can be set without the function "Motorpoti (KP)". If an operation mode without „Motorpoti (KP)" is selected, a connected motor can be controlled via the keys of the control unit KP 500.

The function is activated as described in Chapter 15.10.3 "15.10.3".

The speed of the modification of the reference value is limited by parameter *Ramp Keypad-Motorpoti* **473**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
473	Ramp Keypad Motorpoti	0.00 Hz/s	999.99 Hz/s	2.00 Hz/s

15.11 PWM-/repetition frequency input

The use of a PWM (pulse-width modulated) frequency signal completes the various possibilities of the reference value specification. The signal at one of the available digital inputs is evaluated according to the selected *Operation Mode* **496**.

PWM frequencies ranging from 50 Hz to 150 kHz can be evaluated.

Operation Mode 496	Function
0 - off	The PWM signal or repetition frequency are zero.
2 - PWM S2IND, 0 - 100%	PWM signal capture on terminal X210A.4. 0 ... 100% of <i>Maximum Reference Percentage</i> 519 or 0 ... 100% of <i>Maximum Frequency</i> 419 .
3 - PWM S3IND, 0 - 100%	PWM signal capture on terminal X210A.5. 0 ... 100% of <i>Maximum Reference Percentage</i> 519 or 0 ... 100% of <i>Maximum Frequency</i> 419 .
6 - PWM S6IND, 0 - 100%	PWM signal capture on terminal X210B.1. 0 ... 100% of <i>Maximum Reference Percentage</i> 519 or 0 ... 100% of <i>Maximum Frequency</i> 419 .
12 - PWM S2IND, -100 - 100%	PWM signal capture on terminal X210A.4. -100 ... 100% of <i>Maximum Reference Percentage</i> 519 or -100 ... 100% of <i>Maximum Frequency</i> 419 .
13 - PWM S3IND, -100 - 100%	PWM signal capture on terminal X210A.5. -100 ... 100% of <i>Maximum Reference Percentage</i> 519 or -100 ... 100% of <i>Maximum Frequency</i> 419 .
16 - PWM S6IND, -100 - 100%	PWM signal capture on terminal X210B.1. -100 ... 100% of <i>Maximum Reference Percentage</i> 519 or -100 ... 100% of <i>Maximum Frequency</i> 419 .
21 - S2IND Single Evaluation Pos.	Repetition Frequency Input at terminal X210A.4. One edge of the frequency signal is evaluated with a positive sign.
22 - S2IND Double evaluation pos.	Repetition Frequency Input at terminal X210A.4. Both edges of the frequency signal are evaluated with a positive sign.
31 - S3IND Single Evaluation Pos.	Repetition Frequency Input at terminal X210A.5. One edge of the frequency signal is evaluated with a positive sign.
32 - S3IND Double evaluation pos.	Repetition Frequency Input at terminal X210A.5. Both edges of the frequency signal are evaluated with a positive sign.
61 - S6IND Single Evaluation Pos.	Repetition Frequency Input at terminal X210B.1. One edge of the frequency signal is evaluated with a positive sign.
62 - S6IND Double evaluation pos.	Repetition Frequency Input at terminal X210B.1. Both edges of the frequency signal are evaluated with a positive sign.
121 to 162	Repetition Frequency Input. Operation modes 21 to 62 with evaluation of the frequency signal, but with a negative sign.



If a digital input is configured as a PWM or repetition frequency input, this input cannot be used for other functions.

Check the link of the digital inputs to other functions.

The signal frequency at the selected repetition frequency input can be scaled via the parameter **Divider 497**. The parameter value can be compared to the number of division marks of an encoder per rotation of the drive. The frequency limit of the parameterized digital input is to be taken into account for the frequency of the input signal.


Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
497	Divider	1	8192	1024



The reference value specification within the different functions enables the use of the repetition frequency signal as a percentage figure. A signal frequency of 100 Hz at the repetition frequency input corresponds to 100%, 1 Hz corresponds to 1%. The parameter **Divider 497** is to be used in a way comparable with the speed sensor simulation.

Via parameters **Offset 652** and **Amplification 653** the PWM input signal can be adjusted for the application.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
652	Offset	-100.00%	100.00%	0.00%
653	Amplification	5.0%	1000.0%	100.0%



$$\text{PWM-Value} = \text{Offset } 652 + \left(\frac{T_{on}}{T_{ges}} [\%] \times \text{Amplification } 653 \right)$$

For definition of reference values, the following settings are possible:

- For reference frequencies:
Reference Frequency Source 475 = "32 - Abs. value/PWM Inp. (F3)". The PWM-value for the signal is referred to *Maximum Frequency 419*.
- For reference percentages:
Reference Percentage Source 476 = "32 - Abs. value/PWM Inp. (F3)". The PWM-value for the signal is referred to *Maximum Reference Percentage 519*.

The actual value of the PWM input is shown in parameter *PWM-Input 258*.

16 Control inputs and outputs

The modular structure of the frequency inverters enables a wide spectrum of applications on the basis of the available hardware and software functionality. The control inputs and outputs of terminals X210A and X210B described in the following can be linked to software modules freely via the described parameters.

16.1 Multifunction input MFI1

Multifunction input MFI1 can be configured as a voltage, current or a digital input. Depending on the selected *Operation Mode* **452** for the multifunction input, a link to various functions of the software is possible. The unused operation modes are assigned the signal value 0 (LOW).

Operation Mode 452	Function
1 - Voltage Input	voltage signal (MFI1A), 0 V ... 10 V
2 - Current Input	current signal (MFI1A), 0 mA ... 20 mA
3 - Digital input	digital signal (MFI1D), 0 V ... 24 V



The sampling rate of multi-function input MFI1D is slower than that of digital signals S1IND, S2IND, etc. For this reason, this input should only be used for signals which are not time-critical.

16.1.1 Analog Input MFI1A

Multifunction input MFI1 is configured by default for an analog reference value source with a voltage signal of 0V to 10V.

Alternatively, you can select the operation mode for an analog current signal of 0 mA to 20 mA. The current signal is continuously monitored and the error signal "F1407" displayed if the maximum figure is exceeded.

16.1.1.1 Characteristic

Mapping of the analog input signal onto a reference frequency value or a reference percentage value is possible for various requirements. Parameterization can be done via two points of the linear characteristic of the reference value channel.

Point 1 with coordinates X1 and Y1 and point 2 with coordinates X2 and Y2 can be set in four data sets.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
454	Point X1	0.00 %	100.00 %	2.00 %
455	Point Y1	-100.00 %	100.00 %	0.00 %
456	Point X2	0.00 %	100.00 %	98.00 %
457	Point Y2	-100.00 %	100.00 %	100.00 %


The coordinates of the points relate, as a percentage, to the analog signal with 10 V or 20 mA and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The direction of rotation can be changed via the digital inputs and/or by selection of the points.



WARNING

The monitoring of the analog input signal via the parameter *Error/Warning Behavior* **453** demands the examination of the parameter *Point X1* **454**

The following characteristic is set by default and can be adapted to the application via the parameters mentioned.



Point 1:

$$X1 = 2,00\% \cdot 10 \text{ V} = 0,20 \text{ V}$$

$$Y1 = 0,00\% \cdot 50,00 \text{ Hz} = 0,00 \text{ Hz}$$


Point 2:

$$X2 = 98,00\% \cdot 10 \text{ V} = 9,80 \text{ V}$$

$$Y2 = 100,00\% \cdot 50,00 \text{ Hz} = 50,00 \text{ Hz}$$

The freely configurable characteristic enables setting a tolerance at the ends as well as a reversal of the direction of rotation.

The following example shows the inverse reference value specification with additional reversal of the direction of rotation. This is often used in pressure control systems.



Point 1:

$$X1 = 2,00\% \cdot 10 \text{ V} = 0,20 \text{ V}$$

$$Y1 = 100,00\% \cdot 50,00 \text{ Hz} = 50,00 \text{ Hz}$$

Point 2:

$$X2 = 98,00\% \cdot 10 \text{ V} = 9,80 \text{ V}$$

$$Y2 = -80,00\% \cdot 50,00 \text{ Hz} = -40,00 \text{ Hz}$$

The change of direction of rotation is done in this example at an analog input signal of 5.5 V. pos./neg. maximum figure

The definition of the analog input characteristic can be calculated via the two-point form of the line equation. The speed Y of the drive is controlled according to the analog control signal X.

$$Y = \frac{Y2 - Y1}{X2 - X1} \cdot (X - X1) + Y1$$

16.1.1.2 Scaling

The analog input signal is mapped to the freely configurable characteristic. The maximum admissible setting range of the drive can be set via the frequency limits or percentage limits according to the configuration selected. In the case of the parameterization of a bipolar characteristic, the set minimum and maximum limits for both directions of rotation are effective. The percentage values of the characteristic points are relative to the limits selected.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
418	Minimum frequency	0.00 Hz	599.00 Hz	3.50 Hz ¹⁾
				0.00 Hz ²⁾
419	Maximum frequency	0.00 Hz	599.00 Hz	50.00 Hz

The factory settings depend on the setup of parameter *Configuration 30*:

¹⁾ 3.50 Hz in configurations 1xx, 4xx;

²⁾ 0.00 Hz in configurations 2xx, 5xx


The control system uses the maximum value of the output frequency, which is calculated from the *Maximum Frequency 419* and the compensated slip of the drive mechanism. The frequency limits define the speed range of the drive, and the percentage values supplement the scaling of the analog input characteristic in accordance with the functions configured.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
518	Minimum Reference Percentage	0.00%	300.00%	0.00%
519	Maximum Reference Percentage	0.00%	300.00%	100.00%


16.1.1.3 Tolerance Band and Hysteresis

The analog input characteristic with change of sign of the reference value can be adapted by the parameter *Tolerance Band 450* of the application. The adjustable tolerance band extends the zero passage of the speed relative to the analog control signal. The parameter value (percent) is relative to the maximum current or voltage signal.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
450	Tolerance Band	0.00%	25.00%	2.00%



The default *Minimum Frequency 418* or *Minimum Reference Percentage 518* extends the parameterized tolerance band to the hysteresis.



Tolerance band with set maximum frequency

For example, the output variable coming from positive input signals is kept on the positive minimum value until the input signal becomes lower than the value for the tolerance band in the negative direction. Then, the output variable follows the set characteristic.

16.1.1.4 Filter time constant

The time constant of the filter for the analog reference value can be set via parameter *Filter time constant* **451**.

The time constant indicates the time during which the input signal is averaged by means of a low pass filter, e.g. in order to eliminate fault effects.

The setting range is between 0 ms and 5000 ms in 15 steps.

Filter time constant 451	Function
0 - Time constant 0 ms	Filter deactivated – analog reference value is forwarded unfiltered
2 - Time constant 2 ms	
4 - Time constant 4 ms	
8 - Time constant 8 ms	
16 - Time constant 16 ms	
32 - Time constant 32 ms	
64 - Time constant 64 ms	
128 - Time constant 128 ms	
256 - Time constant 256 ms	
512 - Time constant 512 ms	
1000 - Time constant 1000 ms	
2000 - Time constant 2000 ms	
3000 - Time constant 3000 ms	
4000 - Time constant 4000 ms	
5000 - Time constant 5000 ms	

16.1.1.5 Error and warning behavior

For monitoring the analog input signal, an operation mode can be selected via parameter *Error/Warning Behavior* **453**.

Error/Warning Behavior 453	Function
0 - off	The input signal is not monitored.
1 - Warning < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning message is issued.
2 - Shut Down < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning message is issued; the drive is decelerated according to stopping behavior 2.
3 - Error switch-off < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning and error signal is issued and the drive coasts to a standstill (stopping behavior 0).

Monitoring of the analog input signal is active regardless of the release of the frequency inverter according to the operation mode selected.

Operation Mode 2 2 defines the shut-down and stopping of the drive, regardless of the setting of parameter *Operation Mode* **630** for the stopping behavior. The drive is stopped according to stopping behavior 2. If the set holding time has expired, an error message is issued. The drive can be started again by switching the start signal on and off.


Operation Mode 3 defines the free coasting of the drive, regardless of the setting of parameter *Operation Mode* **630** for the stopping behavior.



WARNING

The monitoring of the analog input signal via the parameter *Error/Warning Behavior* **453** demands the examination of parameter *Point X1* **454**.

Example: *Error/Warning Behavior* **453** = "2 - Shutdown < 1V/2mA" or "3 - Error-Switch-Off < 1V/2mA". In the default settings of parameter *Point X1* **454** shutting down or fault switch-off are effected at an output frequency \neq 0Hz. If shutting down or fault switch-off are to be effected at an output frequency of 0 Hz, the Point X1 must be adjusted (e.g. X1=10% /1 V).



16.2 Multifunction Output MFO1

Multifunction output MFO1 can either be configured as a digital, analog or a repetition frequency output. Depending on the selected *Operation Mode 550* for the multifunction output, a link to various functions of the software is possible. The operation modes not used are deactivated internally.

Operation Mode 550	Function
0 - off	Output has the logic signal LOW
1 - Digital	Digital output, 0 ... 24 V
2 - Analog	Analog output, 0 ... 24 V
3 - Repetition frequency	Repetition frequency output, 0 ... 24 V, $f_{\max} = 150$ kHz

16.2.1 Analog Output MFO1A

By default, the multifunction output MFO1 is configured for the output of a pulse width modulated output signal with a maximum voltage of DC 24V.

The selected configuration determines which actual values can be selected for parameter *Analog Operation 553* of Multifunction output 1.

Analog Operation 553	Function
0 - off	Analog operation MFO1 is switched off.
1 - Abs. Fs	Abs. value of the Stator Frequency 0,00 Hz ... <i>Maximum Frequency 419</i> .
2 - Abs. Fs betw. fmin/fmax	Abs. value of the Stator Frequency Minimum Frequency 418 ... <i>Maximum Frequency 419</i> .
3 - Abs. Speed Sensor 1	Abs. value of speed sensor signal 1, 0,00 Hz ... <i>Maximum Frequency 419</i> .
7 - Abs. actual frequency	Abs. value of act. frequency, 0,00 Hz ... <i>Maximum Frequency 419</i> .
20 - Abs. Iactive	Abs. value of current effective current I_{WIRK} , 0.0 A ... Inverter rated current.
21 - Abs. Isd	Abs. value of flux-forming current component, 0.0 A ... Inverter rated current.
22 - Abs. Isq	Abs. value of torque-forming current component, 0.0 A ... Inverter rated current.
30 - Abs. Pactive	Abs. value of current active power P_{WIRK} , 0.0 kW ... <i>Rated Mech. Power 376</i> .
31 - Abs. M	Abs. value of calculated torque M, 0.0 Nm ... rated torque.
32 - Abs. inside temperature	Abs. value of measured inside temperature, 0 °C ... 100 °C
33 - Abs. Heat Sink Temperature	Abs. value of measured heat sink temperature, 0 °C ... 100 °C
40 - Abs. value analog input MFI1A	Abs. signal value at analog input MFI1A, 0.0 V ... 10.0 V.
50 - Abs. I	Abs. current value of measured output currents, 0.0 A ... Inverter rated current.
51 - DC-Link Voltage	DC-Link Voltage U_d , 0.0 V ... 1000.0 V.
52 - U	Output voltage U, 0.0 V ... 1000.0 V.
53 - Volume Flow	Abs. value of calculated volume flow 0.0 m ³ /h ... <i>Nominal Volumetric Flow 397</i> .


Analog Operation 553	Function
54 - Pressure	Abs. value of calculated pressure 0.0 kPa ... <i>Nominal Pressure</i> 398 .
101 to 133	Operation modes in analog operation with signs.

16.2.1.1 Output Characteristic

The voltage range of the output signal at multifunction output 1 can be adjusted. The value range of the actual value selected via *parameter Analog Operation 553* is assigned to the value range of the output signal which is adjusted via the parameters *Voltage 100% 551* and *Voltage 0% 552*.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
551	Voltage 100%	0.0 V	22.0 V	10.0 V
552	Voltage 0%	0.0 V	24.0 V	0.0 V

Analog Operation 553 with abs. actual *Analog Operation 553* with sign:
value:



With parameters *Voltage 100% 551* and *Voltage 0% 552* the voltage range at 100% and 0% of the output parameter is set. If the output value exceeds the reference value, the output voltage also exceeds the value of the parameter *Voltage 100% 551* up to the maximum value of 24 V.

16.2.2 Frequency Output MFO1F

Multifunction output MFO1 can be used as a frequency output by setting parameter *Operation Mode 550* = "3 - Repetition Frequency". The DC 24 V output signal is assigned to the absolute speed/frequency value via parameter *Repetition Freq. Operation 555*. The selection of the operation modes depends on the extension modules installed as an option.

Repetition Freq. Operation 555	Function
0 - off	Repetition frequency operation MFO1 switched off
1 - Actual frequency	Abs. value of <i>Actual Frequency</i> 241 .
2 - Stator Frequency	Abs. value of <i>Stator Frequency</i> 210 .
3 - Frequency Speed Sensor 1	Abs. value of <i>Encoder 1 Frequency</i> 217 .
5 - Repetition frequency input	Abs. value of <i>Repetition Frequency Input</i> 252 .

16.2.2.1 Scaling

The repetition frequency mode for the multifunction output corresponds to the emulation of an incremental sensor. Parameter *Division Marks* **556** must be set according to the frequency to be output. The minimum frequency of Repetition Freq. Operation is 30 Hz. Smaller values will be output as 0 Hz.

The pulse-pause ratio is not 1:1. For this reason, Repetition Freq. Operation should only be evaluated with the rising or falling edge in the evaluation device.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
556	Division Marks	30	8192	1024

The frequency limit of $f_{\max}=150$ kHz must not be exceeded in the calculation of parameter *Division Marks* **556**.

$$S_{\max} = \frac{150000 \text{ Hz}}{\text{Frequency value}}$$

16.3 Digital Outputs

Op. Mode Digital Output 1 **530** and the relay output with parameter *Op. Mode Digital Output 3* **532** link the digital outputs to various functions. The selection of the functions depends on the parameterized configuration. When multifunction output MFO1 is to be used as a digital output, an *Operation Mode* **550** must be selected and linked via parameter *Digital Operation* **554**.

Operation mode 530, 532, 554	Function
0 - off	Digital output is switched off
1 - Ready or Standby Signal	Frequency inverter is initialized and on stand-by or in operation
2 - Run Signal	Signal enable STO (S1IND/STOA and S7IND/STOB) and a start command are present, output frequency available.
3 - Error Signal	Message is displayed via parameter Current Error 259 and Warnings 269 .
4 - Setting Frequency	The Stator Frequency 210 is higher than the parameterized Setting Frequency 510 .
5 - Reference frequency reached	The Actual Frequency 241 of the drive has reached the Internal Reference Frequency 228 .
6 - Reference percentage reached	The Actual Percentage Value 230 has reached the Reference Percentage Value 229 .
7 - Ixt warning	The Warning Limit Short Term Ixt 405 or Warning Limit Long Term Ixt 406 were reached.
8 - Warning Heat Sink Temperature	Max. heat sink temperature T_K of 80 °C minus Warning Limit <i>Heat Sink Temp.</i> 407 reached.
9 - Inside temperature warning	Max. Inside Temperature T_i of 65 °C minus Warning <i>Limit Inside Temp.</i> 408 reached.
10 - Motor temperature warning	Warning behavior as per configured Motor Temp. Operation Mode 570 at max. motor temperature T_{PTC} .
11 - General warning	Message is displayed via parameter Warnings 269 .
12 - Warning overtemperature	The selected Warning Limit Heat Sink Temp. 407 , Warning Limit Inside Temp. 408 or maximum motor temperature were exceeded.
13 - Mains failure	Failure of the mains voltage and power regulation active according to Operation Mode 670 for the voltage controller.
14 - Warning motor circuit breaker	Parameterized Operation Mode 571 for motor circuit breaker was triggered.

Operation mode 530, 532, 554	Function
15 - Warning current limitation	A controller or Operation Mode 573 of the intelligent current limits limit the output current.
16 - Controller current limit. long term Ixt	The overload reserve for 60 s has been used up and the output current is being limited.
17 - Controller current limit. short term Ixt	The overload reserve for 1 s has been used up and the output current is being limited.
18 - Controller current limit Tk	Max. heat sink temperature T_K reached, intelligent current limits of Operation Mode 573 active.
19 - Controller current limit. motor temp.	Max. motor temperature reached, intelligent current limits of Operation Mode 573 active.
20 - Comparator 1	The comparison according to the selected Op. Mode Comparator 1 540 is true.
21 - Comparator 2	The comparison according to the selected Op. Mode Comparator 2 543 is true.
22 - Warning V-belt	Warning of Operation Mode 581 of V-belt Monitoring.
23 - Timer 1	The selected Operation Mode Timer 1 790 generates an output signal of the function.
24 - Timer 2	The selected Operation Mode Timer 2 793 generates an output signal of the function.
25 - Warning mask	Message of the configurable parameter Create Warning Mask 536 .
26 - Warning, application	A warning application is signaled. Display of the actual value is effected via parameter <i>Application Warnings</i> 273 .
27 - Warning mask, application	Message of the configurable parameter <i>Create Appl. Warning Mask</i> 626 .
28 - Warning gen. + warning appl.	A warning or warning application is signaled.
29 - Warning mask gen. + Warning mask appl.	Message of configurable parameters Create Warning Mask 536 and <i>Create Appl. Warning Mask</i> 626 .
30 - Flux forming finished	Magnetic field has been impressed.
41 - Release brake	Activation of a brake unit depending on Operation Mode 620 for the starting behavior, Operation Mode 630 for the stopping behavior or the configured brake control system.
43 - External fan	The Switch-On Temperature 39 was reached.
50 - Synchronization Fault ¹⁾	The phase error of the index control exceeded the <i>Warning Level</i> 597 .
51 - Signal Fault ¹⁾	Index signal period too short during index control.
56 - Phasing Done ²⁾	Message of phasing function. For positioning in combination with the function of the electronic gear, the value Phasing: Offset 1125 was reached.
57 - In Gear ^{1) 2)}	Synchronization of the electronic gear is reached. The slave drive is engaged and operates at a synchronous angle with the master.
58 - Position Comparator ²⁾	The current actual value is in the range between <i>On-Position</i> 1243 to <i>Off-Position</i> 1244 of the position comparator. The set value of parameter <i>Hysteresis</i> 1245 is considered.
59 - Homing DONE ²⁾	Homing was started and the reference position for a positioning operation was set.

Operation mode 530, 532, 554	Function
60 - Target Position Reached	The <i>Reference orientation</i> 469 of axis positioning was reached or the <i>Target Position / Distance</i> 1202 of a positioning operation ²⁾ was reached (current actual position is within the range set in parameter <i>Target Window</i> 1165 for a minimum time of <i>Target Window Time</i> 1166).
61 - Warning Deviation of Position ²⁾	The contouring error monitoring <i>Warning Threshold</i> 1105 was exceeded .
62 - Motion-Block Digital Signal 1 ²⁾	Message on status of a travel order during a positioning operation. The requirements set for parameter Digital Signal 1 1218 were met. "Start", "Reference value reached" and "End" of a motion block were evaluated.
63 - Motion-Block Digital Signal 2 ²⁾	Message on status of a travel order during a positioning operation. The requirements set for parameter Digital Signal 2 1219 were met. "Start", "Reference value reached" and "End" of a motion block were evaluated.
64 - Motion-Block Digital Signal 3 ²⁾	Message on status of a travel order during a positioning operation. The requirements set for parameter Digital Signal 3 1247 were met. "Start", "Reference value reached" and "End" of a motion block were evaluated.
65 - Motion-Block Digital Signal 4 ²⁾	Message on status of a travel order during a positioning operation. The requirements set for parameter Digital Signal 4 1248 were met. "Start", "Reference value reached" and "End" of a motion block were evaluated.
80 - FT-Outp. Buffer 1 ³⁾	Output signal of a FT instruction. Signal source "2401 - FT output buffer 1" is the output signal. This signal source contains the output value of the FT-instruction assigned to signal source 2401. Assignment is done via parameter <i>FT-target output 1</i> 1350 or <i>FT-target output 2</i> 1351 .
81 - FT-Outp. Buffer 2 ³⁾	Output signal of a FT instruction. Signal source "2402 - FT output buffer 2" is the output signal. This signal source contains the output value of the FT-instruction assigned to signal source 2402. Assignment is done via parameter <i>FT-target output 1</i> 1350 or <i>FT-target output 2</i> 1351 .
82 - FT-Outp. Buffer 3 ³⁾	Output signal of a FT instruction. Signal source "2403 - FT output buffer 3" is the output signal. This signal source contains the output value of the FT-instruction assigned to signal source 2403. Assignment is done via parameter <i>FT-target output 1</i> 1350 or <i>FT-target output 2</i> 1351 .
83 - FT-Outp. Buffer 4 ³⁾	Output signal of a FT instruction. Signal source "2404 - FT output buffer 4" is the output signal. This signal source contains the output value of the FT-instruction assigned to signal source 2404. Assignment is done via parameter <i>FT-target output 1</i> 1350 or <i>FT-target output 2</i> 1351 .
90 to 94 Obj 0x3003 DigOut 1 ⁴⁾ to Obj 0x3003 DigOut 5	Sources of CAN objects. Required for communication module CM with CAN interface
100 to 194	Operation modes inverted (LOW active).

¹⁾ Refer to application manual "Electronic Gear".

²⁾ Refer to application manual "Positioning".

³⁾ Refer to application manual "Function Table".

⁴⁾ Refer to Operating Instructions on extension modules with CAN interface.

16.3.1 Digital message

The signals selected for parameters *Op. Mode Digital Output 1* **530**, *Digital Operation* **554** and *Op. Mode Digital Output 3* **532** can be linked to one another.

Signal digital output 1

175 -	Digital Signal 1	Signal selected via <i>Op. Mode Digital Output 1</i> 530 .
-------	------------------	---

Signal at multifunction output MFO1

176 -	Digital Signal 2	Signal selected via <i>Digital Operation</i> 554 . Adjustment: <i>Operation Mode</i> 550 = 1 - Digital
-------	------------------	---

Signal at digital output 3 (relay output)

177 -	Digital Signal 3	Signal selected via <i>Op. Mode Digital Output 3</i> 532 .
-------	------------------	---

With extension module:

Signal at digital output 1 of an extension module

181 -	Digital message 4, EM-Module	Signal selected via <i>Op. Mode EM-S1OUTD</i> 533 .
-------	------------------------------	--

Signal at digital output 2 of an extension module

182 -	Digital message 5, EM-Module	Signal selected via <i>Op. Mode EM-S2OUTD</i> 534 .
-------	------------------------------	--


16.3.2 Setting Frequency

If Operation Mode **4** - "Setting Frequency" is selected for a digital output, the relevant output will be active once the actual value *Stator Frequency 210* is higher than the value of *Setting Frequency 510*.

The output will be switched again once the *Stator Frequency 210* drops below the value "*Setting Frequency 510* minus *Setting Frequency Off Delta 517*". Once the output stages are switched off (e.g. via STO), the digital signal "Setting Frequency" is set to zero, regardless of the actual frequency.

Signal source 164 - "Setting frequency" can be linked to the functions of the frequency inverter.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
510	Setting Frequency	0.00 Hz	599.00 Hz	3.00 Hz
517	Setting Frequency Off Delta	0.00 Hz	599.00 Hz	2.00 Hz



Once *Setting Frequency Off Delta 517* > *Setting Frequency 510*, the output will not be turned off anymore after first activation. Make sure you use suitable values during parameterization.

<i>Op. Mode Digital Output 1 530</i>	or	4 - Setting frequency
<i>Op. Mode Digital Output 2 531</i>	or	
<i>Op. Mode Digital Output 3 532</i>		
With extension module:		
<i>Op. Mode EM-S1OUTD 533</i>	or	
<i>Op. Mode EM-S1OUTD 534</i>		
<i>Setting Frequency 510</i>		set value [Hz].
For linking to functions		164 - Setting frequency

16.3.3 Reference value reached

In Operation Mode 5 - "Reference Frequency reached" for a digital output, a message will be generated via the relevant output once the actual frequency has reached the setpoint.

In Operation Mode 6 - "Reference Percentage reached" for a digital output, a message is generated via the corresponding output when the actual percentage has reached the reference value.

Signal source 163 - "Reference frequency reached" or 178 - "Reference percentage reached" can be linked to the functions of the frequency inverter.

The hysteresis can be defined as a percentage of the adjustable range (Max - Min) via the parameter *Max. Control Deviation* **549**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
549	Max. Control Deviation	0.01%	20.00%	5.00%


<i>Op. Mode Digital Output 1</i> 530	or	5 - Reference Frequency reached or 6 - Reference Percentage reached (<i>Configuration 30</i> = x11, x30)
<i>Op. Mode Digital Output 2</i> 531	or	
<i>Op. Mode Digital Output 3</i> 532		
With extension module:		
<i>Op. Mode EM-SIOU_TD</i> 533	or	
<i>Op. Mode EM-SIOU_TD</i> 534		
<i>Max. Control Deviation</i> 549		set value [%].
For linking to functions		163 - Reference Frequency reached or 178 - Reference Percentage reached (<i>Configuration 30</i> = x11, x30)

Reference frequency
Internal Reference Frequency **228**

or
Reference percentage
Reference Percentage Value **229**

Actual Frequency **241**

or
Actual Percentage Value **230**



163 - Reference Frequency reached


178 - Reference Percentage reached

Example:

$$\text{Max. Control Deviation [Hz]} = \Delta f \times \text{Max. Control Deviation 549 [\%]}$$

$$= (\text{Maximum Frequency 419} - \text{Minimum Frequency 418}) \times \text{Max. Control Deviation 549 [\%]}$$

$$= (50 \text{ Hz} - 3.5 \text{ Hz}) \times 5\% = 2.325 \text{ Hz}$$



16.3.4 Flux forming finished

If Operation Mode 30 is selected for a digital output, the corresponding output becomes active when the flux formation is finished. The time for the flux formation results from the operating state of the machine and the set parameters for magnetizing the machine. The magnetizing can be defined via the starting behavior and is influenced by the amount of the set starting current.

16.3.5 Brake release

The Brake release function in Operation Mode 41 enables the activation of a corresponding unit via the digital control output. The function uses both the control commands via the contact inputs and the set starting and stopping behavior for controlling the digital output.

According to the configured starting behavior, the output is switched on when the magnetizing of the motor is finished. Once the *Brake Release Time* **625** has elapsed, the drive will be accelerated.

The stopping behavior of the drive depends on the configuration of the parameters *Operation Mode* **630**. This is described in chapter 13.2 "13.2".

If stopping behavior 2 or 5 with stop function is selected, the drive is controlled to zero speed and the digital output is not switched off. In the other operation modes of the stop behavior, the control of the brake is possible. At the start of a free coasting of the drive, the digital output is switched off.

This is similar to the behavior in the case of the stopping behavior with shutdown. The drive is decelerated and supplied with current for the set holding time. Within the set holding time, the control output is switched off and thus the brake activated.

Control of Brake	
Stopping behavior 0	Operation Mode "41-Brake release" switches off the digital output assigned to the function immediately. The mechanical brake is activated.
Stopping behavior 1, 3, 4, 6, 7	Operation Mode "41-Brake release" switches off the digital output assigned to the function once the Switch-off threshold stop function 637 is reached. The mechanical brake is activated.
Stopping behavior 2, 5	Operation Mode "41-Brake release" leaves the digital output assigned to the function switched on. The mechanical brake remains open.

16.3.6 Current limitation

Operation Modes 15 to 19 link the digital outputs and the relay output to the functions of the intelligent current limits. The reduction of power by the set figure in percent of the rated current depends on the selected operation mode. Accordingly, the event for intervention of the current limitation can be output via the operation modes of the digital outputs. If the function of the intelligent current limits is deactivated within the sensorless control, operation modes 16 to 19 are switched off in the same way.

16.3.7 External fan

Operation Mode 43 enables control of an external fan. Via the digital output, the fan is switched on if the controller is released and Start clockwise or Start anticlockwise are switched on, or if the *Switch-On Temperature* **39** for the internal fan was reached.

16.3.8 Warning mask

The warning mask signals, via a digital signal, if a pre-configured warning is present. The warning mask is configured via *Create Warning Mask* **536**. Warnings and controller status messages can be combined. This enables internal or external control using a common output signal. The display of **269 Warning** and **275 Controller Status** is not influenced via the warning mask.

Select one of the settings **1 ... 43** to activate messages.

Select one of the Operation Modes 101 ... 143, if certain warnings are not to be reported.

Create Warning Mask 536	Function
0 - No change	Configured warning mask is not modified.
1 - Activate everything	The warnings and controller status messages stated are linked in the warning mask.
2 - Activate all warnings	The warnings reports stated are linked in the warning mask.
3 - Activate all controller states	The controller status reports stated are linked in the warning mask.
10 - Warning Ixt	The frequency inverter is overloaded
11 - Warning short-term Ixt	Overload reserve for 1 s minus the Warning Limit Short Term Ixt 405 was reached.
12 - Warning long-term Ixt	Overload reserve for 60 s minus the Warning Limit Long Term Ixt 406 was reached.
13 - Warning heat sink temperature	Max. heat sink temperature TK of 80 °C minus the Warning Limit Heat Sink Temp. 407 was reached.
14 - Warning inside temperature	Max. Inside Temperature T _i of 65 °C minus Warning Limit Inside Temp. 408 reached.
15 - Warning limit	The controller stated in Controller Status 355 limits the reference value.
16 - Warning Init	Frequency inverter is being initialized
17 - Motor temperature warning	Warning behavior as per configured Motor Temp. Operation Mode 570 at max. motor temperature T _{PTC} .
18 - Warning Mains Failure	Phase Supervision 576 reports mains failure.
19 - Warning Motor Protection	Operation Mode 571 for motor circuit breaker was triggered.
20 - Warning Fmax	The Maximum Frequency 419 was exceeded. The frequency limitation is active
21 - Warning Analog Input MF11A	The input signal is lower than 1V/2mA according to the operation mode Error/Warning Behavior 453 .
22 - Warning Analog Input EM-S11NA	The input signal at the analog input of an extension module is lower than 1V/2mA according to the operation mode Error -/Warning Behavior 453 .
23 - Warning System Bus	A slave on the system bus reports a fault; warning is only relevant with the EM-SYS option.
24 - Warning Udc	The DC link voltage has reached the type-dependent minimum value.
25 - Warning, application	A warning application is signaled.
30 - Controller Udc Dynamic Operation	Controller is active according to the Operation Mode 670 for the voltage controller.
31 - Controller shutdown	The output frequency in the case of a power failure is below the Shutdown threshold 675 .
32 - Controller mains failure	Failure of the mains voltage and power regulation active according to Operation Mode 670 for the voltage controller.
33 - Controller Udc limitation	The DC link voltage has exceeded the Reference DC-Link Limitation 680 .

Create Warning Mask 536		Function
34 -	Controller Voltage Pre-Control	The Dyn. Voltage Pre-Control 605 accelerates the control characteristics.
35 -	Controller I abs	The output current is limited
36 -	Controller Torque Limitation	The output power or the torque are limited by the speed controller
37 -	Controller Torque Control	Switch-over of field-oriented control between speed and torque-controlled control method.
38 -	Ramp stop	The Operation mode 620 selected in starting behavior limits the output current.
39 -	Contr. intel. curr. lim. LT-Ixt	Overload limit of the long-term Ixt (60s) reached, intelligent current limits active
40 -	Contr. intel. curr. lim. ST-Ixt	Overload limit of the short-term Ixt (1s) reached, intelligent current limits active.
41 -	Contr. intel. curr. lim. Tc	Max. heat sink temperature T_K reached, Operation Mode 573 for intelligent current limits active.
42 -	Contr. intel. curr. lim. motor temp.	Max. motor temperature T_{PTC} reached, Operation Mode 573 for intelligent current limits active.
43 -	Controller Frequ. Limitation	The reference frequency has reached the Maximum Frequency 419 . The frequency limitation is active.
101 to 143		Removal or deactivation of the operation mode within the warning mask

The current warning mask can be read via parameter *Actual Warning Mask* **537**. The above Operation Modes of parameter *Create Warning Mask* **536** are encoded in the *Actual Warning Mask* **537**. The code is calculated by hexadecimal addition of the individual operation modes and the corresponding abbreviation

Warning code				Create Warning Mask 536
A	FFFF	FFFF	-	1 - Activate everything
A	0000	FFFF	-	2 - Activate all warnings
A	FFFF	0000	-	3 - Activate all controller states
A	0000	0001	Ixt	10 - Warning Ixt
A	0000	0002	IxtSt	11 - Warning short-term Ixt
A	0000	0004	IxtLt	12 - Warning long-term Ixt
A	0000	0008	Tc	13 - Warning heat sink temperature
A	0000	0010	Ti	14 - Warning inside temperature
A	0000	0020	Lim	15 - Warning limit
A	0000	0040	INIT	16 - Warning Init
A	0000	0080	MTemp	17 - Motor temperature warning
A	0000	0100	Mains	18 - Warning mains failure
A	0000	0200	PMS	19 - Warning motor circuit breaker
A	0000	0400	Flim	20 - Warning Fmax
A	0000	0800	A1	21 - Warning analog input MFI1A
A	0000	1000	A2	22 - Warning analog input MFI2A
A	0000	2000	Sysbus	23 - Warning system bus
A	0000	4000	UDC	24 - Warning Udc
A	0000	8000	WARN2	25 - Warning, application
A	0001	0000	UDdyn	30 - Controller Udc dynamic operation
A	0002	0000	UDstop	31 - Controller shutdown
A	0004	0000	UDctr	32 - Controller mains failure
A	0008	0000	UDlim	33 - Controller Udc limitation
A	0010	0000	Boost	34 - Controller voltage pre-control
A	0020	0000	Ilim	35 - Controller I abs
A	0040	0000	Tlim	36 - Controller torque limitation
A	0080	0000	Tctr	37 - Controller torque control
A	0100	0000	Rstp	38 - Ramp stop
A	0200	0000	IxtLtim	39 - Contr. intel. curr. lim. LT-Ixt
A	0400	0000	IxtStlim	40 - Contr. intel. curr. lim. ST-Ixt
A	0800	0000	Tclim	41 - Contr. intel. curr. lim. Tc
A	1000	0000	MtempLim	42 - Contr. intel. curr. lim. motor temp.
A	2000	0000	Flim	43 - Controller Freq. Limitation

Output signals

The output of a warning is signaled.

157 -	Warning mask	1)	Output of warning activated in <i>Create Warning Mask 536</i> .
25 -		2)	

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.



Parameters *Warning 269* and *Warning 356* (Error Environment) display the warnings independent of the created warning mask.

Parameters *Controller Status 275* and *Controller Status 355* (Error Environment) display the controller status independent of the created warning mask.

16.3.9 Warning mask, application

The application warning mask signals, via a digital signal, if a pre-configured warning is present. The application warning mask is configured via *Create Appl. Warning Mask 626*.

As soon as limit switches are reached or contouring error thresholds are exceeded, a warning can be issued. The warning signal refers to the parameter values set in error/warning behavior. Depending on the application, any number of warnings can be configured. This enables internal and/or external control using a common output signal. The display of *Application Warnings 273* is not influenced via the warning mask.

Create Appl. Warning Mask 626	Function
0 - no change	The configured warning mask is not changed.
2 - Activate all warnings	The warnings reports stated are linked in the warning mask.
10 - Warning V-belt	Operation Mode 581 signals no-load operation of the application.
11 - Warning pos. SW limit switch ¹⁾	Warning message indicating that the positive SW limit switch has been reached (parameter <i>Pos. SW Limit Switch 1145</i>).
12 - Warning neg. SW limit switch ¹⁾	Warning message indicating that the negative SW limit switch has been reached (parameter <i>Neg. SW Limit Switch 1146</i>).
13 - Warning pos. HW limit switch ¹⁾	Warning message indicating that the positive HW limit switch has been reached.
14 - Warning neg. HW limit switch ¹⁾	Warning message indicating that the negative HW limit switch has been reached.
15 - Warning Contouring Error ¹⁾	Warning message, indicating that the contouring error monitoring range adjusted with parameter <i>Warning Threshold 1105</i> has been left.
16 - Warning Encoder	An encoder with data track can generate a warning. Selection is not effective in the case of encoders without data track.
17 - User Warnig 1	The signal set at digital input <i>User Warnig 1 1363</i> is active.
18 - User Warnig 2	The signal set at digital input <i>User Warnig 2 1364</i> is active.
102 - Deactivate all warnings	All warnings are deactivated.
110 - Deactivate warning V-Belt	Warning 10 is deactivated.
111 - Deactivate warning pos. SW limit switch	Warning 11 is deactivated.
112 - Deactivate warning neg. SW limit switch	Warning 12 is deactivated.
113 - Deactivate warning pos. HW limit switch	Warning 13 is deactivated.
114 - Deactivate warning neg. HW limit switch	Warning 14 is deactivated.
115 - Deactivate Warning Contouring Error	Warning 15 is deactivated.
116 - Deactivate Warning Encoder	Warning 16 is deactivated.
117 - Deactivate User Warnig 1	Warning 17 is deactivated.
118 - Deactivate User Warnig 2	Warning 18 is deactivated.

¹⁾ Refer to application manual "Positioning".

The current application warning mask can be read via parameter *Actual Appl. Warning Mask* **627**. The Operation Modes of parameter *Create Appl. Warning Mask* **626** are encoded in the *Actual Appl. Warning Mask* **627**. The code is calculated by hexadecimal addition of the individual operation modes and the corresponding abbreviation

Warning code		Create Appl. Warning Mask 626
A 003F	-	2 - Activate all warnings
A 0001	BELT	10 - Warning V-belt
A 0002	SW-LIM CW	11 - Warning pos. SW limit switch
A 0004	SW-LIM CCW	12 - Warning neg. SW limit switch
A 0008	HW-LIM CW	13 - Warning pos. HW limit switch
A 0010	HW-LIM CCW	14 - Warning neg. HW limit switch
A 0020	CONT	15 - Warning position controller
A 0040	Enc	16 - Warning Encoder
A 0080	User 1	17 - User Warnig 1
A 0100	User 2	18 - User Warnig 2

Output signals

The output of a warning is signaled.

215 -	Warning mask, application	1)	Output of warning activated in <i>Create Appl. Warning Mask</i> 626 .
27 -		2)	

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.



Parameter *Application Warnings* **273** displays the application warning regardless of the warning mask created. In the error environment, *Application Warning Status* **367** displays the current warnings of the positioning functions.

16.4 Digital Inputs

The assignment of the control signals to the available software functions can be adapted to the application in question. Depending on the *Configuration* **30** selected, the default assignment or selection of the operation mode differ. In addition to the available digital control inputs, further internal logic signals are available as sources.

Each of the individual software functions is assigned to the various signal sources via parameterizable inputs. This enables a flexible use of the digital control signals.

Digital Inputs		Function
6 -	On	Signal input is switched on.
7 -	off	Signal input is switched off.
13 -	Technology Controller Start	Start command technology controller (configuration 111, 211 or 411)
70 -	FI release	¹⁾ Signal at digital inputs S1IND/STOA (X210A.3) and S7IND/STOB (X210B.2). Safety function STO - "Safe Torque Off" is linked permanently.
71 -	S2IND	Signal at digital input S2IND (X210A.4) or remote operation via communication interface.
72 -	S3IND	Signal at digital input S3IND (X210A.5) or remote operation via communication interface.
73 -	S4IND	Signal at digital input S4IND (X210A.6) or remote operation via communication interface.

Digital Inputs	Function
74 - S5IND	Signal at digital input S5IND (X210A.7) or remote operation via communication interface.
75 - S6IND	Signal at digital input S6IND (X210B.1) or remote operation via communication interface.
76 - MFI1D	Signal at multifunction input MFI1 (X210B.6) in <i>Operation Mode 452</i> = "3 - Digital Input" or remote operation via communication interface.
157 - Warning mask	The defined warning mask of parameter <i>Create Warning Mask 536</i> signals a critical operating point.
158 - Timer 1	Output signal of the time function according to the input link <i>Timer 1 83</i> .
159 - Timer 2	Output signal of the time function according to the input link <i>Timer 2 84</i> .
160 - Standby Message	Frequency inverter is initialized and ready for operation.
161 - Run Signal	Signal enable STO (S1IND/STOA and S7IND/STOB) and a start command are present, output frequency available.
162 - Error Signal	Monitoring function signals an operational fault.
163 - Reference frequency reached	Signal indicating when <i>Actual Frequency 241</i> has reached the reference frequency.
164 - Setting Frequency	Signal indicating when the actual value <i>Stator Frequency 210</i> exceeds the value of <i>Setting Frequency 510</i> .
165 - Warning Ixt	The monitoring functions report an overload of the frequency inverter
166 - Heat sink temperature warning	Max. heat sink temperature T_K of 80 °C minus the <i>Warning Limit Heat Sink Temp. Tk 407</i> reached.
167 - Warning Inside Temperature	Max. inside temperature T_i of 65 °C minus the <i>Warning Limit Inside Temp. 408</i> reached.
168 - Warning Motor Temperature	Warning behavior according to parameterized <i>Motor Temp. Operation Mode 570</i> at max. motor temperature T_{PTC} .
169 - General Warning	Signal indicating that <i>Warnings 269</i> are displayed at critical operating points.
170 - Warning overtemperature	The value <ul style="list-style-type: none"> – "80 °C minus <i>Warning Limit Heat Sink Temp. Tk 407</i>" or – "65 °C minus <i>Warning Limit Inside Temp. Ti 408</i>" was reached.
171 - Output Comparator 1	The comparison according to the selected <i>Op. Mode Comparator 1 540</i> is true.
172 - Negated Output Comparator 1	Operation mode 171 with inverted logic (LOW active)
173 - Output Comparator 2	The comparison according to the selected <i>Op. Mode Comparator 2 543</i> is true.
174 - Negated Output Comparator 2	Operation mode 173 with inverted logic (LOW active)
175 - Digital Signal 1	Signal according to parameterized <i>Op. Mode Digital Output 1 530</i> .
176 - Digital Signal 2	Signal according to parameterized <i>Digital Operation 554</i> at multifunction output MFO1.
177 - Digital Signal 3	Signal according to parameterized <i>Op. Mode Digital Output 3 532</i> .
178 - Reference Percentage reached	Signal indicating that <i>Actual Percentage Value 230</i> has reached the <i>Reference Percentage Value 229</i> .
179 - Power Failure	Failure of mains voltage and mains support active according to <i>Operation Mode 670</i> for the voltage controller.

Digital Inputs	Function	
180 - Warning Motor Protection	Parameterized <i>Operation Mode 571</i> of motor circuit breaker triggered.	
181 - Digital Signal 4, EM-Module	Signal according to operation mode for the digital output of an extension module	
182 - Digital Signal 5, EM-Module	Signal according to operation mode for the digital output of an extension module	
215 - Warning mask, application	The defined warning mask of parameter <i>Create Appl. Warning Mask 626</i> signals a critical operating point.	
216 - Warning, application	All warnings application are deactivated. Display is effected via parameter <i>Application Warnings 273</i> .	
270 to 276	Operation modes 70 to 76 of the digital inputs inverted (LOW active).	
282 - Target Position Reached	<i>Reference orientation 469</i> of axis positioning was reached or	
	<i>Target Position / Distance 1202</i> of a positioning operation was reached (the current act. position is within the range set in parameter <i>Target Window 1165</i> for a minimum period of <i>Target Window Time 1166</i> .	2)
284 - STOA inverted	3)	Inverted signal status on digital input S1IND/STOA (first shut-down path STOA of safety function STO - "Safe Torque Off").
285 - STOB inverted		Inverted signal status on digital input S7IND/STOB (second shut-down path STOB of safety function STO - "Safe Torque Off").
292 - STOA		Signal status on digital input S1IND/STOA (first shut-down path STOA of safety function STO - "Safe Torque Off").
293 - STOB		Signal status on digital input S7IND/STOB (second shut-down path STOB of safety function STO - "Safe Torque Off").
320 - EM-S1IND	4)	Signal at digital input 1 of an extension module EM or remote operation via communication interface.
321 - EM-S2IND		Signal at digital input 2 of an extension module EM or remote operation via communication interface.
322 - EM-S3IND		Signal at digital input 3 of an extension module EM or remote operation via communication interface.
520 - EM-S1IND inverted		Operation mode 320 inverted.
521 - EM-S2IND inverted	5)	Operation mode 321 inverted.
522 - EM-S3IND inverted		Operation mode 322 inverted.
526 - S2IND (Hardware)		Digital input S2IND (X210A.4)
527 - S3IND (Hardware)		Digital input S3IND (X210A.5)
528 - S4IND (Hardware)	6)	Digital input S4IND (X210A.6)
529 - S5IND (Hardware)		Digital input S5IND (X210A.7)
530 - S6IND (Hardware)		Digital input S6IND (X210B.1)
531 - MFI1D (Hardware)		Multifunction input MFI1 (X210B.6) in <i>Operation Mode 452</i> = 3 – Digital input.
532 - EM-S1IND (Hardware)		Digital input 1 of an extension module EM.
533 - EM-S2IND (Hardware)		Digital input 2 of an extension module EM.
534 - EM-S3IND (Hardware)		Digital input 3 of an extension module EM.
538 to 546		Operation modes 526 to 534 of the digital inputs inverted (LOW active).
604 - Warning position controller	6)	Contouring error supervision message. The range set with parameter <i>Warning Threshold 1105</i> was left.

Digital Inputs		Function
614 - Homing Done		Homing was started and the reference position for a positioning operation was set.
615 - Homing Requested		Homing was started Signal will be reset once homing is completed.
616 - Phasing done		Message of phasing function. For positioning in combination with the function of the electronic gear, the value <i>Phasing: Offset</i> 1125 was reached.
624 - In gear	7)	Synchronization of the electronic gear is reached. The slave drive is engaged and operates at a synchronous angle with the master.
640 Out-PZD3 Boolean to to 655 Out-PZD18 Boolean	8)	Process data for Profibus communication. Module CM-PDP-V1 with Profibus interface required.
691 - Index Contr.: Warn. Phase Error	9)	The phase error of the index control exceeded the <i>Warning Level</i> 597 .
692 - Index Contr.: Warn. Period		Index signal period too short during index control.
700 - RxPDO1 Boolean1		Signal if an optional extension module EM with system bus is used.
701 - RxPDO1 Boolean2		Signal if an optional extension module EM with system bus is used.
702 - RxPDO1 Boolean3		Signal if an optional extension module EM with system bus is used.
703 - RxPDO1 Boolean4	10)	Signal if an optional extension module EM with system bus is used.
710 to 713		Operation modes 700 to 703 for RxPDO2 with an extension module EM with system bus.
720 to 723		Operation modes 700 to 703 for RxPDO3 with an extension module EM with system bus.
730 - Sysbus emergency		Signal if an optional extension module EM with system bus is used.
750 - OUT-PZD3 Boolean		Process data for Profibus communication. Module CM-PDP with Profibus interface required.
751 - OUT-PZD4 Boolean	11)	Process data for Profibus communication. Module CM-PDP with Profibus interface required.
752 - OUT-PZD5 Boolean		Process data for Profibus communication. Module CM-PDP with Profibus interface required.
753 - OUT-PZD6 Boolean		Process data for Profibus communication. Module CM-PDP with Profibus interface required.
810 to 814 Obj 0x3003 DigOut 1 to Obj 0x3003 DigOut 5	12)	Sources of CAN objects for CANopen communication. Communication module CM with CAN interface required.
832 to 847 Obj 0x3005 Demux Out 1 to Obj 0x3005 Demux Out 16		Sources at output of demultiplexer for CANopen communication. Communication module CM with CAN interface required.
876 - Position Comparator Out		The current actual value is in the range between <i>On-Position</i> 1243 and <i>Off-Position</i> 1244 .
877 - Output position comparator inverted	13)	Operation mode 876 inverted.
887 - MBC: Start Clockwise		Message clockwise of positioning controller.
888 - MBC: Start Anticlockwise		Message anticlockwise of positioning controller.

Digital Inputs			Function
891 -	Motion-Block Signal 1	Digital	Message on status of a travel order during a positioning operation. The requirements set for parameter <i>Digital Signal 1</i> 1218 were met. "Start", "Reference value reached" and "End" of a motion block were evaluated.
892 -	Motion-Block Signal	Digital	Message on status of a travel order during a positioning operation. The requirements set for parameter <i>Digital Signal 2</i> 1219 were met. "Start", "Reference value reached" and "End" of a motion block were evaluated.
893 -	Motion-Block Signal 3	Digital	Message on status of a travel order during a positioning operation. The requirements set for parameter <i>Digital Signal 3</i> 1247 were met. "Start", "Reference value reached" and "End" of a motion block were evaluated.
894 -	Motion-Block Signal 4	Digital	Message on status of a travel order during a positioning operation. The requirements set for parameter <i>Digital Signal 4</i> 1248 were met. "Start", "Reference value reached" and "End" of a motion block were evaluated.
895 to 898			Operation modes 891 to 894 inverted (LOW active).
910 to 925	Output DeMux bit 0 to Output DeMux bit 15	¹⁴⁾	Bit 0 to Bit 15 on output of de-multiplexer; de-multiplexed process data signal via system bus or Profibus on input of multiplexers (parameter <i>DeMux Input</i> 1253).
2401 to 2416	FT-output buffer 1 to FT-output buffer 16	¹⁵⁾	Output signals of FT-instructions of table of functions.

- ¹⁾ Refer to application manual "Safe Torque Off STO".
- ²⁾ Refer to application manual "Positioning".
- ³⁾ Refer to application manual "Safe Torque Off STO".
- ⁴⁾ Refer to operating instructions on extension modules with digital inputs.
- ⁵⁾ The digital signal is independent from the configuration of the parameter *Local/Remote* **412**.
- ⁶⁾ Refer to application manual "Positioning".
- ⁷⁾ Refer to application manuals "Positioning" and "Electronic Gear".
- ⁸⁾ Refer to operating instructions on extension modules with Profibus.
- ⁹⁾ Refer to application manual "Electronic Gear".
- ¹⁰⁾ Refer to operating instructions on extension modules with System Bus.
- ¹¹⁾ Refer to operating instructions on extension modules with Profibus interface.
- ¹²⁾ Refer to operating instructions on extension modules with CAN interface.
- ¹³⁾ Refer to application manual "Positioning".
- ¹⁴⁾ Refer to operating instructions on extension module with System Bus or Profibus interface.
- ¹⁵⁾ Refer to application manual "Function Table".

16.4.1 Start command


Parameters *Start Clockwise* **68** and *Start Anticlockwise* **69** can be linked to the available digital control inputs or the internal logic signals. The drive is only accelerated according to the control method after a start command.

The logic functions are used for the specification of the direction of rotation, but also for using the parameterized *Operation Mode* **620** for the starting behavior and *Operation Mode* **630** for the stopping behavior.

16.4.2 3-wire control

In the case of 3-wire control, the drive is controlled using digital pulses. The drive is prepared for starting via the logic state of the signal *Start 3-Wire-Ctrl* **87** and started by a Start Clockwise pulse (parameter *Start Clockwise* **68**) or a Start Anticlockwise pulses (parameter *Start-Anticlockwise* **69**). The drive is stopped by turning the signal *Start 3-Wire-Ctrl* **87** off.

The control signals for Start clockwise and Start anticlockwise are pulses. The functions Start clockwise and Start anticlockwise for the drive are latching-type functions when signal *Start 3-Wire-Ctrl* **87** is turned on. Latching is canceled when the latching signal is switched off.



The drive is started according to the configured starting behavior if the signal *Start 3-Wire-Ctrl* **87** is on and a positive signal edge for Start clockwise or Start anticlockwise is detected.

Once the drive has started, new edges **(1)** on the start signals will be ignored.

If the start signal is shorter than 32 ms **(2)** or if both start signals were switched on within 32 ms **(2)** the drive will be switched off according to the configured stopping behavior.

3-wire control is activated with parameter *Local/Remote* **412**:

Local/Remote 412	Function
5 - Ctrl. 3-wire, direction Cont.	3-wire; control of sense of rotation and signal <i>3-Wire Ctrl</i> 87 via contacts.
46 - Ctrl. 3-Wire+KP, Dir. Cont. +KP	3-wire and control unit; control of direction of rotation and signal <i>3-Wire Ctrl</i> 87 via contacts or control unit.

For further operation modes of parameter *Local/Remote* **412**, see Chapter 19.3 "19.3".

16.4.3 Error Acknowledgment

The frequency inverters feature various monitoring functions which can be adapted via the error and warning behavior. Switching the frequency inverter off at the various operating points should be avoided by an application-related parameterization. If there is a fault switch-off, this message can be acknowledged via parameter *Program* **34** or the logic signal linked with parameter *Error Acknowledgment* **103**.

16.4.4 Timer

The time functions can be selected via parameters *Operation Mode Timer 1* **790** and *Operation Mode Timer 2* **793**. The sources of the logic signals are selected via parameters *Timer 1* **83** and *Timer 2* **84** and processed according to the configured timer function.

16.4.5 Thermocontact

The monitoring of the motor temperature is a part of the error and warning behavior which can be configured as required. Parameter *Therm. Contact* **204** links the digital input signal to the *defined Motor Temp. Operation Mode* **570**, described in Chapter 14.6 "Motor temperature". The temperature monitoring via a digital input checks the input signal for the threshold value. Accordingly, a thermocontact or an additional circuit must be used if a temperature-dependent resistor is used.

16.4.6 n-/M control change-over

The field-oriented control procedures in configurations 230, 430, 530 and 630 contain the functions for speed or torque-dependent control of the drive. The change-over can be done in ongoing operation, as an additional functionality monitors the transition between the two control systems. The speed controller or the torque controller is active, depending on the *n-/M-Control Change-Over* **164**.

16.4.7 Switch data set


Parameter values can be stored in four different data sets. This enables the use of various parameter values depending on the current operation point of the frequency inverter. The change-over between the four data sets is done via the logic signals assigned to parameters *Data Set Change-Over 1* **70** and *Data Set Change-Over 2* **71**.

The actual value parameter *Active Data Set* **249** shows the selected data set.

Control		
<i>Data Set Change-Over 1</i> 70	<i>Data Set Change-Over 2</i> 71	Function / active data set
0	0	Data set 1 (DS1)
1	0	Data set 2 (DS2)
1	1	Data set 3 (DS3)
0	1	Data set 4 (DS4)

0 = Contact open 1 = Contact closed

When *Configuration* **30** = 110, 111, 410, 411, 430, 510, 511, 530, 610, 611 or 630 is selected, a timer function is connected by default between digital input S4IND and Data Set Change-Over 1.



Data Set Change-Over 1 is linked to the Timer 1:

Data Set Change-Over 1 **70** = 158 – Timer 1

Timer 1 is linked to digital input S4IND (terminal X210A.6):

Timer 1 **83** = 73 – S4IND

By default, Data Set Change-Over 1 is not affected by Timer 1:

Signal delay *Time 1 Timer 1* **791** = 0.00 s/m/h

Signal duration *Time 2 Timer 1* **792** = 0.00 s/m/h

16.4.8 Fixed Value Change-Over

Depending on the selected configuration, the setpoints are defined via the assignment of the *Reference Frequency Source* **475** or *Reference Percentage Source* **476**. Accordingly, there can be a change between the fixed values by connection of the logic signals with parameters *Fixed Frequency Change-Over 1* **66**, *Fixed Frequency Change-Over 2* **67** or parameters *Fixed Percent Change-Over 1* **75**, *Fixed Percent Change-Over 2* **76**.

By combining the logic states of the fixed frequency change-over modes 1 and 2, fixed frequencies 1 through 4 can be selected:

Fixed Frequency Control		
<i>Fixed Frequency Change-Over 1</i> 66	<i>Fixed Frequency Change-Over 2</i> 67	Function/active fixed value
0	0	<i>Fixed Frequency 1</i> 480
1	0	<i>Fixed Frequency 2</i> 481
1	1	<i>Fixed Frequency 3</i> 482
0	1	<i>Fixed Frequency 4</i> 483

0 = Contact open 1 = Contact closed

By combining the logic states of the fixed percentage change-over modes 1 and 2, fixed percentages 1 through 4 can be selected:

Fixed percentage control		
<i>Fixed Percent Change-Over 1</i> 75	<i>Fixed Percent Change-Over 2</i> 76	Function/active fixed value
0	0	<i>Fixed Percentage 1</i> 520
1	0	<i>Fixed Percentage 2</i> 521
1	1	<i>Fixed Percentage 3</i> 522
0	1	<i>Fixed Percentage 4</i> 523

0 = Contact open 1 = Contact closed

16.4.9 Motor potentiometer

Parameters *Reference Frequency Source* **475** and *Reference Percentage Source* **476** contain operation modes with motor potentiometer. *Operation Mode* **474** defines the behavior of the motor potentiometer function and parameters *Frequency Motorpoti Up* **62**, *Frequency Motorpot. Down* **63** or *Percent Motorpoti Up* **72**, *Percent Motorpoti Down Ab* **73** the link to the available logic signals.

Motor Potentiometer Control		
Motorpoti Up	Motorpoti Down	Function
0	0	Output signal does not change
1	0	Output value rises at set ramp

0	1	Output value drops at set ramp
1	1	Output value is reset to initial value

0 = Contact open 1 = Contact closed

16.4.10 Handshake Traverse Function

Via Parameter *Handshake Traverse Function* 49 the signal source is selected for specification of the direction of rotation of the slave drive of the traverse function. The Traverse Function is switched on via parameter *Operation Mode* **435**.

16.4.11 User Warning

For parameterization of external warnings, you can use parameters *User Warnig 1* **1363** and *User Warnig 2* **1364** . Parameterization of an a user warning error enables triggering a warning in the device via a digital signal in the event of a critical state. This warning is displayed in *Application Warnings* **273** can be transmitted to a higher-level control. Please also refer to parameter *Create Appl. Warning Mask* **626** and the explanations in Chapter "".

2 independent warnings can be parameterized via *User Warnig 1* **1363** and *User Warnig 1* **1364**.

16.4.12 External Error

Parameterization of an external error enables switching off or shutting down several frequency inverters at a time if a fault occurs in the plant or the drive. If an error occurs in a frequency inverter, the error signal can be transmitted via a bus system and the required reaction can be triggered in another frequency inverter. Parameter *External Error* **183** can be assigned the logic signal or digital input signal which is to trigger the external error.

Via Parameter *Op Mode ext. Error* **535** the response to an external error can be configured.

Operation Mode 535	Function
0 - disabled	No response to external errors.
1 - Error switch-off	The drive is switched off and the error message „F1454 External Error“ is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.
2 - Shutdown, error	The drive is stopped at the current deceleration ramp and the error message „F1454 External Error“ is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.
3 - Emergency-stop, error	The drive is stopped at the current emergency stop ramp and the error message „F1454 External Error“ is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.

For parameterization of external warnings, you can use parameters *User Warnig 1* **1363** and *User Warnig 2* **1364** . Please refer to Chapter 16.3.9 "16.3.9" for more details.

16.5 Function Modules

16.5.1 Timer


The timer function can be linked to various functions for time-control of digital signals.

Parameters *Operation Mode Timer 1* **790** and *Operation Mode Timer 2* **793** define the evaluation of the digital input signals and the unit of time of the time function.

Operation mode Timer 790, 793	Function
0 - off	Signal output is switched off.
1 - Normal, Rising Edge, Sec.	Positive signal edge starts timer (trigger), time 1 delays the output signal, time 2 defines the signal period

2 - Retrigger, Rising Edge, Sec.	Positive signal edge starts timer (trigger), next positive signal edge within time 1 starts the signal delay again (Retrigger), time 2 defines the signal period
3 - AND-Connect., Rising Edge, Sec.	Positive signal edge starts timer (trigger), if no input signal is received within time 1 the signal delay starts again (Retrigger), if no input signal is received within time 2, the signal period is terminated
11 to 13	Operation modes 1...3, negative signal edge starts timer.
101 to 113	Operation modes 1...3, [in minutes].
201 to 213	Operation modes 1...3, [in hours].

By default, the functions are linked according to the following illustration:



The sources of digital signals (z. B. 73 - S4IND) are selected with parameters *Timer 1 83* and *Timer 2 84*. By default, Timer 1 is linked to digital input 4 and Timer 2 is off.

The timer output signal can be assigned to a frequency inverter feature or a digital output. By default, *Data Set Change-Over 1 70* is linked to Timer 1 and Timer 2 is not assigned.

NOTICE

Default settings: *Time 2 Timer 1 792* = 0. Signals at digital input S4IND are forwarded to Data Set Change-Over 1 without delay.

Function	Parameter for input signal	Operation mode	Time constants	Output signal of function	
Timer 1	<i>Timer 1 83</i>	<i>Operation Mode Timer 1 790</i>	<i>Time 1 Timer 1 791</i> <i>Time 2 Timer 1 792</i>	158 ¹⁾ -	Timer 1
				23 ²⁾ -	
Timer 2	<i>Timer 2 84</i>	<i>Operation Mode Timer 2 793</i>	<i>Time 1 Timer 2 794</i> <i>Time 2 Timer 2 795</i>	159 ¹⁾ -	Timer 2
				24 ²⁾ -	

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.

16.5.1.1 Timer – Time Constant

The logic sequence of input and output signals is to be set separately for both timer functions via the time constants. The default parameter values result in a direct link of the input and output signal without a delay.



Before starting the timer, select the operation mode and set the time constants in order to avoid non-defined states.


Select operation mode for:	Set time constants in:
<i>Operation Mode Timer 1 790</i>	<i>Time 1 Timer 1 791</i> (signal delay)
	<i>Time 2 Timer 1 792</i> (signal duration)
<i>Operation Mode Timer 2 793</i>	<i>Time 1 Timer 2 794</i> (signal delay)
	<i>Time 2 Timer 2 795</i> (signal duration)

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
791	Time 1 Timer 1, signal delay	0.00 s/m/h	650.00 s/m/h	0.00 s/m/h
792	Time 2 Timer 1, signal duration	0.00 s/m/h	650.00 s/m/h	0.00 s/m/h
794	Time 1 Timer 2, signal delay	0.00 s/m/h	650.00 s/m/h	0.00 s/m/h
795	Time 2 Timer 2, signal duration	0.00 s/m/h	650.00 s/m/h	0.00 s/m/h

Examples of the timer function depending on the selected operation mode and the input signal:

Normal, positive edge

Parameter *Operation Mode Timer 1* **790** or *Operation Mode Timer 2* **793** = 1




As soon as the positive signal edge is received at the input, time 1 is started. Once the Time 1 (signal delay) has elapsed, the output signal will be switched for Time 2 (signal duration).

In the settings for signal duration (*Time 2 Timer 1* **792** = 0 and *Time 2 Timer 2* **795** = 0), the output signal will not be reset.

Retrigger, positive edge

Parameter *Operation Mode Timer 1* **790** or *Operation Mode Timer 2* **793** = 2



As soon as the positive signal edge is received at the input, time 1 is started. If a positive signal edge is detected within the signal delay (Time 1), Time 1 will start again (Retrigger). Once the Time 1 (signal delay) has elapsed, the output signal will be switched for Time 2 (signal duration).


In the settings for signal duration (*Time 2 Timer 1* **792** = 0 and *Time 2 Timer 2* **795** = 0), the output signal will not be reset.

←.....: Time not run out completely

←————→: Time run out completely

AND connection, positive edge

Parameter *Operation Mode Timer 1* **790** or *Operation Mode Timer 2* **793** = 3




- 1) As soon as the positive signal edge is received at the input, time 1 is started.
- 2) If a positive signal edge is detected within the signal delay (Time 1), Time 1 will start again (Retrigger).
- 3) Once the Time 1 (signal delay) has elapsed, the output signal will be switched for Time 2 (signal duration).
- 4) Within the signal duration time 2, the output is switched off by the input signal (AND connection).
- 5) If the input signal is present during the whole signal duration (Time 2), the output signal remains on in this time.

←-----: Time not run out completely

←----->: Time run out completely

Factory settings: Time 1 = 0, Time 2 = 0



In the default settings, the output signal will follow the input signal.

16.5.2 Comparator

With the help of software functions Comparator 1 and 2, various comparisons of actual values with percentage-adjustable fixed values can be done.

The actual values to be compared can be selected from the following table with the *parameters Op. Mode Comparator 1* **540** and *Op. Mode Comparator 2* **543**.

If an extension module is connected, further operation modes are available.

Operation mode 540, 543	Function
0 - off	Comparator is switched off.
1 - Absolute current	R.m.s Current 211 > Rated Current 371v
2 - Abs. Active Current	Active Current 214 > Rated Current 371.
3 - Abs. Stator Frequency	Stator Frequency 210 > Maximum Frequency 419.
4 - Abs. Actual Speed 1	Encoder 1 Speed 218 > max. speed (calculated from Maximum Frequency 419 and No. of Pole Pairs 373) .
5 - Abs. Actual Repetition Freq.	Repetition Frequency Input 252 > Maximum Frequency 419.
6 - Winding Temperature, Temp. Follow-Up	Winding Temperature 226 > Temperature 100 °C.
7 - Abs. Actual Frequency	Actual Frequency 241 > Maximum Frequency 419.
9 - DC-Link Voltage	DC-Link Voltage 222 > direct voltage 1000 V.
10 - Abs. Isq	Isq 216 > Rated Current 371.
11 - Abs Filtered Active Current	Active Current 214 > Rated Current 371.
12 - Abs. Internal Ref. Frequency	Internal Reference Frequency 228 > Maximum Frequency 419.
13 - Abs. Ref. Percentage Value	Reference Percentage Value 229 > Maximum Reference Percentage 519.


Operation mode 540, 543	Function
14 - Abs. Actual Percentage Value	Actual Percentage Value 230 > Maximum Reference Percentage 519.
15 - Analog Input MFI1A Abs. value	Analog Input MFI1A 251 > input signal 100%.
100 to 107, 111, 112	Operation modes with signs (+/-).

The switch-on and switch-off thresholds for Comparators 1 and 2 are set via parameters *Comparator On above* **541**, 544 and *Comparator Off below* **542**, 545.

The percentage limits of the corresponding reference values are indicated.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
541	Comparator 1 On above	- 300.00%	300.00%	100.00%
542	Comparator 1 Off below	- 300.00%	300.00%	50.00%
544	Comparator 2 On above	- 300.00%	300.00%	100.00%
545	Comparator 2 Off below	- 300.00%	300.00%	50.00%

The setting of the percentage limits of the comparators enables the following logical links. The comparison with signs is possible in the corresponding operation modes of the comparators.



Example:

Op. Mode Comparator 1 **540** = Abs. Actual Frequency

Comparator On above **541** = 80.00 % (referred to *Maximum Frequency* **419**)

Comparator Off below **542** = 50.00 % (referred to *Maximum Frequency* **419**)

Maximum Frequency **419** = 50.00 Hz

➔ Comparator is switched on when *Actual Frequency* **241** > 40.00 Hz

➔ Comparator is switched off when *Actual Frequency* **241** > 25.00 Hz

Output signals

The result of the comparison is reported via digital signals.

Comparator 1

171 -	Output Comparator 1	¹⁾	The comparison according to the selected <i>Op. Mode</i>
20 -	Comparator 1	²⁾	<i>Comparator 1</i> 540 – is true.
172 -	Negated Output Comparator 1	¹⁾	The comparison according to the selected <i>Op. Mode</i>
			<i>Comparator 1</i> 540 – is true. The output level of the comparator is inverted.

Comparator 2

173 -	Output Comparator 2	¹⁾	The comparison according to the selected <i>Op. Mode</i>
21 -	Comparator 2	²⁾	<i>Comparator 2</i> 543 – is true.
174 -	Negated Output Comparator 2	¹⁾	The comparison according to the selected <i>Op. Mode</i>
			<i>Comparator 2</i> 543 – is true. The output level of the comparator is inverted.

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.

16.5.3 Table of functions

With the table of functions, external analog or digital signals and internal logic signals of the frequency inverter can be linked to one another. Apart from standard AND, OR and XOR combinations, various complex logic functions such as RS Flip Flop are available. The corresponding output value can be used for other logic instructions and digital outputs. Logic instructions can be combined to one another so that any complex links can be realized.

Up to 32 instructions enable flexible adjustment for linking different input signals.

Analog functions include, for example, comparisons of analog input values, mathematical functions, PID control functions, filters, control of positioning functions limitations, switches and counters.

Example:

A drive is to start if

- release is given AND S5IND is set
- OR
- release is given AND S6IND and MFI1D are set.

For a detailed description, refer to the application manual "Function Table".

16.5.4 Multiplexer/demultiplexer

The multiplexer/demultiplexer enables the transfer of various digital signals between an overriding controller and frequency inverters via field bus or between frequency inverters via the system bus. For parameterization of the multiplexer and demultiplexer using the VTable application, the commissioning and diagnosis software VPlus, version 4.0.2 or higher is required.

Multiplexer:

The multiplexer features 16 inputs for logic signals or digital input signals.

On the output, the logic signal 927 – Output MUX for the inputs of the TxPDO process data of the system bus or for PZDx-IN process data of the Profibus can be used.

Operation mode		Factory setting	
1252	Mux inputs	7 -	off

Parameters *Mux Input Index (write)* **1250** and *Mux Input Index (read)* **1251** for the input signals of the multiplexer enable parameterization via the control unit KP500 or the application VTable in VPlus.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
1250	Mux input index (write) ¹⁾	0	33	1
1251	Mux input index (read)	0	33	1

¹⁾ non-volatile (fixed parameterization):		Volatile:	
0:	all indices in EEPROM	17:	all indices in RAM
1...16:	On index in EEPROM	18...33:	Index 1...16 in RAM

NOTICE

Setting "0" for *Mux Input Index (write)* **1250** will change all data in EEPROM and RAM.

In the case of non-volatile storage (0..16), the changed values are still available when power supply is switched on again.

In the case of volatile storage (17...33), the data is only stored in RAM. If the unit is switched off, this data is lost and the data required are loaded from EEPROM.

Demultiplexer:


The demultiplexer features an input *DeMux Input* **1253** whose signal can be for the process data RxPDO of the system bus or OUT-PZDx of Profibus.

On the output of the demultiplexer, the logic signals „910 – Output DeMux Bit 0“ to „925 – Output DeMux Bit 15“ are available, e.g. for control of FT-instructions.

Operation Modes for DeMux Input 1253	
9 -	Zero
704 ... 727 -	RxPDO Word
740, 741 -	Remote control word , remote state word
754 ... 757 -	OUT-PZD word
900 -	Controller Status
927 -	Output MUX

Demultiplexer outputs	
910 ... 925 -	Output DeMux Bit 0 ... output DeMux Bit 15

Example: Transfer of a user-defined status word from a slave to a master via system bus or Profibus, parameterization of multiplexer and demultiplexer using PC application VTable in VPlus



Settings on transmitter:

In VPlus, start application VTable via the button bar.

In VTable assign the required signal sources for sending to parameter *Mux Input* **1252** index 1 to index 16. (a setting for index 0 results in this setting being taken over for all other indices.)

Assign signal source „927 – Output MUX“ to a TxPDO process data parameter of the system bus or a PZDx-IN process data parameter of Profibus.

Settings on receiver:

Assign the corresponding RxPDO signal sources of the system bus or OUT-PZD signal sources of Profibus to parameter *DeMux Input* **1253**.


The transmitted signals are available at the receiver as signal sources 910 to 925.

17 V/f characteristic

The sensorless control in configurations 110 and 111 is based on the proportional change of output voltage compared to the output frequency according to the configured characteristic.

By setting the V/f-characteristic, the voltage of the connected 3-phase motor is controlled according to the frequency. The torque to be applied by the motor at the corresponding operating point demands the control of the output voltage proportional to the frequency. At a constant output voltage / output frequency ratio of the frequency inverter, the magnetization is constant in the nominal operating range of the 3-phase motor. The rating point of the motor or end point of the V/f-characteristic is set via the guided commissioning with parameter *Cut-Off Voltage* **603** and parameter *Cut-Off Frequency* **604**.

The lower frequency range, where an increased voltage is necessary for the start of the drive, is critical. The voltage at output frequency = zero is set with the parameter *Starting Voltage* **600**. A voltage increase deviating from the linear course of the V/f characteristic can be defined by parameters *Voltage Rise* **601** and *Rise Frequency* **602**. The parameter value percentage is calculated from the linear V/f characteristic. Via parameters *Minimum Frequency* **418** and *Maximum Frequency* **419**, the working range and/or V/f characteristic are defined.



(FMIN): *Minimum Frequency* **418**, (FMAX): *Maximum Frequency* **419**,

(US): *Starting Voltage* **600**,

(UK): *Voltage Rise* **601**, (FK): *Rise Frequency* **602**

(UC): *Cut-Off Voltage* **603**, (FC): *Cut-Off Frequency* **604**

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
600	Starting voltage	0.0 V	100.0 V	5.0 V
601	Voltage rise	-100 %	200 %	10 %
602	Rise frequency	0 %	100 %	20 %
603	Cut-off voltage	60.0 V	560.0 V	400.0 V
604	Cut-off frequency	0.00 Hz	599.00 Hz	50.00 Hz



The guided commissioning takes the parameterized rated motor values and reference data of the frequency inverter into account when it comes to pre-setting the V/f-characteristic. In the case of asynchronous machines, the speed can be increased at a constant torque if the motor winding can be switched over from star to delta connection. If the data for delta connection indicated on the rating plate of the three-phase motor were entered, the cut-off frequency is increased automatically by the square root of three.

The default *Cut-Off Voltage* **603** (UC) and *Cut-Off Frequency* **604** (FC) are derived from the motor data *Rated Voltage* **370** and *Rated Frequency* **375**. With the parameterized *Starting Voltage* **600** (US), the linear equation of the V/f-characteristic results.

$$U = \left(\frac{UC - US}{FC - 0} \right) \cdot f + US = \left(\frac{400,0V - 5,0V}{50,00Hz - 0,00Hz} \right) \cdot f + 5,0V$$

The *Rise Frequency* **602** (FK) is entered as a percentage of the *Cut-Off Frequency* **604** (FC), the default value is $f=10$ Hz. The output voltage for the default *Voltage Rise* **601** (UK) is calculated as $U=92.4V$.

$$U = \left[\left(\frac{UC - US}{FC - 0} \right) \cdot (FK \cdot FC) + US \right] \cdot (1 + UK) = \left[\left(\frac{400V - 5V}{50Hz - 0Hz} \right) \cdot (0,2 \cdot 50Hz) + 5V \right] \cdot 1,1 = \underline{\underline{92,4V}}$$

17.1 Dynamic voltage pre-control

The *Dyn. Voltage Pre-Control* **605** accelerates the control behavior of the current limit controller (parameter *Operation Mode* **610**) and the voltage controller (parameter *Operation Mode* **670**). The output voltage value resulting from the U/F characteristic is changed by addition of the calculated voltage pre-control.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
605	Dyn. Voltage Pre-Control	0 %	200 %	100 %

18 Control functions

The frequency inverters provide a selection of established control methods in *Configuration 30*. The selected control structure can be parameterized as required and optimized for the application by further functions.

18.1 Intelligent current limits

The current limits to be set according to the application avoid inadmissible loading of the connected load and prevent a fault switch-off of the frequency inverter. The function extends the current controller available in the control system. The specified overload reserve of the frequency inverter can be utilized optimally using the intelligent current limits, particularly in applications with dynamic load changes. The criterion to be selected via *parameter Operation Mode 573* defines the threshold to the activation of the intelligent current limit. The parameterized rated motor current or the reference current of the frequency inverter is synchronized as the limit value of the intelligent current limits.

Operation Mode 573	Function
0 - off	The function is switched off.
1 - Ixt	Limitation to the overload of the frequency inverter (Ixt).
10 - Tc	Limitation to the maximum heat sink temperature (T_C)
11 - Ixt + Tc	Operation mode 1 and 10 (Ixt + T_C)
20 - Motor temp.	Limitation to motor temperature (T_{Motor})
21 - Motor temp. + Ixt	Operation mode 20 and 1 (T_{Motor} + Ixt)
30 - Tc + Motor temp.	Operation mode 10 and 20 (T_C + T_{Motor})
31 - Tc + Motor temp. + Ixt	Operation mode 10, 20 and 1 (T_C + T_{Motor} + Ixt).

The threshold selected via *parameter Operation Mode 573* is monitored by the intelligent current limits. In the operation modes with motor and heat sink temperature monitoring, the reduction of power selected with the parameter *Power Limit 574* is done when the threshold value has been reached. This is achieved by a reduction of the output current and the speed in motor operation. The load behavior of the connected machine must be a function of the speed to ensure a sensible use of the intelligent current limits. The total time of the power reduction as a result of an increased motor or heat sink temperature contains not only the cooling time, but also the additionally defined *Limitation Time 575*.

The definition of the power limit should be selected as small as possible in order to give the drive sufficient time to cool down. The reference value is the rated output of the frequency inverter or the set rated power of the motor.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
574	Power Limit	40.00%	95.00%	80.00%
575	Limitation Time	5 min	300 min	15 min

In the operation modes with overload reserve (Ixt), the output current will be reduced if the threshold is exceeded. A distinction is made in this context between long-time and short-time overload reserve. After the short-term overload (1s) has been used up, the output current is reduced to the long-term overload current matching the present switching frequency. After the long-term overload current has been used up (60s), the output current is reduced to the rated current which also depends on the switching frequency.

If the output current has already been reduced due to the fact that the long-term overload has been used up, the short-term overload is no longer available even if it has not been used up beforehand. The defined overload reserve (Ixt) of the frequency inverter is available again after 10 minutes of operation at reduced power.

Output signals

Reaching of a limit – selected in *Operation Mode 573* – can be signaled via digital outputs.

15 -	Warning current limitation	The intelligent current limits limit the output current.
16 -	Controller current limit. long term Ixt	The overload reserve for 60 s has been used up and the output current is being limited.
17 -	Controller current limit. short term Ixt	The overload reserve for 1 s has been used up and the output current is being limited.
18 -	Controller current limit Tk	Max. heat sink temperature T_K reached. Intelligent current limits are active.
19 -	Controller current limit. motor temp.	Max. heat sink temperature T_{PTC} reached. Intelligent current limits are active.

18.2 Voltage controller

The voltage controller contains the functions necessary for monitoring the DC link voltage.

The DC link voltage which rises in generator operation or in the braking process of the 3-phase machine is controlled to the set limit value by the voltage controller.

The power failure regulation uses the rotation energy of the drive to bridge short-term power failures.

The voltage controller is set with the parameter *Operation Mode* **670** in accordance with the application.

Operation Mode 670	Function
0 - off	The function is switched off. Brake and motor chopper are active and switch at the thresholds parameterized with P.506 and P.507 .
1 - DC link limitation active	Overvoltage controller switched on. Brake and motor chopper are active and switch at the thresholds parameterized with P.506 and P.507 . Factory setting.
2 - Mains Support active	Mains failure regulation turned on. Brake and motor chopper are active and switch at the thresholds parameterized with P.506 and P.507 . Can be used for quick shutdown.
3 - Udc-Limit. & Mains Supp. active	Overvoltage controller and power failure regulation switched on, with motor chopper.
12 - Mains support active, without chopper	Mains failure regulation turned on. During mains support, the brake and motor chopper are deactivated. In all other cases, the brake and motor chopper are active and switch at the thresholds parameterized with P.506 and P.507 .
13 - Udc-Limit. & Mains Supp. active without chopper	Overvoltage controller and power failure regulation switched on. During mains support, the brake and motor chopper are deactivated. In all other cases, the brake and motor chopper are active and switch at the thresholds parameterized with P.506 and P.507 .



In ACU 501 and 601, mains failure regulation is effected via the DC link capacitor for a maximum of 1 second. In the case of long mains failures, mains failure regulation cannot be guaranteed.

The function motor chopper is available in the field-oriented control methods (in configurations 210, 230, 410, 411 and 430).

When an operation mode with motor chopper is selected, set *Trigger Threshold* **507** < (*Reference DC-Link Limitation* **680** – 10 V). See Chapter 19.7.1 "19.7.1".




For synchronous motors (*Configuration* **30**=610), the motor chopper feature is deactivated to prevent the motor from being damaged. The other functions of the voltage controller are not affected by this.

For asynchronous motors in V/f control (*Configuration* **30**=110), the motor chopper feature is deactivated. The other functions of the voltage controller are not affected by this.



The brake chopper is active depending on the setting of *Operation Mode* **670**. For parameterization of the switching threshold, refer to Chapter 19.4 "19.4".

Operation mode overvoltage control,
Voltage controller: Parameter *Operation Mode* **670** = 1




The overvoltage controller prevents a switch-off of the frequency inverter in generator operation. The reduction of the drive speed by a ramp gradient selected via the parameter *Deceleration (Clockwise)* **421** and *Deceleration Anticlockwise* **423** can lead to an overvoltage in the DC link. If the voltage exceeds the figure set by the parameter *Reference DC-Link Limitation* **680**, the deceleration is reduced in such a way that the DC link voltage is regulated to the set value. If the DC link voltage cannot be regulated to the set reference value by the reduction of the deceleration, the deceleration is stopped and the output frequency raised. The output frequency is calculated by addition of the parameter value *Max. Frequency Rise* **681** to the frequency at the operating point of the controller intervention.

Parameter		Setting			
No.	Description	ACU	Min.	Max.	Factory setting
680	Reference DC link limitation	201	225.0 V	387.5 V	380.0 V
		401	425.0 V	775.0 V	760.0 V
		501	550.0 V	875.0 V	860.0 V
		601	725.0 V	1175.0 V	1160.0 V
681	max. frequency rise	all	0.00 Hz	599.00 Hz	10.00 Hz

For reliable operation of the overvoltage control, Bonfiglioli Vectron MDS GmbH recommends setting the motor chopper *Trigger Threshold* **507** < (*Reference DC-Link Limitation* **680** – 10 V) . Refer to Chapter 19.7.1 "19.7.1".

Operation mode power failure regulation.

Voltage controller: Parameter *Operation Mode* **670** = 2



With mains failure regulation, short-term power failures can be bridged. Mains failure is detected when the DC link voltage has dropped below the set value of parameter *Mains Failure Threshold* **671**. If a mains failure is detected, the controller tries to regulate the DC link voltage to the value set with parameter *Reference Mains Support Value* **672**. To that end, the output frequency is continuously reduced and the motor with its rotating masses is switched over to generator operation. In field-oriented control methods (2xx, 4xx, 5xx), the output frequency reduction is done at a current not exceeding the maximum set with parameter *Gen. Ref. Current Limit* **683**.



Gen. Ref. Current Limit **683** is active in Configuration 210, 410, 510 and 610 (FOR and SERVO).

The threshold values of the voltage controller are calculated starting with the current DC link voltage with parameters *Mains Failure Threshold* **671** and *Reference Mains Support Value* **672**.

Output signals

Mains failure and mains support are signaled via digital signals.

179 - Power Failure	¹⁾	Failure of the mains voltage and power regulation – selected via
13 - Power Failure	²⁾	<i>Operation Mode</i> 670 of voltage controller .

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.


If the mains voltage is restored before a switch-off is effected by the mains undervoltage detection system, the drive is accelerated to its reference frequency at the set acceleration or according to parameter *Acceleration on Mains Resumption* **674**. If the value of parameter *Acceleration on Mains Resumption* **674** is set to the default value of 0.00 Hz/s, the drive is accelerated at the values set for the ramp parameters *Acceleration (Clockwise)* **420** or *Acceleration Anticlockwise* **422**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
671	Mains failure threshold	-200.0 V	-50.0 V	-100.0 V
672	Reference mains support value	-200.0 V	-10.0 V	-40.0 V



The frequency inverter reacts to the signals at the control inputs both when the power failure regulation is switched on and in normal operation. A control via externally supplied control signals is only possible in the case of a no-break supply. As an alternative, supply of the control signals through the frequency inverter is to be used.

Operation mode power failure regulation



The DC link voltage which is available in the case of a power failure is supplied by the motor. The output frequency is continuously reduced and the motor with its rotating masses is switched over to generator operation. The reduction of the output frequency is done at a current not exceeding the maximum set with parameter *Gen. Ref. Current Limit* **683** or the ramp *Mains Support Deceleration* **673**. *Mains Support Deceleration* **673** is active only if the actual frequency is lower than the *Shutdown Threshold* **675**.

The time required until the motor has come to a standstill results from the regenerative energy of the system which results in an increase in the DC link voltage. The DC link voltage set with the parameter *Reference Shutdown Value* **676** is used by the voltage controller as a control figure and kept constant. The voltage rise enables optimization of the braking behavior and the time until the drive has come to a standstill. The behavior of the controller can be compared to stopping behavior 2 (Shutdown and Stop), as the voltage controller brings the drive to a standstill at the maximum deceleration ramp and supplies it with the remaining DC link voltage.

If the DC-Link Voltage is restored before the drive has stopped, but after dropping below the *Shutdown Threshold* **675**, the drive will be decelerated until it stops.

If the mains voltage is restored after the shutdown of the drive but before the undervoltage switch-off has been reached, the frequency inverter signals a fault. The control unit displays the error signal "F0702".

If the mains failure without shutdown (*Shutdown Threshold* **675** = 0 Hz) takes so long that the frequency has been reduced to 0 Hz, the drive is accelerated to the reference frequency when the mains supply is restored.

If the mains failure with or without shutdown takes so long that the frequency inverter shuts off completely (LED's = OFF), the frequency inverter will be in the "Standby" state when the mains supply is restored. If the inverter is released again, the drive will start. If the drive is to start automatically after restoration of the mains supply if the inverter is released permanently, *Operation Mode* **651** of Auto Start must be switched on.

Parameter		Setting			
No.	Description	ACU	Min.	Max.	Factory setting
675	Shutdown threshold	all	0.00 Hz	599.00 Hz	0.00 Hz
676	Reference shutdown value	201	225.0 V	387.5 V	365.0 V
		401	425.0 V	775.0 V	730.0 V
		501	550.0 V	875.0 V	830.0 V
		601	725.0 V	1175.0 V	1130.0 V



The *Shutdown Threshold* **676** becomes effective below the frequency value *Shutdown Threshold* **675**.

The voltage controller uses the limit values of the DC link voltage. *Acceleration on Mains Resumption* **674** replaces - if the default value is changed - the set ramp parameter values *Acceleration (Clockwise)* **420** or *Acceleration Anticlockwise* **422**. The voltage control in a mains failure changes from the frequency limit *Shutdown Threshold* **675** from *Reference Mains Support Value* **672** to *Reference Shutdown Value* **676**. The value of *Gen. Ref. Current Limit* **683** (2xx, 4xx, 5xx) or the ramp *Mains Support Deceleration* **673** (V/f) defines the maximum deceleration gradient to the *Reference Shutdown Value* **676**. *Mains Support Deceleration* **673** is only active if the actual frequency is smaller than *Shutdown Threshold* **675**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
683	Gen. Ref. Current Limit	0.0 A	$0 \cdot I_{FIN}$	I_{FIN}
673	Mains support deceleration	0.01 Hz/s	9999.99 Hz/s	50.00 Hz/s
674	Acceleration on mains resumption	0.00 Hz/s	9999.99 Hz/s	0.00 Hz/s



Mains Support Deceleration **673** is active in Configuration 1xx (V/f).

Gen. Ref. Current Limit **683** is active in Configuration 2xx, 4xx, 5xx and 6xx (FOR and SERVO).

The proportional and integrating component of the current controller can be set via parameters *Amplification* **677** and *Integral Time* **678**. The control functions are deactivated by setting the parameters to 0. The controllers are P and I controllers in the corresponding settings.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
677	Amplification	0.00	30.00	1 ¹⁾
				2 ²⁾
678	Integral Time	0 ms	10000 ms	8 ms ¹⁾
				23 ms ²⁾

The factory settings depend on the selected configuration and control procedure. According to the setup of parameter *Configuration* **30**, there is the following assignment.


¹⁾ Configurations 1xx

²⁾ Configurations 4xx, 2xx, 5xx, 6xx

18.3 Technology controller

The technology controller, the behavior of which corresponds to a PID controller, is available as an additional function in configuration 111, 211, 411, 511 and 611. The connection of reference and actual value of the application with the functions of the frequency inverter enables process control without further components. In this way, applications such as pressure, volume flow or speed control can be implemented easily. The configuration of the reference percentage source and the assignment of the actual percentage source are to be considered.

Structural image: Technology controller



Note the chapters indicated in the table:

Parameter	Chapter
Controller setpoint:	
<i>Reference Percentage Source 476</i>	15.5 "15.5"
Displays the current controller setpoint:	
<i>Reference Percentage Value 229</i>	20.1 "20.1"
Actual controller value:	
<i>Actual Percentage Source 478</i> is:	18.3 "18.3"
- Analog signal at multifunction input:	
<i>Operation Mode 452</i>	16.1 "16.1"
- Frequency signal at digital input:	
<i>Operation Mode 496</i>	15.11 "15.11"
Displays the current actual controller value:	
<i>Actual Percentage Value 230</i>	20.1 "20.1"

For the reference value, the technology controller also demands the assignment of an analog application figure with parameter *Actual Percentage Source 478*. The difference between reference and actual value is used by the technology controller to control the drive system. The measured actual value is mapped via a signal converter onto the input signal of the reference percentage source.

Actual Percentage Source 478	Function
1 - Analog Input MFI1A	The analog signal on multifunction input 1 in analog Operation Mode 452.
32 - Repetition frequency input (F3)	The frequency signal on the digital input corresponding to the selected Operation Mode 496.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
58	Technology Controller Release	Selection		6 - On

Via parameter *Technology Controller Release 58* , you can stop the technology controller. The current P and D portions are kept at the last value before shutdown. The output value and the I portion will be deleted when *Technology Controller Release 58* is turned off.




Note the default link of parameter *Start Clockwise 68* to the logic signal of the technology controller:

Start Clockwise 68 = "13 – Technology Controller Start".

This link must not be changed. The technology controller becomes active with the controller release at digital input S1IND/STOA.

Structural image: Inputs for reference percentage source



The function selected via the parameter *Operation Mode 440* defines the behavior of the technology controller.

Operation Mode 440	Function
0 - off	The technology controller is switched off, the reference value specification is done via the reference percentage channel.
1 - Standard	For pressure and volume flow control with linear operating behavior and actual value monitoring
2 - Liquid Level 1	Liquid Level control at defined motor speed with actual value missing
3 - Liquid Level 2	Liquid Level control at defined motor speed with actual value missing or high control deviation
4 - Speed controller	Speed control with analog feedback of the actual speed
5 - Indirect Volume Flow Control	Volume flow control with square rooted actual value.

The behavior of the technology controller corresponds to a PID controller with portions

- Proportional component *Amplification* **444**
- Integral component *Integral Time* **445**
- Differential component *Derivative Time* **618**

The sign of the amplification defines the control direction, i.e. if the actual value increases and the sign of the amplification is positive, the output frequency is reduced (e.g. pressure control). With a rising actual value and negative sign of the amplification, the output frequency is increased (e.g. in temperature control systems, refrigerating machines, condensers).

The integral component can be used in order to reduce the stationary error (deviation between actual value and setpoint) over time. If the integral component is too dynamic¹⁾, the system may become unstable and vibrate. If the integral component is too passive²⁾, the stationary error is not compensated sufficiently.

For this reason, the integral portion must be adjusted plant-specifically.

¹⁾ Dynamic behavior: Quick compensation of deviations.

²⁾ Passive behavior: Slow compensation of deviations.

By default, the differential component is set to *Derivative Time* **618** = 0 ms, i.e. it is deactivated.

If the compensation behavior of the PI controller (or P controller) is too slow, quicker compensation can be reached by activating and adjusting the differential component (*Derivative Time* **618**). However, if the differential component is activated, the system has a higher tendency toward vibration. For this reason, the differential component should be activated and changed carefully.

Bonfiglioli Vectron MDS GmbH recommends setting the times *Integral Time* **445** for the integral component and *Derivative Time* **618** for the differential component to a value which exceeds the sampling time which is 2 ms in the case of the ACU device.

Parameter *Max. P-Component* **442** limits the frequency change at the controller output. This prevents vibrations of the system if steep acceleration ramps were selected.

Parameter *Hysteresis* **443** enables suppressing changes of the integral component outside of a certain range (hysteresis range). This enables a more passive behavior of the technology controller. This may be useful if the stator frequency cannot follow the reference frequency of the technology controller. The *Hysteresis* **443** is referred, as a percentage, to the *Rated Frequency* **375**, i.e. typically 50 Hz.

The hysteresis is a limiting factor at the input of the integral component. High differences between the current stator frequency and the technology controller output are limited in this way, excessive integrating of the integral component is prevented.


$\left \frac{f_{tech} - f_{stator}}{Rated\ frequency\ 375} \right \geq Hysteresis\ 443$	<p>The deviation Δ between the technology controller reference frequency (f_{tech}) and the stator frequency (f_{stator}) is too large. The integrator is stopped.</p>
$\left \frac{f_{tech} - f_{stator}}{Rated\ frequenz\ 375} \right < Hysteresis\ 443$	<p>The stator frequency (f_{stator}) can follow the technology controller reference frequency (f_{tech}) sufficiently. The deviation Δ is small enough.</p>

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
441	Fixed frequency	-599.00 Hz	+599.00 Hz	0.00 Hz
442	max. P component	0.01 Hz	599.00 Hz	50.00 Hz
443	Hysteresis	0.01 %	100.00 %	10.00 %
444	Amplification	-15.00	+15.00	1.00
445	Integral Time	0 ms	32767 ms	200 ms
446	Ind. volume flow control factor	0.10	2.00	1.00
618	Derivative action time	0 ms	1000 ms	0 ms

In Operation Modes 1,2,3 and 5 the output frequency is shifted on the y-axis by the *Minimum Frequency* **418**. The technology controller output value in percent thus is:

0 % = *Minimum Frequency* **418**

100 % = *Maximum Frequency* **419**



The parameterization of the technology controller in the individual data sets enables an adaptation to various operating points of the application with the data set change-over via control contacts.




The technology controller works in clockwise motor sense of rotation. The sense of rotation can be reversed via parameter *Change Sense of Rotation* **1199**. See Chapter 11.2.8 "11.2.8".

Operation Mode Standard, Parameter Operation Mode 440 = 1

This operation mode can be used, for example, for pressure or volumetric flow control with linear operation behavior.

The minimum value monitoring prevents an acceleration of the drive if the actual value is missing.

If the actual value is missing ($< 0.5\%$) the output frequency is guided to the *Minimum Frequency* **418**. This is done using the set *Deceleration (Clockwise)* **421**. If the actual value is available again, the controller continues operation automatically.



Operation Mode Liquid Level 1, Parameter Operation Mode 440 = 2

This operation mode can be used, for example, for Liquid Level control.


If the actual value is missing, the function brings the output frequency to an adjustable value.

The minimum value monitoring prevents an acceleration of the drive if the actual value is missing.

If the actual value is missing ($< 0.5\%$) the output frequency is guided to the *Fixed Frequency* **441**. This is done using the set *Deceleration (Clockwise)* **421**.

The *Fixed Frequency* **441** must be in the range between *Minimum Frequency* **418** and *Maximum Frequency* **419**. If the *Fixed Frequency* **441** is smaller than the *Minimum Frequency* **418**, the output frequency is guided to the *Minimum Frequency* **418**. The frequency will not drop below the *Minimum Frequency* **418**.

If the actual value is available again, the controller continues operation automatically. The integral component is reset once the actual value is restored.



Operation Mode Liquid Level 2, Parameter Operation Mode 440 = 3


This operation mode can be used, for example, for Liquid Level control.

The minimum value monitoring prevents an acceleration of the drive if the actual value is missing.

If the actual value is missing ($< 0.5\%$) the output frequency is guided to the *Fixed Frequency* **441**. This is done using the set *Deceleration (Clockwise)* **421**.

If there is no control deviation (actual value = reference value) or if the control deviation is negative (actual value > reference value), the output frequency is guided to *Minimum Frequency* **418**. This is done using the selected controller settings. In addition, the ramp is limited by *Deceleration (Clockwise)* **421**. If *Minimum Frequency* **418** = 0, the output stage will be turned off in this case.


The drive accelerates as soon as an actual value is present again or the control deviation exceeds the positive *Hysteresis* **443**. The drive stops if actual value \geq setpoint, the controller output has reached 0 Hz and *Minimum Frequency* **418** = 0.



Operation Mode Speed Controller, parameter Operation Mode 440 = 4

This operation mode is suited for speed controls with an analog actual value transmitter (e.g. analog speedometer via analog input or HTL encoder via frequency input). The motor is accelerated or decelerated according to the control deviation.

The output frequency is limited by the *Maximum Frequency* **419**.



NOTE

Minimum Frequency **418** has no limiting effect in Operation Mode "4-Speed Controller". In Configurations 411, 511 and 611 this can result in longer operation of the motor in current impression mode (current frequency < *Frequency Limit* **624**). Prevent excessive motor heat-up by long current impression operation.

Operation Mode "4-Speed Controller" can result in reversal of the drive.


**Operation Mode Indirect Volume Flow Control,
parameter Operation Mode 440 = 5**

This operation mode is suitable for volume flow control based on pressure measurement.


The square rooted actual value enables, for example, direct measurement of the active pressure in the system via the intake nozzle of the fan. The active pressure has a square proportion to the volume flow and thus forms the control figure for the volume flow control. The calculation corresponds to the "Law of Proportionality" which is generally valid for centrifugal machines.

Adjustment to the application and measurement is done via *Ind. Volume Flow Control Factor 446*. The actual values are calculated from the system data to be parameterized, reference pressure and volume flow, according to the bad point method, as described in chapter 20.4.2 "20.4.2".

The output frequency is limited by *Minimum Frequency 418* and *Maximum Frequency 419*.



Structural image: Indirect Volume Flow Control



18.4 Functions of sensorless control

The configurations of the sensorless control contain the following additional functions, which supplement the behavior according to the parameterized V/f characteristic.

18.4.1 Slip compensation

The load-dependent difference between the reference speed and the actual speed of the 3-phase motor is referred to as the slip. This dependency can be compensated by the current measurement in the output phases of the frequency inverter.

Activation of *Operation Mode 660* for the slip compensation enables as speed control without feedback. The stator frequency and speed are corrected as a function of the load.

Slip compensation is turned on during guided commissioning. The *Stator Resistance 377* is required to ensure a correct function and is measured during guided commissioning.

If guided commissioning is not performed, slip compensation can also be activated manually. In this case enter the *Stator Resistance 377* manually, refer to motor data sheet.

Operation Mode 660	Function
0 - off	The slip compensation is deactivated.
1 - On	The load-dependent slip speed is compensated

The control behavior of the slip compensation can only be optimized via the parameters in the case of specific applications. Parameter *Amplification 661* determines the correction of the speed and the effect of the slip compensation proportionally to the change of load. *Max. Slip Ramp 662* defines the max. frequency change per second in order to avoid an overload in the case of a load change.

Parameter Minimum Frequency 663 determines the frequency as from which the slip compensation becomes active.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
661	Amplification	0.0 %	300.0 %	100.0 %
662	Max. slip ramp	0.01 Hz/s	650.00 Hz/s	5.00 Hz/s
663	Minimum frequency	0.01 Hz	599.00 Hz	0.01 Hz

18.4.2 Current limit value controller

Via a load-dependent speed control, the current limit value controller ensures that the drive system is not overloaded. This is extended by the intelligent current limits described in the previous chapter. The current limit value controller reduces the load on the drive, e.g. during acceleration, by stopping the acceleration ramp. The switch-off of the frequency inverter which happens when the acceleration ramps have been set at an excessive gradient is prevented in this way.

The current limit value controller is switched on and off via parameter *Operation Mode* **610**.

Operation Mode 610	Function
0 - off	The current limit value controller functions and the intelligent current limits have been deactivated.
1 - On	The current limit value controller is active.

Behavior in motor operation:

If the current set via parameter *Current Limit* **613** is exceeded, the activated current limit value controller will reduce the output frequency until the current limit is no longer exceeded. The output frequency is reduced as a maximum to the frequency set by the parameter *Frequency Limit* **614**. If the current value drops below the *Current Limit* **613** the output frequency is increased to the setpoint again.

Behavior in generator operation:

If the current set via parameter *Current Limit* **613** is exceeded, the activated current limit value controller will increase the output frequency until the current limit is no longer exceeded. The output frequency is increased, as a maximum, to the set *Maximum Frequency* **419**. If the current value drops below the *Current Limit* **613**, the output frequency is reduced to the required reference value again.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
613	Current Limit	0.0 A	0·I _{FIN}	0·I _{FIN}
614	Frequency Limit	0.00 Hz	599.00 Hz	0.00 Hz

The control behavior of the current limit controller can be set via the proportional component, parameter *Amplification* **611**, and the integrating component, parameter *Integral Time* **612**. If an optimization of the controller parameters is necessary in exceptional cases, a setting should be made by way of erratic changes of parameter *Current Limit* **613**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
611	Amplification	0.01	30.00	1.00
612	Integral Time	1 ms	10000 ms	24 ms



The dynamism of the current limit value controller and the voltage controller is influenced by the setting of the parameter *Dyn. Voltage Pre-Control* **605**.

18.5 Functions of field-oriented control

The field-oriented control systems are based on a cascade control and the calculation of a complex machine model. In the course of the guided commissioning, a map of the connected machine is produced by the parameter identification and transferred to various parameters. Some of these parameters are visible and can be optimized for various operating points.

18.5.1 Current controller

The inner control loop of the field-oriented control comprises two current controllers. The field-oriented control thus impresses the motor current into the machine via two components to be controlled.

This is done by:

- controlling the flux-forming current value I_{sd}
- controlling the torque-forming current value I_{sq}

By separate regulation of these two parameters, a decoupling of the system equivalent to an externally excited direct current machine is achieved.

The set-up of the two current controllers is identical and enables joint setting of amplification as well as the integral time for both controllers. Parameters *Amplification* **700** and *Integral Time* **701** are available for this. The proportional and integration and component of the current controllers can be switched off by setting the parameters to zero.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
700	Amplification	0.00	8.00	0.13
701	Integral Time	0.00 ms	10.00 ms	10.00 ms

The guided commissioning has selected the parameters of the current controller in such a way that they can be used without having to be changed in most applications.

If, in exceptional cases, an optimization of the behavior of the current controllers is to be done, the reference value jump during the flux-formation phase can be used for this. With suitable parameterization, the reference value of the flux-forming current components leaps to *Current during Flux-Formation* **781** and, after elapsing of *Max. Flux-Formation Time* **780**, then changes in a controlled way to the magnetizing current. The operating point necessary for the adjustment demands the setting of parameter *Minimum Frequency* **418** to 0.00 Hz, as the drive is accelerated after magnetizing. The measurement of the jump reply, which is defined by the ratio of the currents mentioned, should be done in the motor supply line by means of a measuring current transformer of a sufficient bandwidth.



The internally calculated actual value for the flux-forming current component cannot be output via the analog output for this measurement as the time resolution of the measurement is not sufficient.

To set the parameters of the PI controller, the *Amplification* **700** is increased first until the actual value overshoots distinctly during the control process. Now, the amplification is reduced to about fifty percent again and then the *Integral Time* **701** is synchronized until actual value overshoots slightly during the control process.

The settings of the current controllers should not be too dynamic in order to ensure a sufficient reserve range. The control tends to increased oscillations if the reserve range is reduced.

The dimensioning of the current controller parameters by calculation of the time constant is to be done for a switching frequency of 2 kHz. For other switching frequencies, the values are adapted internally so that the setting can remain unchanged for all switching frequencies. The dynamic properties of the current controller improve if the switching and scanning frequency increases.

The fixed time interval for the modulation results in the following scanning frequencies of the current controller via parameter *Switching Frequency* **400** .

Setting	
Switching frequency	Scanning frequency
2 kHz ¹⁾	2 kHz
4 kHz	4 kHz
8 kHz	8 kHz
12 kHz	8 kHz
16 kHz	8 kHz

¹⁾ This switching frequency can be set for parameter *Min. Switching Frequency* **401**.

18.5.2 Advanced current controller

In some machines, it may be necessary to set different amplification factors for different current ranges.

Definition:

- Current < Current below P. 777 is in effect **776** → Amplification low Current **777**
- Current above P. 700 is in effect **775** > Current
> Current below P. 700 is in effect **757** → Amplification **700**
- Current > Current above P. 759 is in effect **758** → Amplification high Current **759**

By default, the parameters are preset such that the parameters are not active and only the basic parameters are active.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
757	Current below P. 700 is in effect	0.00	o * I _{FIN}	o * I _{FIN}
758	Current above P. 759 is in effect	0.00	o * I _{FIN}	o * I _{FIN}
759	Amplification high Current	0.00	0.00	0.00
775	Current above P. 700 is in effect	0.00	o * I _{FIN}	0.00
776	Current below P. 777 is in effect	0.00	o * I _{FIN}	0.00
777	Amplification low Current	0.00	0.00	0.00

I_{FIN} = Rated frequency inverter output current

o: Overload capacity of frequency inverter.

The parameters are changed during motor auto setup.

18.5.3 Torque controller

The torque-controlled Configurations 230, 430, 530 and 630 enable sensor-less torque control as an alternative to speed control. Torque control is possible above the *Frequency Limit* **624**. Below the frequency limit, current impression is active at the current reference frequency as the reference frequency. In this case, the torque is not controlled but is set depending on the load behavior and the *Starting Current* **623**. In order to obtain torque controlled starting, the reference frequency should be above the *Frequency Limit* **624**. For example, this is guaranteed if *Minimum Frequency* **418** > *Frequency Limit* **624**.

f < *Frequency Limit* **624**: Current impression

f ≥ *Frequency Limit* **624**: Direct Torque Control DMR

The *Frequency Limit* **624** is set automatically during motor commissioning.

18.5.3.1 Torque preset

The reference torque can be specified as follows:

Set parameter *n-/M-Control Change-Over* 164 to "6 - On" or link it to a digital signal and turn it on.

Select the torque preset source via parameter *Reference Percentage Source 1* 476 or *Reference Percentage Source 2* 494.

For example:

- The reference torque can be set via the arrow keys of the control panel if the following setting is selected: *Reference Percentage Source 2* **494** = "5 - KeyPad-Motorpoti" (factory setting).
- The reference torque can be set via multifunction input 1 (MFI1A) if the following setting is selected: *Reference Percentage Source 1* **476** = "1 - Analog value MFI1A" (factory setting).
- 100 % torque refer to torque calculated from *Rated mech. power* **376** (motor power) and *Rated Speed* **372** (rated motor speed).

Parameter *Torque* **224** shows the actual torque value.

Select setting of parameter *Operation Mode Search Run* **645** according to the application. See Chapter 13.5 "13.5".

18.5.3.2 Upper and lower frequency limit in torque control

In many situations, the speed must be limited at operating points with reduced or without load torque, as the speed is adjusted according to the preset torque and the load behavior. To avoid unwanted speeds (in most cases excessive speed, but sometimes low speeds, too, and to avoid current impression), the speed is limited by the speed controller via *Frequency Upper Limit* **767** and *Frequency Lower Limit* **768**.

As from the limit, the speed is adjusted to the maximum (*Frequency Upper Limit* **767** and *Frequency Lower Limit* **768**) which corresponds to the behavior of the speed controller. In addition, the controller limits the speed to the *Maximum Frequency* **419**. This limitation is done by the speed controller – changes of the speed controller affect the speed behavior in the limit range of the 3 parameters mentioned accordingly.

In current impression mode, the frequency is also limited to the *Minimum Frequency* **418**– in direct torque control mode, this limit is not active.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
767	Frequency upper limit	-599.00 Hz	599.00 Hz	599.00 Hz
768	Frequency lower limit	-599.00 Hz	599.00 Hz	-599.00 Hz



Positive values limit clockwise speed, negative values limit anticlockwise speed. If, for example, both values are positive (> 0 Hz), anticlockwise operation will be disabled.



WARNING

If torque control is activated while the torsional frequency is outside the range between *Frequency Upper Limit* **767** and *Frequency Lower Limit* **768**, (e.g. when a machine is started from standstill or a quickly rotating machine is stopped quickly), the permissible speed range will be approached without ramps by means of the speed controller. In this case, the torque is only limited by the limitations of the speed controller (current and torque). For this reason, there may be unexpected dynamic behavior.

18.5.3.3 Limit value sources

The limitation of the frequency can be done by setting fixed values and by linking to an analog input parameter. The analog value is limited via parameters *Minimum Reference Percentage* **518** and *Maximum Reference Percentage* **519**, but does not consider the *Gradient Percentage Ramp* **477** of the reference percentage value channel.

The assignment is done for the torque controller via parameters *Frequency Upper Limit Source* **769** and *Frequency Lower Limit Source* **770**.

Operation mode 769, 770	Function
101 - Analog Input MFI1A	Multifunction input 1 in analog Operation Mode 452 is the source.
110 - Fixed Limit	The selected parameter values are taken into account to limit the speed controller.
201 - Inv. Analog Input MFI1A	Operation mode 101, inverted.
210 - Inv. Fixed Limit	Operation mode 110, inverted.

18.5.3.4 Switching over between speed control and torque control

With the signal assigned to parameter *n-/M-Control Change-Over* **164**, you can switch between speed control and torque control. See Chapter 16.4.6 "16.4.6".

18.5.4 Speed controller


The actual speed source is selected via parameter *Actual Speed Source* **766**. In the default setting, Speed Sensor 1 is used as the source of actual speed. If Speed Sensor 2 of an extension module is to deliver the actual value signal for the speed controller, Speed Sensor 2 must be selected as the source. Alternatively, the speed controller can derive the actual speed value from the machine model in in Configurations 410, 411 and 430 (*Parameter Configuration* **30**).

Operation Mode 766	Function
1 - Speed Sensor 1	The actual speed source is speed sensor 1 of the basic device (factory setting).
2 - Speed Sensor 2	The actual speed source is speed sensor 2 of an extension module. ¹⁾
3 - Machine Model	The speed controller receives the calculated actual speed value from the machine model. Can be set in configurations 4xx and 6xx.
4 - Speedtracking EC 1	Speedtracking by comparison between the calculated machine model and speed sensor 1 to increase speed accuracy. Can be set in configurations 4xx and 6xx. The setting for parameter <i>Integral Time Speedtracking</i> 515 is considered.
5 - Speedtracking EC 2	Speed compensation by comparison between the calculated machine model and speed sensor 2 of an extension module ¹⁾ to increase speed accuracy. Can be set in configurations 4xx and 6xx. The setting for parameter <i>Integral Time Speedtracking</i> 515 is considered.

¹⁾ Only available if extension module is installed

The control of the torque-forming current components is done in the outer control loop by the speed controller. Via parameter *Operation Mode* **720**, you can select the operation mode for the speed controller. The operation mode defines the use of the parameterizable limits. These are referred to the direction of rotation and the direction of the torque and depend on the selected configuration.

Operation Mode 720	Function
0 - Speed controller off	The controller is deactivated or the torque-forming component is zero.
1 - Limits for Motor/Generator Op.	The limitation of the speed controller assigns the upper limit to the motor operation of the drive. Independent of the direction of rotation, the same limit is used. The same applies in the case of regenerative operation with the lower limit.
2 - Limits for pos./neg. Torque	The assignment of the limit is done by the sign of the value to be limited. Independent of the motor or generator operating points of the drive, the positive limitation is done by the upper limit. The lower limit is regarded as a negative limitation.



The properties of the speed controller can be adapted for adjustment and optimization of the controller. The Amplification and Integral Time of the speed controller can be set via parameters *Amplification 1* **721** and *Integral Time 1* **722**. For the second speed range, you can set parameters *Amplification 2* **723**, *Integral Time 2* **724**. The distinction between the speed ranges is done based on the value selected with parameter *Speed Control Switch-Over Limit* **738**. Parameters *Amplification 1* **721** and *Integral Time 1* **722** are not considered by the default parameter *Speed Control Switch-Over Limit* **738**. If parameter *Speed Control Switch-Over Limit* **738** is set to a value above 0.00 Hz, parameters *Amplification 1* **721**, *Integral Time 1* **722** will be active below the limit, and parameters *Amplification 2* **723**, *Integral Time 2* **724** will be active above the limit.

Use the *Filter time constant* **754** to filter the control deviation, if required. In this way, operation with static control deviation and occasional undesired higher deviations can be stabilized. However, this will affect the dynamic behavior when the load changes (speed change or changing torque requirements).

The parameterized amplification at the current operating point can additionally be assessed via the parameter *Backlash Damping* **748**. In particular the small signal behavior in applications with a gearbox can be improved by a value higher than zero percent.

Parameter *Backlash Damping* **748** is available depending on the type of unit.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
721	Amplification 1	0.00	200.00	- ¹⁾
722	Integral Time 1	0 ms	60000 ms	- ¹⁾
723	Amplification 2	0.00	200.00	- ¹⁾
724	Integral Time 2	0 ms	60000 ms	- ¹⁾
754	Filter time constant	0 ms	128 ms	0 ms
738	Speed Control Switch-Over Limit	0.00 Hz	599.00 Hz	55.00 Hz
748	Backlash damping	0 %	300 %	100 %

- ¹⁾ The default setting is relative to the recommended machine data for the amplification and integral time. This enables a first function test in a large number of applications. Switch-over between settings 1 and 2 for the current frequency range is done by the software according to the selected limit value.

The optimization of the speed controller can be done with the help of a reference value leap. The amount of the leap is defined by the set ramp or limitation. The optimization of the PI controller should be done at the maximum admissible reference figure change rate. First, the amplification is increased until the actual value overshoots distinctly during the control process. This is indicated by a strong oscillation of the speed and by the running noises. In the next step, reduce the amplification slightly (1/2 ...3/4 etc.). Then reduce the integral time (larger I component) until the actual value overshoots only slightly in the control process.


If necessary, check the speed control settings in the case of dynamic operations (acceleration, deceleration). The frequency at which a change-over of the controller parameters takes place can be set via the parameter *Speed Control Switch-Over Limit* **738**.

18.5.4.1 Limitation of speed controller

The output signal of the speed controller is the torque-forming current component I_{sq} . The output and the I portion of the speed controller can be limited via parameters *Current Limit* **728**, *Current Limit Generator Op.* **729**, *Torque Limit* **730**, *Torque Limit Generator Operation* **731** and *Power Limit* **739**, *Power Limit Generator Operation* **740**. The limits of the proportional portion are set via parameters *P-Comp. Torque Upper Limit* **732** and *P-Comp. Torque Lower Limit* **733**.

- The output value of the controller is limited by an upper and a lower current limit, parameters *Current Limit* **728** and *Current Limit Generator Op.* **729**. The limit figures are entered in Amperes. The current limits of the controller can be linked to the fixed limits and analog input parameters. The assignment is done via the parameters *Isq Limit Source Motor Operation* **734** and *Isq Limit Source Generator Op.* **735**.
- The output value of the controller is limited by an upper and a lower torque limit, parameter *Torque Limit* **730** and parameter *Torque Limit Generator Operation* **731**. The limit values are input as a percentage of the rated motor torque. The assignment of fixed values or analog limit values is done via the parameters *Torque Limit Source Motor Op.* **736** and *Torque Limit Source Gen. Op.* **737**.
- The output value of the P component is limited with parameter *P-Comp. Torque Upper Limit* **732** and *P-Comp. Torque Lower Limit* **733**. The limit values are input as torque limits as a percentage of the rated motor torque.
- The power output by the motor is proportional to the product of speed and torque. This output power can be limited at the controller output with a *Power Limit* **739** and *Power Limit Generator Operation* **740**. The power limits are entered in kilowatt.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
728	Current Limit	0.0 A	$0 \cdot I_{FIN}$	$0 \cdot I_{FIN}$
729	Current Limit Generator Op.	-0.1 A	$0 \cdot I_{FIN}$	$0 \cdot I_{FIN}$
730	Torque Limit	0.00 %	650.00 %	650.00 %
731	Torque Limit Generator Operation	0.00 %	650.00 %	650.00 %
732	P-Comp. Torque Upper Limit	0.00 %	650.00 %	100.00 %
733	P-Comp. Torque Lower Limit	0.00 %	650.00 %	100.00 %
739	Power Limit	0.00 kW	$2 \cdot 0 \cdot P_{FIN}$	$2 \cdot 0 \cdot P_{FIN}$
740	Power Limit Generator Operation	0.00 kW	$2 \cdot 0 \cdot P_{FIN}$	$2 \cdot 0 \cdot P_{FIN}$



18.5.4.2 Limit value sources

As an alternative to limiting the output values by a fixed value, linking to an analog input value is also possible. The analog value is limited via parameters *Minimum Reference Percentage* **518**, *Maximum Reference Percentage* **519**, but does not consider the *Gradient Percentage Ramp* **477** of the reference percentage channel.

The assignment is done via parameter *Isq Limit Source Motor Operation* **734** and *Isq Limit Source Generator Op.* **735** for the torque-forming current component Isq.

The sources for the torque limits can be selected via parameter *Torque Limit Source Motor Op.* **736** and *Torque Limit Source Gen. Op.* **737**.

Operation mode 736, 737	Function
101 - Analog Input MFI1A	Multifunction input 1 in analog Operation Mode 452 is the source.
105 - Repetition frequency input (F3)	The frequency signal on the repetition frequency input corresponding to Operation Mode 496 .
110 - Fixed Limit	The selected parameter figures for limiting the speed controller are taken into account.



The limit values and assignment to different limit value sources are data set related in the configurations. The use of the data record change-over demands an examination of the parameters in question.

18.5.4.3 Integral time speed compensation

For speed compensation and in order to increase the speed accuracy, the integrating component of the speed control can be set via parameter *Integral Time Speedtracking* **515**. The setting is effective in Operation Modes „4 - Speedtracking EC 1“ and „5 - Speedtracking EC 2“ for Parameter *Actual Speed Source* **766**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
515	Integral Time Speedtracking	1 ms	60 000 ms	5000 ms

18.5.5 Acceleration pre-control

The acceleration pre-control is active in the speed-controlled configurations and can be activated via parameter *Operation Mode* **725**.

Operation Mode 725	Function
0 - off	The control system is not influenced.
1 - On	The acceleration pre-control is active according to the limit values.

The acceleration pre-control controlled parallel to the speed controller reduces the reaction time of the drive system to a change of reference values. The minimum acceleration time defines the modification speed of the reference speed value as from which a torque necessary for acceleration of the drive is pre-controlled. Acceleration of the mass depends on the *Mech. Time Constant* **727** of the system. The value calculated from the increase of the reference value and the multiplication factor of the torque required is added to the output signal of the speed controller.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
726	Minimum acceleration	0.1 Hz/s	6500.0 Hz/s	1.0 Hz/s
727	Mech. Time Constant	1 ms	60000 ms	10 ms

For optimal setting, the acceleration pre-control is switched on and the mechanical time constant is set to the minimum value. The output value of the speed controller is compared to the minimum acceleration time during the acceleration processes. The frequency ramp is to be set to the highest value occurring in operation at which the output figure of the speed controller is not yet limited. Now, the value of the *Minimum Acceleration* **726** is set to half the set acceleration ramp so that it is ensured that the acceleration pre-control is active. The acceleration pre-control is not raised by increasing the *Mech. Time Constant* **727** until the output figure corresponds to the time modification of the drive mechanism during the acceleration processes.

18.5.6 Field controller

The flux-forming current component is controlled by the field controller. The guided commissioning optimizes the parameters of the field controller by measuring the time constant and magnetizing curve of the connected asynchronous motor. The parameters of the field controller are selected such that they can be used without changes in most applications. The proportional and the integrating part of the field controller are to be set via parameters *Amplification* **741** and *Integral Time* **742**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
717	Reference Flux	0.01%	300.00%	100.00%
741	Amplification	0.0	100.0	5.0
742	Integral Time	0.0 ms	1000.0 ms	100.0 ms

Please note that any changes of the field controller should only be made in the base speed range.

If the field controller must be optimized, set the *Field Controller Integral Time* **742** = *Act. Rotor Time Constant* **227** / 2, i.e. half the rotor time constants. In most applications, this change will be sufficient.

If additional optimization is required, please proceed as follows:

First set the output frequency (e.g. via reference frequency) such that the actual value *Modulation* **223** = 80...90 % *Reference Modulation* **750**.

Now, change parameter *Reference Flux* **717** from 100 % to 90 %. While doing so, oscillograph I_{sd} . The course of the signal of the flux-forming current I_{sd} should reach the stationary value after overshooting without oscillation.

Adjust parameters *Amplification* **741** and *Integral Time* **742** according to the application requirements.

Change the *Reference Flux* **717** back to 100 % and repeat the reference flux jump, while analyzing the changes by means of oscillography. Repeat these steps if necessary.

If a quick transition into field weakening is necessary for the application, the integral time should be reduced.

For good dynamic behavior, choose a relatively high value for *Amplification* **741** of the controller. Note that high overshoot is necessary for good control behavior in controlling of a load with low-pass behavior, for example a 3-phase machine.

Parameter *Reduction Factor Flux* **778** reduces the stall current when a stopping behavior is selected with "Stop" function. This stopping behavior is selected if Parameter *Operation Mode* **630** is set to 2x (20 ... 27 – "R->0, Stop, ... ") or x2 (2, 12, 22, 32, 42, 52, 62, 72 – " ... , R->0, Stop"). The stopping behavior is described in Chapter "".

In these operation modes, the setting for *Reduction Factor Flux* **778** will be effective once the time set in parameter *Holding Time* **638** has elapsed. The resulting stall flux is calculated from the factors *Reference Flux* **717** and *Reduction Factor Flux* **778**. After a start command, the drive will start immediately and the flux will increase to the reference flux while the drive is running.

Due to the reduced flux, a higher torque-forming current component I_{sq} is needed when the drive is starting. The time required to reach the reference flux can be influenced via parameter *Ref. Isd Upper Limit* **743**. This parameter is set to the rated motor current during guided commissioning.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
778	Reduction Factor Flux	20.00%	100.00%	100.00%

18.5.6.1 Limitation of field controller

The output signal of the field controller, the integrating and proportional component are limited via parameters *Ref. Isd Upper Limit* **743** and *Ref. Isd Lower Limit* **744**. During guided commissioning, parameter *Ref. Isd Upper Limit* **743** is set according to parameter *Rated Current* **371**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
743	Ref. Isd upper limit	0	$0 \cdot I_{FIN}$	I_{FIN}
744	Ref. Isd lower limit	$- I_{FIN}$	I_{FIN}	0.0

The limits of the field controller define not only the maximum current occurring, but also the dynamic properties of the controller. The upper and lower limits restrict the modification speed of the machine flux and the torque resulting from it. In particular the speed area above the nominal frequency should be observed for the modification of the flux-forming component. The upper limit is to be estimated from the product of the set magnetizing current and the correction factor *Reference Flux* **717**, although the limit must not exceed the overload current of the drive.

18.5.7 Modulation controller

The modulation controller, which is designed as an I regulator, automatically adapts the output value of the frequency inverter to the machine behavior in the basic speed area and in the field weakening area. If the modulation exceeds the figure set with parameter *Reference Modulation* **750**, the field-forming current component and thus the flux in the machine are reduced.

In order to make the best possible use of the voltage available, the figure selected via parameter *Operation Mode* **753** is put into proportion to the DC link voltage. That means that with a high mains voltage there is also a high output voltage available, the drive only reaches the field weakening area later and produces a higher torque.

Operation Mode 753	Function
0 - Usq-Control	The modulation is calculated from the ratio of torque-forming voltage component U_{sq} to the DC link voltage.
1 - U abs. value control	The modulation is calculated from the abs. voltage value / DC link voltage ratio.

The integrating part of the modulation controller is to be set via parameter *Integral Time* **752**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
750	Reference modulator	3.00 %	105.00 %	102.00 %
752	Integral Time	0.0 ms	1000.0 ms	10.0 ms

The percentage setting of the *Reference Modulation* **750** is basically a function of the leakage inductance of the machine. The default value was selected such that in most cases the remaining deviation of 5% is sufficient as a reserve range for the current controller. For the optimization of the controller parameters, the drive is accelerated with a flat ramp into the area of field weakening, so that the modulation controller intervenes. The limit is set via *parameter Reference Modulation* **750**. Then, the control loop can be excited with a jump function by modifying the reference modulation (change-over between 95% and 50%). By means of an oscillographed measurement of the flux-forming current component on the analog output of the frequency inverter, the controlling process of the modulation controller can be assessed. The course of the signal of the flux-forming current I_{sd} should reach the stationary value after overshooting without oscillation. An oscillating of the course of the current can be damped by increasing the integral time. Parameter *Integral Time* **752** should roughly correspond to the actual value *Act. Rotor Time Constant* **227**.

18.5.7.1 Limitation of modulation controller

The output signal of the modulation controller is the internal reference flux. The controller output and integrating component are limited via parameter *Reference Imr Lower Limit* **755** and the product of *Rated Magnetising Current* **716** and *Reference Flux* **717**. The upper limiting parameter Magnetising Current is to be set to the rated value of the machine. For the lower limit, select a value which also builds up an adequate flux in the machine in the field weakening area. The limitation of the control deviation at the output of the modulation controller prevents a possible oscillation of the control loop in the case of load surges. The parameter *Control Deviation Limitation* **756** is stated as an absolute value and acts both as a positive and a negative limit.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
755	Reference Imr Lower Limit	$0.01 \cdot I_{FIN}$	$0 \cdot I_{FIN}$	$0.01 \cdot I_{FIN}$
756	Control Deviation Limitation	0.00 %	100.00 %	10.00 %

19 Special functions

The configurable functions of the corresponding control methods enable another field of application of the frequency inverters. The integration in the application is made easier by special functions.

19.1 Pulse width modulation

The motor noise can be reduced by switching parameter *Switching Frequency* **400**. The switching frequency should be reduced to a maximum ratio of 1:10 to the frequency of the output signal for a sine-shaped output signal. The maximum possible switching frequency depends on the drive output and the ambient conditions. For the required technical data refer to the corresponding table and the device type diagrams.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
400	Switching frequency	2 kHz	16 kHz	2 kHz ¹⁾
				4 kHz ²⁾

The factory setting of parameter *Switching Frequency* **400** depends on the selected parameter *Configuration* **30**:

¹⁾ Configurations 1xx

²⁾ Configurations 2xx / 4xx

The heat losses increase proportionally to the load point of the frequency inverter and the switching frequency. The automatic reduction adjusts the switching frequency to the current operating state of the frequency inverter in order to provide the output performance required for the drive task at the greatest possible dynamics and a low noise level.

The switching frequency is adjusted between the limits set with parameters *Switching Frequency* **400** and *Min. Switching Frequency* **401**. If *Min. Switching Frequency* **401** is higher or equal to the *Switching Frequency* **400**, automatic reduction will be disabled.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
401	Min. Switching Frequency	2 kHz	16 kHz	2 kHz

The change of the switching frequency depends on the heat sink temperature switch-off limit and the output current. The temperature limit to be exceeded so that the switching frequency is reduced can be set via parameter *Reduction Limit Ti/Tc* **580**. If the heat sink temperature falls below the threshold set via parameter *Reduction Limit Ti/Tc* **580** by 5 °C, the switching frequency is increased again step by step.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
580	Reduction limit Ti/Tk	-25 °C	0 °C	-4 °C



The limit for the switching frequency reduction is influenced by the intelligent current limits depending on the selected *Operation Mode* **573** and the output current. If they have been switched off or provide the full overload current, the switching frequency is reduced when the output current exceeds the limit of 87.5% of the long-term overload current (60s). The switching frequency is increased if the output current drops below the reference current of the next highest switching frequency.

19.2 Fan

The switch-on temperature of the heat sink fan can be set with *parameter Switch-On Temperature 39*.

If mains voltage is applied to the frequency inverter, and the heat sink temperature exceeds the set temperature, the heat sink fan is switched on. Independent from parameter *Switch-On Temperature 39*, the heat sink fan will be switched on, as soon as the frequency inverter is switched on and enabled and the start signal is received.



To protect the device, a device error will be triggered once an internal temperature shutdown threshold is reached.

If the heat sink temperature drops below the set temperature by 5 °C, or if the controller enable signal is inhibited, the heat sink fan is switched of when the minimum ON-time has elapsed.

The minimum ON-time of the heat sink fan is set internally to 1 minute. If the temperature drops below *the Switch-On Temperature 39* during this time, the heat sink fan will be continue operation until the minimum on time has elapsed.

Operation mode 43 for digital outputs additionally enables the control of an **external** fan. Via the digital output, the fan is switched on if the controller is released and Start clockwise or Start anticlockwise are switched on, or if the *Switch-On Temperature 39* for the internal fan was reached. Like in the case of the internal heat sink fan, the minimum ON-time of the external fan is 1 minute.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
39	Switch-On Temperature	0 °C	60 °C	30 °C

19.3 Bus controller



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify safe isolation from power supply.

Work on the device may only be started once the DC link capacitors have discharged. The time to wait is at least 3 minutes in the case of sizes 1 through 7 .

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.



In order to be able to control the drive, the digital controller inputs S1IND/STOA and S7IND/STOB must be connected and set to "High-Signal" in order to enable the output stage.

The frequency inverters can be extended by different options for data communication and can be integrate in an automation and control system in this way. Parameterization and commissioning can be done via the optional communication card, the operating unit or the interface adapter.

Parameter *Local/Remote 412* defines the operating behavior and enables a change between the control via contacts or the control unit and/or the interface.

Local/Remote 412	Function
0 - Control via contacts	The Start and Stop commands as well as the direction of rotation are controlled via digital signals.
1 - Control via state machine	The Start and Stop commands as well as the direction of rotation are controlled via the DRIVECOM Statemachine of the communication interface.

2 -	Control via remote contacts	The Start and Stop commands as well as the direction of rotation are controlled via logic signals through the communication protocol.
3 -	Ctrl. KP, direction Contacts	The Start and Stop commands are controlled from the control unit and the direction of rotation is controlled via digital signals.
4 -	Ctrl. KP+Cont., direction Cont.	Commands Start and Stop via control unit or digital signals. The statement of the direction of rotation only with the help of the digital signals.
5 -	Ctrl. 3-Wire, direction Cont.	3-wire; control of sense of rotation and signal <i>3-Wire Ctrl. 87</i> via contacts.
13 -	Control via KP, Direction KP	The Start and Stop commands as well as the direction of rotation are controlled via the control unit.
14 -	Control KP+Cont., Direction KP	Commands Start and Stop via control unit or digital signals. The statement of the direction of rotation only with the help of the operating unit.
20 -	Control Contacts, Clockw.	Commands Start and Stop via digital signals. Fixed direction of rotation, clockwise rotation only.
23 -	Control Keypad, Clockw.	Commands Start and Stop via control unit. Fixed direction of rotation, clockwise rotation only.
24 -	Control Cont. + KP, Clockw.	Commands Start and Stop via control unit or digital signals. Fixed direction of rotation, clockwise rotation only.
30 to 34		Operation mode 20 to 24, anticlockwise direction of rotation only.
43 -	Ctrl. KP, Dir. Cont. + KP	Commands Start and Stop via control unit. The statement of the direction of rotation comes from the operating unit or via digital signals.
44 -	Ctrl. Cont.+KP, Dir. Cont.+KP	Both the Start and Stop commands as well as the sense of rotation can be controlled from either the control unit or via digital signals.
46 -	Ctrl. 3-Wire+KP, Dir. Cont.+KP	3-wire and control unit; control of direction of rotation and signal <i>3-Wire Ctrl 87</i> via contacts or control unit.



If the operation mode is changed while the drive is running, the drive will not be stopped if no stop command is present in the new operation mode.

19.4 Brake chopper and brake resistance

The frequency inverters feature a brake chopper transistor. The external brake resistor is connected to terminals Rb1 and Rb2. The parameter *Trigger Threshold 506* defines the switch-on threshold of the brake chopper. The generator output of the drive, which leads to the increase in the DC link voltage, is converted to heat by the external brake resistor above the limit set via parameter *Trigger Threshold 506*.

Parameter		Setting			
No.	Description	ACU	Min.	Max.	Factory setting
506	Trigger Threshold	201	225.0 V	1000.0 V	390.0 V
		401	425.0 V		780.0 V
		501	925.0 V	1050.0 V	800.0 V
		601	1225.0 V	1400.0 V	1150.0 V

The parameter *Trigger Threshold 506* is to be set in such a way that it is between the maximum DC link voltage which the mains can generate and the maximum admissible DC link voltage of the frequency inverter.

$$U_{\text{Netz}} \cdot 1,1 \cdot \sqrt{2} < U_{d_{\text{BC}}} < U_{d_{\text{max}}}$$

If the parameter *Trigger Threshold 506* is set larger than the maximum admissible DC link voltage, the brake chopper cannot become active, the brake chopper is switched off.

If the parameter *Trigger Threshold* **506** is set to a value below the DC link voltage generated by the mains, error message F0705 (chapter 21.1.1 "21.1.1") is displayed if the start command is issued to the frequency inverter.

If the DC-Link Voltage exceeds a certain threshold, error message F0700 will be triggered (see Chapter 21.1.1 "21.1.1"). The threshold depends on the device series:


ACU 201 device series: 400 V

ACU 401 device series: 800 V

ACU 501 device series: 900 V

ACU 601 device series: 1200 V

The sampling time of the function is 125 µs. The brake chopper remains on for at least 125 µs after the set trigger threshold was exceeded even if the value drops below the trigger threshold within this period again.



19.4.1 Dimensioning of brake resistor



WARNING

The brake resistor is to be connected according to the specifications and instructions in chapter 7.4.4 "7.4.4".

The following values must be known for dimensioning:

Peak braking power $P_{b \text{ Peak}}$ in W

Resistance R_b in Ω

On time OT in %

- Calculation of peak braking power $P_{b \text{ Peak}}$**

$$P_{b \text{ Spitze}} = \frac{J \cdot (n_1^2 - n_2^2)}{182 \cdot t_b}$$

$P_{b \text{ Peak}}$	=	Peak braking power in W
J	=	Moment of inertia of drive system kgm^2
n_1	=	Speed of drive system before the braking operation in rpm
n_2	=	Speed of drive system after the braking operation in rpm
t_b	=	Braking time in s

- Calculation of resistance R_b**

$$R_b = \frac{U_{d \text{ BC}}^2}{P_{b \text{ Spitze}}}$$

R_b	=	Resistance in Ω
$U_{d \text{ BC}}$	=	Switch-on threshold in V
$P_{b \text{ Peak}}$	=	Peak braking power in W

The switch-on threshold $U_{d \text{ BC}}$ is the DC link voltage at which the brake resistor is switched on. The switch-on threshold can be set, as described above, via parameter *Trigger Threshold* **506**.


CAUTION

The resistance of the brake resistor must not be less than the minimum value $R_{b \min}$ - 10%. The values for $R_{b \min}$ are listed in chapter 5 "5".

If the calculated resistance R_b of the brake resistor is between two standard series values, the lower resistance is to be selected.

- **Calculation of On Time OT**

$$ED = \frac{t_b}{t_z}$$

OT = On Time
 t_b = Braking time
 t_z = Cycle time


Example:

$t_b = 48 \text{ s}$, $t_z = 120 \text{ s}$

$$ED = \frac{t_b}{t_z} = 0,4 = 40\%$$

In the case of infrequent short braking operations, typical values of the On Time OT are at 10 %, for long braking operations ($\geq 120 \text{ s}$) typical values are at 100%. In the case of frequent deceleration and acceleration operations, it is recommended that the On Time OT be calculated according to the above formula.

The calculated values for $P_{b \text{ peak}}$, R_b and OT can be used by the resistor manufacturers for determining the resistor-specific permanent power.

19.5 Motor circuit breaker

In order to protect the motor against excessive heat-up, monitoring mechanisms are required which will identify potential thermal overloading in due time to prevent the motor from damage. The thermal condition of a motor can be identified in different ways.

1. Direct monitoring via temperature sensors in the winding (see Chapter 19.5.1 "19.5.1")
 - PTC
 - KTY
 - PT1000
 - Thermocontact
2. Indirect monitoring of motor temperature
 - Monitoring of motor current using the K- characteristic of an integrated motor circuit breaker
 - Thermocontact
 - Modeling of motor heat-up by consideration of temperature-relevant factors via a mathematical model I^2t

The thermal monitoring method is selected based on the type and operating conditions of the motor. Generally, any of the available methods is sufficient for reliable motor protection. A combination of methods from both groups (one from each group) and parallel execution is possible.

19.5.1 Motor circuit breaker


Motor circuit breakers are used for protecting a motor and its supply cable against overheating by overload. Depending on the overload level, they disconnect the motor from power supply immediately in the case of a short-circuit or they disconnect the motor if an overload has occurred for some time.

Conventional motor circuit breakers are commercially available for various applications with different trigger characteristics (L, G/U, R and K), as shown in the diagram on the right. As frequency inverters in most cases are used for supplying motors which are classified as operating equipment with very high starting currents, only the K characteristic was realized in this function.

Unlike the operation of a conventional motor circuit breaker which disconnects the equipment to be protected immediately if the trigger threshold is reached, this function provides the possibility of issuing a warning instead of disconnecting the equipment immediately.

The rated current of the motor circuit breaker refers to the rated motor current stated via parameter *Rated Current* **371** of the corresponding data set.

The rated values of the frequency inverter are to be considered accordingly when it comes to dimensioning the application.



The function of the motor circuit breaker can be linked to different data sets. In this way, it is possible to operate different motors via one frequency inverter. Thus, each motor can be equipped with its own motor circuit breaker.

In case a motor is operated via the frequency inverter for which some setting values, e.g. minimum and maximum frequency, are changed via the data set switch-over, only one motor circuit breaker may be installed. This functionality can be differentiated by selecting the parameter *Operation Mode* **571** for single motor operation or multiple motor operation.

Operation Mode 571	Function
0 - off	The function is deactivated.
1 - K-Char., Multi-Motor Op., Err.Sw.Off	In each of the four data sets, the rated values are monitored. Overloading the drive is prevented by the fault switch-off "F0401".
2 - K-Char., Single-Motor, Err.Sw.-Off	The rated values in the first data set are used independently of the active data set. Overloading the drive is prevented by the fault switch-off "F0401".
11 - K-Char., Multi-Motor Op., Warning	In each of the four data sets, the rated values are monitored. Overloading the drive mechanism is signaled by a warning message "A0200".
22 - K-Char., Single-Motor, Warning	The rated values in the first data set are used independently of the active data set. Overloading the drive mechanism is signaled by a warning message "A0200".
42 - I ² t, Single-Motor, Err.Sw.-Off	see Chapter 19.5.2
51 - I ² t, Multi-Motor Op., Warning	see Chapter 19.5.2
52 - I ² t, Single-Motor Op., Warning	see Chapter 19.5.2

61 - I ² t, Multi-Motor Op., Warning and Err.Sw.-Off	see Chapter 19.5.2
62 - I ² t, Single-Motor Op., Warning and Err.Sw.-Off	see Chapter 19.5.2
101 K-Char., Multi-Motor Op., - Err.Sw.Off, Latching	<p>Like operation modes 1, 2, 11 or 22 In addition, the integrated current will be saved permanently when the device is turned off and set to the saved value upon restart.</p>
102 K-Char., Single-Motor Op., - Err.Sw.Off, Latching	
111 K-Char., Multi-Motor Op., Warning, - Latching	
122 K-Char., Single-Motor, Warning, - Latching	

Multiple motor operation

Parameter *Operation Mode* **571 = 1, 11, 101 or 111**

In multiple motor operation, it is assumed that each data set is assigned to a corresponding motor. For this, one motor and one motor circuit breaker are assigned to each data set. In this operation mode, the rated values of the active data set are monitored. The current output current of the frequency inverter is only taken into account in the motor circuit breaker activated by the data set. In the motor circuit breakers of the other data sets, zero current is expected, with the result that the thermal decay functions are taken into account. In combination with the data set change-over, the function of the motor circuit breakers is similar to that of motors connected alternately to the mains with their own circuit breakers.

In addition, in Operation Modes **101** and **111**, the integrated current will be saved permanently when the device is turned off and set to the saved value upon restart.

Single motor operation

Parameter *Operation Mode* **571 = 2, 22, 102 or 122**

In single motor operation, only one motor circuit breaker, which monitors the output current of the frequency inverter, is active. In the case of a data set change-over, only the switch-off limits derived from the rated machine parameters are changed over. Accumulated thermal values are used after the change-over as well. In the case of the data set change-over, please ensure that the machine data are stated identically for all data sets. In combination with the data set change-over, the function of the motor circuit breaker is similar to that of motors connected alternately to the mains with one common circuit breaker.

In addition, in Operation Modes **102** and **122**, the integrated current will be saved permanently when the device is turned off and set to the saved value upon restart.

Reset-proof

Parameter *Operation Mode* **571 = 101, 102, 111 or 122.**

The internal state of the motor circuit breaker is saved permanently (reset-proof). These settings are to be used in the case of regular short-time mains failure/disconnection. This guarantees correct motor protection for the application even in the case of short-time mains failure/disconnection.

Motor protection, in particular self-ventilation motors, is improved via a *Frequency Limit* **572** which can be set as a percentage of the rated frequency.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
572	Frequency Limit	0%	300%	0%

Output signals

Digital signals signal that of the function "motor circuit breaker" has been triggered.

180 -	Warning Motor	1)	Triggering of "motor circuit breaker" function as per <i>Operation Mode</i> 571 is reported.
14 -	Protection	2)	

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.



In Operation Modes 101, 102, 111 and 122, the function set in parameter *Operation Mode* **571** should be the same in all data sets.

In the calculation of the triggering time, the output current measured in working points below the frequency limit will be valued at a factor between 1 and 2.

This factor is determined depending on the stator frequency. In this way, the higher thermal load of self-ventilated motors in the lower speed range is considered.

The table shows an extract of the factors for a 50 Hz motor.

		Frequency Limit 572								
		300%	200%	150%	100%	80%	60%	40%	20%	10%
Statorfrequenz [Hz]	0	200%	200%	200%	200%	200%	200%	200%	200%	200%
	5	188%	182%	177%	168%	162%	153%	139%	114%	100%
	10	177%	168%	160%	147%	139%	129%	114%	100%	100%
	20	160%	147%	137%	122%	114%	106%	100%	100%	100%
	30	147%	132%	122%	109%	103%	100%	100%	100%	100%
	50	129%	114%	106%	100%	100%	100%	100%	100%	100%
	100	106%	100%	100%	100%	100%	100%	100%	100%	100%
	150	100%	100%	100%	100%	100%	100%	100%	100%	100%

19.5.2 Motor protection by I²t monitoring

I²t monitoring is another way to protect the motor against thermal overload. This motor protection method is mainly used in servo systems.


Wherever synchronous servomotors are used, I²t monitoring is a proven alternative to motor circuit breakers. By integrating measurable or known motor parameters, heat-up is modeled based on a mathematical model.

The I²t monitoring feature can be selected via Operation Mode 571.

The settings are data set change-over settings.

I²t monitoring is done, as shown in the illustration, via $(I_{st}/I_n)^2$.

The monitored variable is valued via a PT1 element with the thermal time constant of the stator. If the PT1 element output exceeds 120%, an error message will be reported and the inverter will shut down. The 120% threshold ensures the overshooting will not result in immediate shutdown. Permanent exceeding of the 100% load of the stator winding should be avoided in the application.



The output of the first PT1 element is connected to the input of the second PT1 element which contains the thermal time constant of the motor. This output may be loaded at 100% permanently. This corresponds to full thermal loading of the motor. Once 102% are reached, the inverter will shut down and an error will be reported. Both outputs are linked to an adjustable Warning Threshold.

Operation Mode 571	Function
42 - I ² t, Single-Motor, Err.Sw.-Off	The I ² t load of the motor is monitored via the rated values from the active data set. Once the fixed error threshold of 100% _{Motor} (120% _{Stator}) is exceeded, there will be an error shutdown "F0401" by the active data set.
51 - I ² t, Multi-Motor Op., Warning	In each of the four data sets, the I ² t load of the motors is monitored based on the corresponding rated values. Once the set <i>Warning Limit I²t</i> 615 is reached, a warning "A0200" will be triggered by the active data set.
52 - I ² t, Single-Motor Op., Warning	The I ² t load of the motor is monitored via the rated values from the active data SE. Once the set <i>Warning Limit I²t</i> 615 is reached, a warning "A0200" will be triggered by the active data set.
61 - I ² t, Multi-Motor Op., Warning and Err.Sw.-Off	In each of the four data sets, the I ² t load of the motors is monitored based on the corresponding rated values. Once the set <i>Warning Limit I²t</i> 615 is reached, a warning "A0200" will be triggered. Once the fixed error threshold of 100% _{Motor} (120% _{Stator}) is exceeded, there will be an error shutdown "F0401". Both events will be triggered by the active data set.
62 - I ² t, Single-Motor Op., Warning and Err.Sw.-Off	The I ² t load of the motor is monitored via the rated values from the active data SE. Once the set <i>Warning Limit I²t</i> 615 is reached, a warning "A0200" will be triggered. Once the fixed error threshold of 100% _{Motor} (120% _{Stator}) is exceeded, there will be an error shutdown "F0401". Both events will be triggered by the active data set.

The thermal time constant for the motor is in the range between a couple of minutes and several hours. This motor-specific parameter is set via *Thermal time constant motor* **608**.

The thermal time constant of the stator is much smaller. To protect the stator winding, additional monitoring is required and defined via the *Thermal time constant stator* **609**. For the time constant values, refer to the relevant motor datasheets. If time constants are estimated, optimum motor protection cannot be guaranteed.

Warning thresholds give the user the chance to respond to imminent I²t error shutdown. Via *Warning Limit I²t* **615**, you can choose a value between 6% and 100% of thermal load.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
608	Thermal time constant motor	1 min	240 min	30 min
609	Thermal time constant stator	1 s	600 s	15 s
615	Warning Limit I ² t	6%	100%	80%

Output signals

Digital signals signal that of the function "motor circuit breaker" has been triggered.

180 -	Warning Motor Protection	1)	Triggering of "motor circuit breaker" function as per <i>Operation Mode</i> 571 is reported.
14 -		2)	

1) For linking to frequency inverter functions

2) For output via a digital output.

19.6 V-belt monitoring

Continuous monitoring of the load behavior and thus of the connection between the 3-phase machine and the load is the task of the V-belt monitoring system. Parameter *Operation Mode* **581** defines the function behavior if the *Active Current* **214** (sensorless control) or the torque-forming current component *Isq* **216** (field-oriented control method) is below the set *Trigger Limit Iactive* **582** for longer than the parameterized *Delay Time* **583**.

Operation Mode 581	Function
0 - off	The function is deactivated.
1 - Warning	If the active current drops below the threshold value, the warning "A8000" is displayed.
2 - Fault	The unloaded drive is switched off and error signal "F0402" is displayed

The error and warning messages can be read out by means of the digital outputs (Signal 22 - "Warning V-Belt") or reported to a higher-level control system. The *Trigger Limit Iactive* **582** is to be parameterized as a percentage of the *Rated Current* **371** for the application and the possible operating points.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
582	Trigger limit Iactive	0.1%	100.0%	10.0%
583	Delay time	0.1 s	600.0 s	10.0 s

19.7 Functions of field-oriented control

The field-oriented control systems are based on a cascade control and the calculation of a complex machine model. The various control functions can be supplemented by special functions specific to the application.

19.7.1 Motor chopper

The field-oriented control systems contain the function for adapted implementation of the generator energy into heat in the connected three-phase machine. This enables the realization of dynamic speed changes at minimum system costs. The torque and speed behavior of the drive system is not influenced by the parameterized braking behavior. The parameter *Trigger Threshold 507* of the DC link voltage defines the switch-on threshold of the motor chopper function.

Parameter		Setting			
No.	Description	ACU	Min.	Max.	Factory setting
507	Trigger Threshold	201	225.0 V	1000.0 V	400.0 V
		401	425.0 V		800.0 V
		501	925.0 V	1050.0 V	800.0 V
		601	1225.0 V	1400.0 V	1150.0 V

The parameter *Trigger Threshold 507* is to be set in such a way that it is between the maximum DC link voltage which the mains can generate and the maximum admissible DC link voltage of the frequency inverter.

$$U_{\text{Netz}} \cdot 1,1 \cdot \sqrt{2} < U_{\text{dMC}} < U_{\text{dmax}}$$

If the parameter *Trigger Threshold 507* is set larger than the maximum admissible DC link voltage, the motor chopper cannot become active, the motor chopper is switched off.

If the set *Trigger Threshold 507* is smaller than the maximum DC link voltage the mains can generate, error message F0706 (see Chapter 21.1.1 "21.1.1") is displayed when the frequency inverter is switched on.



The motor chopper function will only work if it was activated via the voltage controllers *Operation Mode 670*. See Chapter 18.2 "18.2".



For synchronous motors (*Configuration 30*=5xx or 6xx), the motor chopper feature is deactivated to prevent the motor from being damaged. The other functions of the voltage controller are not affected by this.



Note that, by default, the motor chopper *Trigger Threshold 507* and brake chopper *Trigger Threshold 506* are set to different values. When using both functions make sure the set thresholds are suitable for the application.

19.7.2 Temperature Adjustment

The field-oriented control systems are based on the most precise calculation of the machine model possible. The rotor time constant is an important machine variable for the calculation. The figure to be read out via the parameter *Act. Rotor Time Constant* **227** is calculated from the inductance of the rotor circuit and the rotor resistance. The dependence of the rotor time constant on the motor temperature can be taken into account in the case of particularly high precision requirements via a suitable measurement. Via *Operation Mode* **465** for the temperature adjustment, you can select different methods and actual value sources for temperature measurement.

Operation Mode 465	Function
0 - off	The function is deactivated.
1 - Temp. meas. on MFI1A	Temperature synchronization (0 ... 200 °C => 0 ... 10 V / 0 ... 20 mA), actual temperature value at multifunction input 1
4 - Temp.meas. upon start	Determination of temperature by frequency inverter via measurement of the winding resistance without external temperature measurement
11 - Vectron temp. meas. on MFI1A	Temperature synchronization; act. temperature value across analog multi-function input. (-26.0 °C ... 207.8 °C => 0 ... 10 V / 0 ... 20 mA)

Operation mode 1 requires an external temperature measurement system which evaluates the temperature sensor and maps the temperature range from 0...200 °C to an analog voltage or current signal. *Operation Mode* **452** of multifunction input MFI1 must be selected accordingly.

Operation mode 4 is available in configurations 210, 211 and 230. When the signals Controller release and Start clockwise or Start anticlockwise are present, the motor temperature and the rotor time constant are synchronized by means of the measured winding resistance.

For Operation Mode 11, an optional temperature measurement board from Bonfiglioli Vectron MDS GmbH is required. This board can be connected to the 20 V power supply on the frequency inverter. This board converts the temperature to an analog voltage or current signal in a range from -26.0 °C to 207.8 °C. The resistance of the measuring resistor KTY84/130 to be used is 1000 Ω at a temperature of 100 °C.

The material used for the rotor winding of the motor is taken into account via the parameter *Temperature Coefficient* **466**. This value defines the change of the rotor resistance as a function of the temperature for a certain material of the rotor winding. Typical temperature coefficients are 39%/100 °C for copper and 36%/100 °C for aluminum at a temperature of 20°C.

The temperature characteristic within the software is calculated via the aforementioned temperature coefficient and the parameter *Adjusting Temperature* **467**. The adjustment temperature enables an additional optimization of the rotor time constant alongside the parameter *Rated Slip Correction Factor* **718**.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
466	Temperature coefficient	0.00%/100 °C	300.00%/100 °C	39.00%/100 °C
467	Adjusting temperature	-50 °C	300 °C	35 °C

The synchronization of the rotor time constant as a function of the winding temperature can be adjusted. The default values should normally be sufficiently precise so that neither an adjustment of the rotor time constants via the parameter *Rated Slip Correction Factor* **718** nor an adjustment of the temperature synchronization via the parameter *Temperature Coefficient* **466** is necessary. If an adjustment is necessary, please remember that the rotor time constant is calculated by the guided commissioning via the machine data. The *Adjusting Temperature* **467** is to be set to the temperature at which the optimization of the extended machine data was carried out. The temperature can be read out via the actual value parameter *Winding Temperature* **226** and can be used in the optimization for the parameter.

19.7.3 Speed sensor monitoring

Failures of the speed sensor lead to a faulty behavior of the drive, as the measured speed forms the foundation of the control system. By default, the speed sensor monitoring system continuously monitors the speed sensor signal, the track signals. If an extension module EM is connected, the number of division marks is monitored additionally. If, while the frequency inverter is released, a faulty signal is recognized for longer than the timeout, a fault switch-off is effected. If parameter *Operation Mode 760* is set to zero, the monitoring function is deactivated.

Operation Mode 760	Function
0 - off	The function is deactivated.
2 - Error	A error signal is displayed according to the timeouts set.

The speed sensor monitoring is to be parameterized in the part functions according to the application. The monitoring function becomes active with the release of the frequency inverter and the start command. The timeout defines a monitoring time in which the condition for the fault switch-off must be fulfilled without interruption. If one of the timeouts is set to zero, this monitoring function is deactivated.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
761	Timeout: Signal fault	0 ms	65000 ms	1000 ms
762	Timeout: Track fault	0 ms	65000 ms	1000 ms
763	Timeout: Direction of rotation fault	0 ms	65000 ms	1000 ms

Timeout: Signal fault

The actual speed measured is compared with the output value of the speed controller. If the actual speed value is exactly zero for the time selected with the parameter *Timeout: Signal fault 761*, although a reference value is available, the fault is displayed with message "F1430".

Timeout: Track fault


The actual speed measurement monitors the sequence in time of the signals in the quadruple evaluation of the speed sensor operation mode. If the speed sensor signal is faulty for the time selected with the parameter *Timeout: Channel fault 762*, the fault is displayed with message "F1430".

Timeout: Direction of rotation fault

The actual speed measured is compared with the reference speed. If the sign between reference value and actual value differs for the time selected with parameter *Timeout: Direction fault 763*, the fault is displayed with the message "F1432". The monitoring function is reset when the drive mechanism has moved in the reference value direction by a quarter of a revolution.


19.8 Traverse function

With the traverse function, the a triangle-shaped frequency signal with the start-up and shut-down times to be set is superimposed on the output frequency. The resulting chronological order of the reference frequency of master drive and slave drive are shown in the following diagrams. The function can be used, for example, for drives which wind up thread on coils in textile machines. To avoid winding errors at the turning point of the thread guide, a proportional jump is performed which causes a quick speed change.



In the case of the master drive, the superimposed traverse frequency is linearly opposite to the limit **Traverse Amplitude 438** and will then reverse its direction. When the direction is reversed, a proportional jump is effected. Via a handshake signal, the master drive informs the slave drive that the traverse output has changed its direction. The traverse function of the slave drive has the same gradient as the traverse function of the master drive, but an opposite sign. When the slave drive reaches the limit **Traverse Amplitude 438** before switch-over of the handshake signal, the frequency is maintained until switch-over is effected. If the handshake signal is received before the frequency limit is reached, the direction is reversed immediately.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
436	Startup time	0.01 s	320.00 s	5 s
437	Shut-down time	0.01 s	320.00 s	5 s
438	Traverse amplitude	0.01 %	50.00 %	10 %
439	Proportional jump	0.01 %	50.00 %	0.01%



Signal "14 – Output Wobble" is added to the reference frequency value.

Via parameter *Operation Mode* **435**, the drive is configured as a master drive or slave drive.

Operation Mode 435	Function
0 - off	The traverse function is deactivated.
1 - Master drive	Operation as master drive.
2 - Slave drive	Operation as slave drive.

For traverse mode, the reference value source is selected via parameter *Reference Frequency* **48**.

Traverse mode becomes active once the *Reference Frequency* **48** is reached for the first time. This frequency is reached via the values for *Acceleration (Clockwise)* **420**, *Acceleration Anticlockwise* **422**, *Deceleration (Clockwise)* **421** and *Deceleration Anticlockwise* **423**. In traverse mode, the values for *Acceleration Time* **436** and *Deceleration Time* **437** are active.

The frequency range for traverse mode is limited by *Minimum Frequency* **418** and *Maximum Frequency* **419**.

During traverse operation, the configured traverse parameter values cannot be changed.

The source of the handshake signal is selected via *Handshake Traverse Function* **49**.

19.9 Profibus/Internal Notation converter

With the Profibus/Internal Notation converter ("Convert Profibus/Intern"), you can convert a 16 bit word to an internal 32 bit frequency value and vice versa. This is useful, for example, if several devices are networked via System Bus and only 1 device is provided with a Profibus option for cost reasons. By forwarding the Profibus word via System Bus ("Tunneling"), you can reduce the bandwidth needed in System Bus and make parameterization of the "Gateways" (System Bus Master with Profibus Slave communication module) easier. In this case, the converter is used without Profibus module in one device in order to convert the Profibus notation to an internal reference value.

Parameter		Setting		
No.	Description	Min.	Max.	Factory setting
1370	In-F-PDP-word 1	Selection		
1371	In-F-PDP-word 2	Selection		
1372	In-F-intern long 1	Selection		
1373	In-F-intern long 2	Selection		
1374	In-F-Convert Reference	0.01 Hz	599.00 Hz	50.00 Hz

Likewise, the current frequency can be converted to a value based on Profibus notation, for example.

The converter can also be used for other purposes, e.g. using the internal PLC programming.

In-F-PDP-word 1 **1370** and *In-F-PDP-word 2* **1371** convert Profibus notation to internal frequency representations. 0x4000 in Profibus notation (=100 %) corresponds to *In-F-Convert Reference* **1374** in Hz.

In-F-intern-long 1 **1372** and *In-F-intern-long 2* **1373** convert internal frequency values to Profibus notation. 0x4000 in Profibus notation (=100 %) corresponds to *In-F-Convert Reference* **1374** in Hz.

Profibus notation is limited to values from -200 % (0x8000) to +200 % (0x7FFF).

0x4000	= 100 %	= <i>In-F-Convert Reference</i> 1374
0x7FFF	= 200 %	= <i>2x In-F-Convert Reference</i> 1374
0x8000	= -200 %	= <i>-2x In-F-Convert Reference</i> 1374
0xC000	= -100 %	= <i>-In-F-Convert Reference</i> 1374

The values converted in this way are available as internal sources.

774 – Out-F-PDP-Conv1-long1 as output of
In-F-PDP-word 1 **1370** (Profibus not. → frequency)

775 – Out-F-PDP-Conv1-long2 as output of
In-F-PDP-word 2 **1371** (Profibus not. → frequency)

776 – Out-F-PDP-Conv1-word1 as output of
In-F-PDP-long 1 **1372** (Frequency → Profibus not.)

777 – Out-F-PDP-Conv2-word2 as output of
In-F-PDP-long 2 **1373** (Frequency → Profibus not.)

20 Actual values

The various control functions and methods include electrical control variables and various calculated actual values of the machine or system. The different actual values can be read out for operational and error diagnosis via a communication interface or in the "VAL" menu branch of the control unit.

20.1 Actual values of frequency inverter

The modular hardware of the frequency inverter enables application-specific adaptation. Further actual value parameters can be displayed as a function of the selection configuration and the installed expansion cards.

Actual values of frequency inverter		
No.	Description	Function
222	DC-Link Voltage	Direct voltage in DC-link.
223	Modulation	Output voltage of the frequency inverter relative to the mains voltage (100% = U_{FIN})
228	Internal Reference Frequency	Sum of the <i>Reference Frequency Sources 475</i> as a reference value from the frequency reference value channel
229	Reference Percentage Value	Sum of the <i>Reference Percentage Sources 476</i> as a reference value from the reference percentage channel
230	Actual Percentage Value	Actual value signal at <i>Actual Percentage Source 478</i>
243	Digital Inputs hardware	Decimally coded status of the six digital inputs and of Multifunction input 1 in <i>Operation mode 452</i> - Digital Input. Represents the status of the physical inputs (also refer to <i>Digital inputs 250</i>).
244	Working Hours Counter	Working hours in which the output stage of the inverter is active.
245	Operation Hours Counter	Operating hours of the frequency inverter in which supply voltage is available.
249	Active Data Set	The data set actively in use according to <i>Data Set Change-Over 1 70</i> and <i>Data Set Change-Over 2 71</i> .
250	Digital Inputs	Decimally coded status of the six digital inputs and of Multifunction input 1 in <i>Operation mode 452</i> - Digital Input.
251	Analog Input MFI1A	Input signal at Multifunction input 1 in analog <i>Operation mode 452</i>
252	Repetition Frequency Input	Signal at repetition frequency input according to <i>Operation mode 496</i> .
254	Digital Outputs	Decimally coded status of the two digital outputs and of Multifunction output 1 in <i>Operation mode 550</i> - Digital
255	Heat Sink Temperature	Measured heat sink temperature.
256	Inside Temperature	Measured inside temperature.
257	Analog Output MFO1A	Output signal at Multifunction output signal 1 in <i>Operation mode 550</i> - Analog.
258	PWM input	Pulse-width modulated signal at PWM input according to <i>Operation Mode 496</i> .
259	Current Error	Error message with error code and abbreviation.
269	Warnings	Warning message with warning code and abbreviation.
273	Application Warnings	Warning message application with warning code and abbreviation.

Actual values of frequency inverter		
No.	Description	Function
275	Controller Status	The reference value signal is limited by the controller coded in the controller status.
277	STO Status	Signal status of switch-of paths STOA (digital input S1IND/STOA) and STOB (S7IND/STOB) of safety function "STO – Safe Torque Off".
278	Frequency MFO1F	Output signal on Multifunction output 1 in <i>Operation mode 550</i> – repetition frequency



In addition to the actual values shown, other actual values are available and can be read out via field bus.

This includes, in particular, parameters *Current Error 260*, *Warnings 270* and *Application Warnings 274* where the relevant message can be read out as hexadecimal code (and without texts). Please refer to the communication manuals.



The actual values can be read out and monitored in the VAL menu branch of the operating unit. The parameter *Control Level 28* in the PARA menu branch defines the selection of the actual value parameters.



In the actual value display **243**, **250**, the digital inputs cannot be active (permanently "0"). This can be caused by the configuration or functions used (e.g. sensor input or frequency input).

Input	Deactivation mechanism for actual value display
S2IND	PWM / Rep. frequ. Input
S4IND	Track B (speed sensor 1)
S5IND	Track A (speed sensor 1)
S6IND	Track Z (speed sensor 1) or PWM / Rep. frequ. Input
MFI1	Analog input

Setting:

For speed sensor 1, check Parameter *Operation Mode 490*.

For PWM / Rep. frequ. input, check parameter *Operation Mode 496*.

For MFI1, check Parameter *Operation Mode 452*.

Actual value:

Encoder 1 Frequency is shown in **217**, speed in **218**.

PWM/rep.frequ. input: PWM is shown in **258**, frequency in **252**.

20.1.1 STO Status

Parameter *STO Status* **277** can be used for extended diagnosis of the two inputs STOA and STOB. The statuses of the inputs are shown in bit-encoded form.

Bit	Value	Meaning
0	1	STOA input missing.
1	2	STOB input missing.
2	4	Switch off STOA input.
3	8	Switch off STOB input.
4	16	Timeout STOA.
5	32	Timeout STOB.
6	64	Diagnosis error.
7	128	FI error (fault).

With correct wiring and correct function, only the 2 states "0" (= STO enabled) and "3" (= STO disabled) are typically shown (decimal representation) in parameter *STO Status* **277**.

The signal states at digital inputs STOA and STOB can be linked to functions of the frequency inverter.

292 -	STOA	Signal state at digital input STOA
284 -	STOA inverted	Inverted signal state at digital input STOA
293 -	STOB	Signal state at digital input STOB
285 -	STOB inverted	Inverted signal state at digital input STOB

Refer to Application manual "Safe Torque Off STO".

20.2 Actual values of machine

The frequency inverter controls the behavior of the machine in the various operating points. As a function of the configuration selected and the expansion cards installed, control variables and further actual value parameters of the machine can be displayed.

Actual values of machine		
No.	Description	Function
210	Stator frequency	The output voltage (motor voltage) of the frequency inverter.
211	R.m.s Current	Calculated effective output current (motor current) of the frequency inverter.
212	Output Voltage	Calculated effective value of linked output voltage (motor voltage) of frequency inverter.
213	Active Power	Active power calculated from the voltage, the current and the control variables.
214	Active Current	Active current calculated from the rated motor parameters, the control variables and the current.
215	Isd	Current component of the field-oriented control forming the magnetic flux.
216	Isq	Torque-forming current component of field-oriented control.
217	Encoder 1 Frequency	Calculated from the data on speed sensor 1, the No. of Pole Pairs 373 and the speed sensor signal
218	Encoder 1 Speed	Calculation from Encoder 1 Frequency
221	Slip Frequency	Difference from the synchronous frequency calculated from the rated motor parameters, the control variables and the current.
224	Torque	Torque at the current output frequency calculated from the voltage, the current and the control variables.
225	Rotor Flux	Current magnetic flux relative to the rated motor parameters.

226	Winding Temperature	Measured temperature of the motor winding according to Operation Mode 465 for temperature adjustment
227	Act. Rotor Time Constant	Time constant calculated for the operating point of the machine from the rated motor parameters, the rated and control variables
235	Flux-Forming Voltage	Voltage component of the field-oriented control forming the magnetic flux.
236	Torque-Forming Voltage	Voltage component of the field-oriented control forming the torque.
238	Flux Value	Magnetic flux calculated according to the rated values and the operating point of the motor.
239	Reactive Current	Reactive current calculated from the rated motor parameters, the control variables and the current.
240	Actual Speed	Measured or calculated speed of drive.
241	Actual Frequency	Measured or calculated frequency of drive.



The actual values can be read out and monitored in the VAL menu branch of the operating unit. Parameter *Control Level* **28** in PARA menu branch defines the selection of the actual value parameters to be selected.

20.3 Actual value memory

The assessment of the operating behavior and the service of the frequency inverter in the application are facilitated by storing various actual values. The actual value memory guarantees monitoring of the individual variables for a definable period. The parameters of the actual value memory can be read out via a communication interface and displayed via the operating unit. In addition, the operating unit provides monitoring of the peak and mean values in the VAL menu branch.

Actual value memory		
No.	Description	Function
231	Peak Value Long Term Ixt	utilization of the device-dependent overload of 60 seconds.
232	Peak Value Short Term Ixt	Utilization of the device-dependent overload of 1 second.
287	Peak Value Vdc	The maximum DC link voltage measured.
288	Average Value Vdc	The mean DC link voltage calculated in the period of observation.
289	Peak Value Heat Sink Temp.	The highest measured heat sink temperature of the frequency inverter.
290	Average Value Heat Sink Temp.	The mean heat sink temperature calculated in the period of observation.
291	Peak Value Inside Temperature	the maximum measured inside temperature in the frequency inverter
292	Average Value Inside Temperature	The mean inside temperature calculated in the period of observation.
293	Peak Value Irms	The highest abs. current calculated from the measured motor phases.
294	Average Value Irms	The mean abs. current calculated in the period of observation.
295	Peak Value Active Power pos.	The largest calculated active power in motor operation.
296	Peak Value Active Power neg.	Maximum generator active power calculated from the voltage, the current and the control variables.
297	Average Value Active Power	The mean active power calculated in the period of observation.
301	Energy, positive	The calculated energy to the motor in motor operation.

302	Energy, negative	The calculated energy from the motor in generator operation.
-----	------------------	--



The actual values can be read out and monitored in the VAL menu branch of the operating unit. Parameter *Control Level* **28** in PARA menu branch defines the selection of the actual value parameters to be selected.

Parameter *Reset Memory* **237** which is to be selected in the PARA menu branch of the operating unit enables purposeful resetting of the individual mean and peak values. The peak value and the mean value with the values stored in the period are overwritten with the parameter value zero.

Reset Memory 237	Function
0 - No Reset	Values of actual value memory remain unchanged.
1 - Peak Value Long Term Ixt	Reset Peak Value Long Term Ixt 231
2 - Peak Value Short Term Ixt	Reset Peak Value Short Term Ixt 232
3 - Peak value Vdc	Reset Peak Value Vdc 287 .
4 - Average value Vdc	Delete Average Value Vdc 288 .
5 - Peak value Tc	Reset Peak Value Heat Sink Temp. 289 .
6 - Average Tc	Delete Average Value Heat Sink Temp. 290 .
7 - Peak value Ti	Reset Peak Value Inside Temperature 291 .
8 - Average Ti	Delete Average Value Inside Temperature 292 .
9 - Peak Value Irms	Reset Peak Value Irms 293 .
10 - Average Value Irms	Delete Average Value Irms 294 .
11 - Peak value Pactive pos.	Reset Peak Value Active Power pos. 295 .
12 - Peak value Pactive neg.	Reset Peak Value Active Power neg. 296 .
13 - Average Pactive	Delete Average Value Active Power 297 .
16 - Energy, positive	Reset parameter Energy, positive 301 .
17 - Energy, negative	Reset parameter Energy, negative 302 .
100 - All peak values	Reset all saved peak values.
101 - All average values	Delete average values and saved values.
102 - All values	Delete the entire actual value memory.

20.4 Actual values of the system

The calculation of the actual figures of the system is based on the parameterized system data. Specific to the application, the parameters are calculated from the factors, electrical variables and the controls. The correct display of the actual figures is a function of the data of the system to be parameterized.

20.4.1 Actual value system

The drive can be monitored via actual value *Actual Value System* **242**.

The *Actual Frequency* **241** to be monitored is multiplied by the *Factor Actual Value System* **389** and can be read out via parameter *Actual Value System* **242**, i.e. *Actual Frequency* **241** x *Factor Actual Value System* **389** = *Actual Value System* **242**.

Actual Value System		
No.	Description	Function
242	Actual Value System	Calculated frequency of drive.

20.4.2 Volumetric Flow and Pressure

Parameterization of factors *Nominal Volumetric Flow* **397** and *Nominal Pressure* **398** is necessary when the corresponding actual values *Volumetric Flow* **285** and *Pressure* **286** are used for drive monitoring. The conversion is done using the electrical control parameters. *Volumetric Flow* **285** and *Pressure* **286** are referred to the *Active Current* **214** in the case of the sensorless control methods. In the case of the field-oriented control methods, they are referred to the torque-forming current component *Isq* **216**.

Volumetric Flow and Pressure		
No.	Description	Function
285	Volumetric Flow	Calculated volumetric flow in m ³ /h.
286	Pressure	Pressure calculated according to the characteristic with the unit kPa.

21 Error protocol

The various control methods and the hardware of the frequency inverter include functions which continuously monitor the application. The operational and error diagnosis is facilitated by the information stored in the error protocol.

21.1 List of errors

The last 16 error signals are stored in chronological order and *No. of Errors* **362** shows the number of errors which have occurred since initial commissioning of the frequency inverter. The error code FXXXX is displayed in menu branch VAL of the control unit. For the meaning of the error code, refer to the following chapter 21.1.1 "21.1.1". Via the PC user interface, the number of operation hours (h), operation minutes (m) and the error signal can additionally be read out. The current operating hours can be read out via *Operation Hours Counter* **245**. The error message can be acknowledged via the keys of the operating unit and according to *Error Acknowledgment* **103**.

List of errors		
No.	Description	Function
310	Last Error	hhhhh:mm ; FXXXX error message.
311	Last Error but one	hhhhh:mm ; FXXXX error message.
312 to 325		Error 3 to error 16.
362	No. of Errors	Number of errors occurred after the initial commissioning of the frequency inverter.

The error and warning behavior of the frequency inverter can be set in various ways. The automatic error acknowledgment enables acknowledgment of the faults Overcurrent F0500, Overcurrent F0507 and Overvoltage F0700 without intervention by an overriding control system or the user. The *No. of self acknowledged Errors* **363** shows the total number of automatic error acknowledgments.

List of errors		
No.	Description	Function
363	No. of self acknowledged Errors	Total number of automatic error acknowledgment with synchronization.

21.1.1 Error messages

The error code saved after a fault consists of the error group FXX and the code number XX.

Error messages		
Key		Meaning
F00	00	No fault has occurred.
Overload		
F01	00	Frequency inverter overloaded.
F01	02	Frequency inverter overloaded (60 s), check load behavior
	03	Short-term overload (1 s), check motor and application parameters

Table "Fault Messages" continued on next page.

Heat sink		
Key		Meaning
F02	00	Heat sink temperature too high, check cooling system and fan.
	01	Temperature sensor defective or ambient temperature too low.
Interior		
F03	00	Interior temperature too high, check cooling system and fan.

	01	Interior temperature too low, check control cabinet heating.
Motor connection		
F04	00	Motor temperature too high or sensor defective, check connection S6IND.
	01	Motor circuit breaker tripped, check drive.
	02	V-belt monitoring reports no load on the drive.
	03	Phase failure, check motor and wiring.
	04	Control Deviation Position Controller Refer to Positioning application manual.
	05	Start monitoring. Check brake & limiting parameters, such as <i>Current Limit 728</i> , intelligent current limits, etc.
Output current		
F05	00	Overloaded, check load situation and ramps.
	01	Instantaneous output current value too high. Check load.
	02	Dynamic phase current limitation. Check load.
	03	Short circuit or earth fault, check motor and wiring.
	04	Overloaded, check load situation and current value limit controller.
	05	Asymmetric motor current, check current and wiring.
	06	Motor phase current too high, check motor and wiring.
	07	Message from phase monitoring, check motor and wiring.
DC-Link Voltage		
F07	00	DC link voltage too high, check deceleration ramps and connected brake resistor.
	01	DC link voltage too low, check mains voltage.
	02	Mains failure, check mains voltage and circuit.
	03	Phase failure, check mains fuse and circuit.
	04	<i>Reference DC-Link Limitation 680</i> too small, check mains voltage.
	05	Brake chopper <i>Trigger Threshold 506</i> too small, check mains voltage
	06	Motor chopper <i>Trigger Threshold 507</i> too small, check mains voltage
Electronic voltage		
F08	01	Electronics voltage DC 24 V too low, check control terminal.
	04	Electronic voltage too high, check wiring of control terminals.
Brake chopper		
F10	10	Also refer to Chapter 19.4 "19.4".
Output frequency		
F11	00	Output frequency too high, check control signals and settings.
	01	Max. frequency achieved by control, check deceleration ramps and connected brake resistor.
	10	Frequency limit See application manual "Hoisting Gear Drives".

Table "Fault Messages" continued on next page.

Safety function STO		
Key		Meaning
F12	01	Diagnosis error of function STO; at least one of the shut-down paths STOA and STOB is defective. Check the devices connected to the shut-down paths; check wiring and EMC.
	04	Software self-diagnosis has detected an internal error. Please contact your local BONFIGLIOLI subsidiary.
	05	Error signal of 5-second monitoring. Shut-down paths STOA and STOB were not actuated at the same time, but with an offset of more than 5 seconds. Check addressing of shut-down paths or control of protection provision.
Motor connection		
F13	00	Earth fault on output, check motor and wiring.
	01	Set <i>IDC Compensation Limit</i> 415 reached, check motor and cabling, increase limit, if necessary
	10	Minimum current monitoring, check motor and wiring.
Control connection		
F14	01	Reference value at multifunction input 1 faulty, check signal.
	02	Reference value signal at EM-S1INA defective, check signal.
	07	Overcurrent at multifunction input 1, check signal.
	21	Resolver error. Check resolver connection and speed.
	22	Resolver counting error. Check resolver connection.
	23	Resolver, wrong no. of pole pairs. Check no. of pole pairs parameters.
	24	Resolver connection error. Check resolver connection.
	30	Encoder signal defective, check connections S4IND and S5IND.
	31	One track of the speed sensor signal is missing, check connections.
	32	Direction of rotation of speed sensor wrong, check connections.
	33	Encoder 2: Division Marks Fault Check encoder settings.
	34	Too few encoder division marks Check encoder settings.
	35	Too many encoder division marks. Check encoder settings.
	36	Encoder 1 Division Marks Fault Correct <i>Division Marks</i> 491 of speed sensor 1; also refer to Chapter 11.4.2 "11.4.2".
	37	Speed sensor was deactivated. A speed sensor must be activated in configurations 210, 211 and 230. Set evaluation for parameter <i>Operation Mode</i> 490 (not "0 – off"). If an extension module is installed and setting "2 – speed sensor 2" is selected for parameter <i>Actual Speed Source</i> 766 , you will have to set an evaluation for parameter <i>Operation Mode</i> 493 (speed sensor 2).
38	Motor blocked. For the time set in 782 Timeout: Drive blocked the drive will work at the current limit (728 Current Limit). Check encoder/resolver settings. Check if parameter 728 Current Limit was set too low. In some situations it may be a good idea to increase the value of 782 Timeout: Drive blocked . Permanent deactivation of encoder monitoring via 760 Operation Mode is not recommended.	
50	KTY temperature monitoring error. Check KTY connection.	
54	External error; drive responded according to parameter setting for <i>Op. Mode ext. Error</i> 535 . Error was triggered via the logic signal or digital input signal assigned to parameter <i>External Error</i> 183 .	
Positioning		
F14	4n	Positioning error Refer to Positioning application manual.
	5n	
	6n	
	7n	
Absolute encoder		
F14	8n	Error in absolute encoder capturing. Please refer to EM-ABS-01 instructions.
	9n	

Table "Fault Messages" continued on next page.

Positioning		
Key	Meaning	
F15	nn	Positioning error Refer to Positioning application manual.
Absolute encoder		
F17	nn	Error in absolute encoder capturing. Please refer to EM-ABS-01 instructions.
Modbus and VABus		
F20	10	Communication error as defined by parameter <i>CM: VABus Watchdog Timer</i> 413 .
CANopen		
F20	21	CAN Bus OFF
	22	CAN Guarding
	23	Error state
	24	SYNC error (SYNC timing)
	25	CAN error state
	26	RxPDO1 length error
	27	RxPDO2 length error
	28	RxPDO3 length error
	2A	CAN RxPDO1 Timeout
	2B	CAN RxPDO2 Timeout
	2C	CAN RxPDO3 Timeout
Number of received bytes differs from mapping.		
DeviceNet		
F20	5n	DeviceNet error. Please refer to DeviceNet instructions.
PROFIBUS		
F20	6n	PROFIBUS error. Please refer to PROFIBUS instructions.
System Bus		
F21	nn	Error signal in system bus master with fault in system bus slave, nn = node ID of slave (hex)
F22	00	Communication fault, system bus, Sync timeout telegram
	01	Communication fault, system bus, timeout RxPDO1
	02	Communication fault, system bus, timeout RxPDO2
	03	Communication fault, system bus, timeout RxPDO3
	10	Communication fault, system bus, bus off
CANopen		
F23	nn	Heartbeat error, nn = triggering node.
CM-module identification		
F24	00	Unknown CM Module Verify firmware and CM module compatibility.
EM-module identification		
F25	00	Unknown EM Module Verify firmware and EM module compatibility.
Industrial Ethernet		
F27	nn	Industrial Ethernet error. Please follow instructions on the Ethernet module used.
EtherCAT		
F28	nn	EtherCAT error.

Table "Fault Messages" continued on next page.

User error VPLC		
Key	Meaning	
F30	3n	Error in internal PLC function caused by user. Please refer to VPLC application manual.
Optional components		
F0A	10	Data transmission from control unit KP 500 to the frequency inverter not possible. At least one file must be stored in the control unit.
F0B	13	The communication module was fitted to slot B without disconnection of the mains voltage, switch mains voltage off.
Internal monitoring		
F0C	40	After 6 warm starts in less than 3 minutes, this error will be triggered. Most probably, the PLC or function table were programmed incorrectly. In addition, the function table will be stopped (P.1399 = 0 in RAM only).

Output signals in the case of error messages

Errors are reported via digital signals.

162 -	Error Signal	¹⁾	A monitoring functions reports an error displayed via parameter <i>Current Error</i> 259 .
3 -		²⁾	

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.

In addition to error signals mentioned, there are further error signals. However these messages are only used for internal purposes and are not listed here. If you receive error signals which are not listed here, please contact the BONFIGLIOLI customer service.

Please download the parameter file to your PC before contacting us.

21.2 Error environment

The parameters of the error environment help troubleshooting both in the settings of the frequency inverter and also in the complete application. The error environment documents the operational behavior of the frequency inverter at the time of the last four faults.

Error environment		
No.	Description	Function
330	DC-Link Voltage	Direct voltage in DC-link.
331	Output voltage	Calculated output voltage (motor voltage) of the frequency inverter.
332	Stator frequency	The output voltage (motor voltage) of the frequency inverter.
333	Frequency Speed Sensor 1	Calculated from the data on speed sensor 1, the <i>No. of Pole Pairs</i> 373 and the speed sensor signal.
335	Phase Current Ia	Measured current in motor phase U.
336	Phase Current Ib	Measured current in motor phase V.
337	Phase Current Ic	Measured current in motor phase W.
338	R.m.s Current	Calculated effective output current (motor current) of the frequency inverter.
339	Isd/Reactive Current	Current component forming the magnetic flux or the calculated reactive current.
340	Isq/Active Current	Current component forming the torque or the calculated active current.
341	Rotor Magnetizing Current	Magnetizing current relative to the rated motor parameters and the operating point.
342	Torque	Torque calculated from the voltage, the current and the control variables.

Error environment		
No.	Description	Function
343	Analog Input MFI1A	Input signal at Multifunction input 1 in analog <i>Operation Mode 452</i> .
346	Analog Output MFO1A	Output signal at Multifunction output signal 1 in <i>Operation Mode 550</i> – Analog.
349	Repetition Frequency Output	Signal at repetition frequency output according to <i>Operation Mode 550</i> – repetition frequency
350	Status of Digital Inputs	Decimally coded status of the six digital inputs and of Multifunction input 1 in Operation mode 452 - Digital Input.
351	Status of Digital Outputs	Decimally coded status of the two digital outputs and of Multifunction output 1 in <i>Operation Mode 550</i> - Digital
352	Time since Release	The time of the error in hours (h), minutes (m) and seconds (s) after the release signal: hhhhh:mm:ss . $\frac{\text{sec}}{10}$ $\frac{\text{sec}}{100}$ $\frac{\text{sec}}{1000}$.
353	Heat Sink Temperature	Measured heat sink temperature.
354	Inside Temperature	Measured inside temperature.
355	Controller Status	The reference value signal is limited by the controller coded in the controller status.
356	Warning Status	The warning messages coded in warning status.
357	Int. value 1	Software service parameter.
358	Int. value 2	Software service parameter.
359	Long value 1	Software service parameter.
360	Long value 2	Software service parameter.
367	Application Warning Status	The application warnings coded in warning status.

Parameter *Checksum* **361** shows whether the storage of the error environment was free of errors (OK) or incomplete (NOK).


Error environment		
No.	Description	Function
361	Checksum	Check protocol of the error environment.

22 Operational and error diagnosis

Operation of the frequency inverter and the connected load are monitored continuously. Various functions document the operational behavior and facilitate the operational and error diagnosis.

22.1 Status display


The green and red light-emitting diodes give information about the operating point of the frequency inverter. If the control unit is connected, the status messages are additionally displayed by the display elements RUN, WARN and FAULT.



Status indication			
green LED	red LED	Display	Description.
off	off	-	no supply voltage.
on	on	-	initialization and self-test.
flashing	off	RUN flashing	ready, no output signal.
on	off	RUN	operating message.
on	flashing	RUN + WARN	Operating message, current <i>Warning 269</i> .
flashing	flashing	RUN + WARN	Ready for operation, current <i>Warning 269</i> .
off	flashing	FAULT flashing	<i>Last Error 310</i> of frequency inverter.
off	on	FAULT	<i>Last Error 310</i> , acknowledge fault.

22.2 Status of digital signals

The status display of the digital input and output signals enables checking of the various control signals and their assignment to the corresponding software functions, in particular during commissioning.



A decimal value is displayed, indicating the status of the digital signals in bits after conversion into a binary figure.

Example: Decimal value 33 is displayed. Converted into the binary system, the number reads **00100001**. Thus, the following contact inputs or outputs are active:

- Control signal at digital input or output 1
- Control signal at digital input or output 6

22.3 Controller Status

The controller status can be used to establish which of the control functions are active. If a several controllers are active at the time, a controller code composed of the sum total of the individual codes is displayed. The display of the controller status by the control unit and the light-emitting diodes can be parameterized via the *Controller-Status Message 409*.

Coding of the controller status	
CXXXX Controller key	ABCDE Controller abbreviation
Key	Controller Status
C 00 00 -	No controller active.
C 00 01 UDdyn	Voltage controller is in the rise phase according to <i>Operation Mode 670</i>
C 00 02 UDstop	The output frequency in power failure is below the <i>Shutdown Threshold 675</i>
C 00 04 UDctr	Failure of the mains voltage and power regulation active according to <i>Operation Mode 670</i> of the voltage controller
C 00 08 UDim	DC-Link voltage exceeded <i>Reference DC-Link Limitation 680</i> .
C 00 10 Boost	The <i>Dyn. Voltage Pre-Control 605</i> accelerates the control system.
C 00 20 Ilim	The output current is limited by the current limit value controller or the speed controller.
C 00 40 Tlim	The output power or the torque are limited by the speed controller
C 00 80 Tctr	Switch-over of field-oriented control between speed and torque-controlled control method.
C 01 00 Rstp	The <i>Operation Mode 620</i> selected in starting behavior limits the output current
C 02 00 IxtLtLim	Overload limit of the long-term Ixt (60s) reached, intelligent current limits active
C 04 00 IxtStLim	Overload limit of the short-term Ixt (1s) reached, intelligent current limits active.
C 08 00 Tclim	Max. heat sink temperature T_K reached, intelligent current limits of <i>Operation Mode 573</i> active.
C 10 00 PTCLim	Max. motor temperature T_{PTC} reached, intelligent current limits of <i>Operation Mode 573</i> active
C 20 00 Flim	Reference frequency has reached the <i>Maximum Frequency 419</i> . The frequency limitation is active.

Example: The controller status is displayed as **C0024 UDctr Ilim**

The controller status results from the hexadecimal sum of the controller codes (0004+0020 = 0024). At the same, the power failure regulation and also the current limitation of the speed controller are active.

22.4 Warning Status and Warning Status Application

The current warning is displayed by a message in the warning status and can be used for early reporting of a critical operational condition. If a warning is present, this is indicated by the flashing red LED and the display field WARN of the control unit. If several warnings are present, the warning status is displayed as the sum of the individual warning codes.

The warning masks created through parameters *Create Warning Mask 536* and *Create Appl. Warning Mask 626* have no influence on the warnings displayed. Via actual value parameters *Warnings 269*, *Application Warnings 273*, *Warning Status 356* (in error environment) and *Application Warning Status 367* (in error environment) all warnings present at the time of the error are displayed.

Coding of the warning status

AXXXX	ABCDE
Warning key	Warning abbreviation

Meaning of key displayed by parameter *Warning Status 356*:

Key	Warning Status
A 00 00 -	No warning present.
A 00 01 Ixt	Frequency inverter overloaded (A0002 or A0004)
A 00 02 IxtSt	Overload for 60 s relative to the nominal output of the frequency inverter
A 00 04 IxtLt	Short-time overload for 1 s relative to the nominal output of the frequency inverter.
A 00 08 Tc	Max. heat sink temperature T_K of 80 °C minus <i>Warning Limit Heat Sink Temp. 407</i> reached.
A 00 10 Ti	Max. inside temperature T_i of 65 °C minus <i>Warning Limit Inside Temp. 408</i> reached.
A 00 20 Lim	The controller stated in <i>Controller Status 275</i> is limiting the reference figure.
A 00 40 INIT	Frequency inverter is being initialized
A 00 80 PTC	Warning behavior as per configured <i>Motor Temp. Operation Mode 570</i> at max. motor temperature T_{Motor} .
A 01 00 Mains	<i>Phase Supervision 576</i> reports mains phase failure.
A 02 00 PMS	Motor circuit breaker parameterized in <i>Operation Mode 571</i> tripped.
A 04 00 Flim	The <i>Maximum Frequency 419</i> was exceeded. The frequency limitation is active.
A 08 00 A1	The input signal MFI1A is lower than 1 V / 2 mA according to the operation mode for the <i>Error/Warning Behavior 453</i> .
A 10 00 A2	The input signal is lower than 1 V / 2 mA according to the operation mode for the <i>Error/Warning Behavior 453</i> .
A 20 00 SYS	A slave on the system bus reports a fault; warning is only relevant with the EM-SYS option.
A 40 00 UDC	The DC link voltage has reached the type-dependent minimum value.
A 80 00 WARN2	In <i>Application Warning Status 367</i> , a warning is present.

Example: The following warning status is displayed:

A008D Ixt IxtLt Tc PTC

The warning status results from the hexadecimal sum of the warning codes (0001+0004+0008+0080 = 008D).

The short-term overload (1 s), warning limit heat sink temperature and warning limit motor temperature warnings are present.

Output signals

Warnings are signaled via digital signals .

169 -	General Warning	¹⁾	Signal when message is output in <i>Warnings</i> 269 .
11 -	General warning	²⁾	

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.

Meaning of code displayed by parameter *Application Warning Status* **367**:

Key			Warning Status
A 00	00	NO WARNING	No warning present.
A 00	01	BELT	Warning V-Belt by <i>Operation Mode</i> 581 .
A 00	02	SW-LIM CW	Positive SW limit switch was reached (parameter <i>Pos. SW Limit Switch</i> 1145).
A 00	04	SW-LIM CCW	Negative SW limit switch was reached (parameter <i>Neg. SW Limit Switch</i> 1146).
A 00	08	HW-LIM CW	The positive HW limit switch was reached.
A 00	10	HW-LIM CCW	The negative HW limit switch was reached.
A 00	20	CONT	The contouring error monitoring range set with <i>Warning Threshold</i> 1105 was left.
A 00	40	Enc	A connected encoder with data track triggered a warning.
A 00	80	User 1	The signal set at digital input <i>User Warnig 1 I</i> 1363 is active.
A 01	00	User 2	The signal set at digital input <i>User Warnig 2 I</i> 1364 is active.

Output signals

Application Warnings are signaled via digital signals .




216 -	Warning, application	¹⁾	Signal when message is output in <i>Application Warnings</i> 273 .
26 -		²⁾	

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output.

23 List of parameters

The parameter list is structured according to the menu branches of the control unit. The parameters are listed in ascending numerical order. A headline (shaded) can appear several times, i.e. a subject area may be listed at different places in the table. For better clarity, the parameters have been marked with pictograms:

-  The parameter is available in the four data sets.
-  The parameter value is set by the SETUP routine.
-  This parameter cannot be written when the frequency inverter is in operation.

I_{FIN} , U_{FIN} , P_{FIN} : Rated values of frequency inverter, o: Overload capacity of frequency inverter

(201) Setting in ACU **201** devices

(401) Setting in ACU **401** devices

(501) Setting in ACU **501** devices

(601) Setting in ACU **601** devices

ACU 201 devices: $U_{dmax} = 400$ V, ACU 401 devices: $U_{dmax} = 800$ V,

ACU 501 devices: $U_{dmax} = 900$ V, ACU 601 devices: $U_{dmax} = 1200$ V



In the KP500 control unit, parameter numbers > 999 are shown in hexadecimal form (999, A00 ... B5 ... C66).



For information on parameters specific to the liquid-cooled devices, see „Operating Instructions Liquid Cooling Supplemental“.

23.1 Actual Value Menu (VAL)

Actual values of machine				
No.	Description	Unit	Display range	Chapter
210	Stator frequency	Hz	0.00 ... 999.99	20.2
211	R.m.s Current	A	0.0 ... I_{max}	20.2
212	Output Voltage	V	0.0 ... U_{FIN}	20.2
213	Active Power	kW	0.0 ... P_{max}	20.2
214	Active Current	A	0.0 ... I_{max}	20.2
215	Isd	A	0.0 ... I_{max}	20.2
216	Isq	A	0.0 ... I_{max}	20.2
217	Encoder 1 Frequency	Hz	0.00 ... 999.99	20.2
218	Encoder 1 Speed	1/min	0 ... 60000	20.2
221	Slip Frequency	Hz	0.0 ... 999.99	20.2
Actual values of frequency inverter				
222	DC-Link Voltage	V	0.0 ... U_{dmax}	20.1
223	Modulation	%	0 ... 100	20.1
Actual values of machine				
224	Torque	Nm	± 9999.9	20.2
225	Rotor Flux	%	0 ... 100	20.2
226	Winding Temperature	deg.C	0 ... 999	20.2
227	Act. Rotor Time Constant	ms	0 ... τ_{max}	20.2
Actual values of frequency inverter				
228	Internal ref. frequency	Hz	0.00 ... f_{max}	20.1
229	Reference percentage	%	± 300.00	20.1
230	Actual percentage value	%	± 300.00	20.1

Actual value memory				
No.	Description	Unit	Display range	Chapter
231	Peak Value Long Term Ixt	%	0.00 ... 100.00	20.3
232	Peak Value Short Term Ixt	%	0.00 ... 100.00	20.3
Actual values of machine				
235	Flux-forming voltage	V	0.0 ... U_{FIN}	20.2
236	Torque-forming voltage	V	0.0 ... U_{FIN}	20.2
238	Flux Value	%	0.0 ... 100.0	20.2
239	Reactive Current	A	0.0 ... I_{max}	20.2
240	Actual Speed	1/min	0 ... 60000	20.2
241	Actual Frequency	Hz	0.0 ... 999.99	20.2
Actual values of the system				
242	Actual Value System	Hz	0.0 ... 999.99	20.4.1
Actual values of frequency inverter				
243	Digital Inputs (Hardware)	-	00 ... 255	20.1
244	Working Hours Counter	h	99999	20.1
245	Operation Hours Counter	h	99999	20.1
249	Active Data Set	-	1 ... 4	20.1
250	Digital Inputs	-	00 ... 255	20.1
251	Analog Input MFI1A	%	± 100.00	20.1
252	Repetition frequency input	Hz	0.0 ... 999.99	20.1
254	Digital Outputs	-	00 ... 255	20.1
255	Heat Sink Temperature	deg.C	0 ... T_{kmax}	20.1
256	Inside Temperature	deg.C	0 ... T_{imax}	20.1
257	Analog Output MFO1A	V	0.0 ... 24.0	20.1
258	PWM input	%	0.00 ... 100.00	20.1
259	Current Error	-	FXXXX	20.1
269	Warnings	-	AXXXX	20.1
273	Application Warnings	-	AXXXX	20.1
275	Controller Status	-	CXXXX	20.1
277	STO Status	-	XXXX	20.1
278	Frequency MFO1F	Hz	0.00 ... f_{max}	20.1
Actual values of the system				
285	Volumetric Flow	m ³ /h	0 ... 99999	20.4.2
286	Pressure	kPa	0.0 ... 999.9	20.4.2
Actual value memory				
287	Peak Value Vdc	V	0.0 ... U_{dmax}	20.3
288	Average Value Vdc	V	0.0 ... U_{dmax}	20.3
289	Peak value heat sink temp.	deg.C	0 ... T_{kmax}	20.3
290	Average value heat sink temp.	deg.C	0 ... T_{kmax}	20.3
291	Peak Value Inside Temperature	deg.C	0 ... T_{imax}	20.3
292	Average Value Inside Temperature	deg.C	0 ... T_{imax}	20.3
293	Peak Value Irms	A	0.0 ... $0 \cdot I_{FIN}$	20.3
294	Average Value Irms	A	0.0 ... $0 \cdot I_{FIN}$	20.3
295	Peak Value Active Power pos.	kW	0.0 ... $0 \cdot P_{FIN}$	20.3
296	Peak value active power neg.	kW	0.0 ... $0 \cdot P_{FIN}$	20.3
297	Average value active power	kW	0.0 ... $0 \cdot P_{FIN}$	20.3
301	Energy, positive	kWh	0 ... 99999	20.3
302	Energy, negative	kWh	0 ... 99999	20.3

List of errors

No.	Description	Unit	Display range	Chapter
310	Last Error	h:m; F	00000:00; FXXXX	21.1
311	Last Error but one	h:m; F	00000:00; FXXXX	21.1
312	Error 3	h:m; F	00000:00; FXXXX	21.1
313	Error 4	h:m; F	00000:00; FXXXX	21.1
314	Error 5	h:m; F	00000:00; FXXXX	21.1
315	Error 6	h:m; F	00000:00; FXXXX	21.1
316	Error 7	h:m; F	00000:00; FXXXX	21.1
317	Error 8	h:m; F	00000:00; FXXXX	21.1
318	Error 9	h:m; F	00000:00; FXXXX	21.1
319	Error 10	h:m; F	00000:00; FXXXX	21.1
320	Error 11	h:m; F	00000:00; FXXXX	21.1

List of errors

321	Error 12	h:m; F	00000:00; FXXXX	21.1
322	Error 13	h:m; F	00000:00; FXXXX	21.1
323	Error 14	h:m; F	00000:00; FXXXX	21.1
324	Error 15	h:m; F	00000:00; FXXXX	21.1
325	Error 16	h:m; F	00000:00; FXXXX	21.1






















Error environment


















	330	DC-Link Voltage	V	0.0 ... U_{dmax}	21.2
	331	Output voltage	V	0.0 ... U_{FIN}	21.2
	332	Stator frequency	Hz	0.00 ... 999.99	21.2
	333	Frequency Speed Sensor 1	Hz	0.00 ... 999.99	21.2
	335	Phase Current Ia	A	0.0 ... I_{max}	21.2
	336	Phase Current Ib	A	0.0 ... I_{max}	21.2
	337	Phase Current Ic	A	0.0 ... I_{max}	21.2
	338	R.m.s Current	A	0.0 ... I_{max}	21.2
	339	Isd / Reactive Current	A	0.0 ... I_{max}	21.2
	340	Isq / Active Current	A	0.0 ... I_{max}	21.2
	341	Rotor Magnetizing Current	A	0.0 ... I_{max}	21.2
	342	Torque	Nm	± 9999.9	21.2
	343	Analog Input MFI1A	%	± 100.00	21.2
	346	Analog Output MFO1A	V	0.0 ... 24.0	21.2
	349	Repetition Frequency Output	Hz	0.00 ... 999.99	21.2
	350	Status of Digital Inputs	-	00 ... 255	22.2
	351	Status of Digital Outputs	-	00 ... 255	22.2
	352	Time since Release	h:m:s.ms	00000:00:00.000	21.2
	353	Heat Sink Temperature	deg.C	0 ... T_{kmax}	21.2
	354	Inside Temperature	deg.C	0 ... T_{imax}	21.2
	355	Controller Status	-	C0000 ... CFFFF	22.3
	356	Warning Status	-	A0000 ... AFFFF	22.4
	357	Int. Value 1	-	± 32768	21.2
	358	Int. Value 2	-	± 32768	21.2
	359	Long Value 1	-	± 2147483647	21.2
	360	Long Value 2	-	± 2147483647	21.2
	361	Checksum	-	OK / NOK	21.2






















List of errors				
No.	Description	Unit	Display range	Chapter
362	No. of errors	-	0 ... 32767	21.1
363	No. of self acknowledged Errors	-	0 ... 32767	21.1
Error environment				
367	Application Warning Status	-	A0000 ... AFFFF	22.4
Positioning				
470	Rotations	U	0.000 ... 1·10 ⁶	13.6
Digital Outputs				
537	Actual Warning Mask	-	AXXXXXXXX	16.3.8
627	Actual Appl. Warning Mask	-	AXXXX	16.3.9
Auto set-up				
797	SET-UP Status	-	OK / NOK	9.5
















23.2 Parameter Menu (PARA)


































Inverter data				
No.	Description	Unit	Setting range	Chapter
0	Serial Number	-	Characters	10.1
1	Optional Modules	-	Characters	10.2
12	Inverter Software Version	-	Characters	10.3
15	Copyright	-	Characters	10.3
27	Set Password	-	0 ... 999	10.4
28	Control Level	-	1 ... 3	10.5
29	User Name	-	32 characters	10.6
30	Configuration	-	Selection	10.7
33	Language	-	Selection	10.8
34	Program	-	0 ... 9999	10.9
37	Release axis positioning	-	Selection	13.6.2
Fan				
39	Switch-On Temperature	deg.C	0 ... 60	19.2
Traverse function				
48	Reference frequency	-	Selection	19.8
Digital Inputs				
49	Handshake Traverse Function	-	Selection	16.4.10
58	Technology Controller Release	-	Selection	18.3
62	Frequency motorpoti up	-	Selection	16.4.9
63	Frequency motorpoti down	-	Selection	16.4.9
66	Fixed frequency change-over 1	-	Selection	16.4.8
67	Fixed frequency change-over 2	-	Selection	16.4.8
68	Start clockwise	-	Selection	16.4.1
69	Start anticlockwise	-	Selection	16.4.1
70	Data Set Change-Over 1	-	Selection	16.4.7
71	Data Set Change-Over 2	-	Selection	16.4.7
72	Percent Motorpoti Up	-	Selection	16.4.9
73	Percent Motorpoti Down	-	Selection	16.4.9
75	Fixed Percent Change-Over 1	-	Selection	16.4.8
76	Fixed Percent Change-Over 2	-	Selection	16.4.8


























Digital Inputs				
No.	Description	Unit	Setting range	Chapter
83	Timer 1	-	Selection	16.4.4
84	Timer 2	-	Selection	16.4.4
87	Start 3-Wire Ctrl	-	Selection	16.4.2
103	Error Acknowledgment	-	Selection	16.4.3
164	n-/M control change-over	-	Selection	16.4.6
183	External Error	-	Selection	16.4.12
Digital Inputs				
204	Therm. Contact	-	Selection	16.4.5
Actual value memory				
237	Reset memory	-	Selection	20.3
Guided commissioning				
369	Motor Type	-	Selection	9.2.3
Rated motor parameters				
 370	Rated Voltage	V	$0.17 \cdot U_{FIN} \dots 2 \cdot U_{FIN}$	11.1
 371	Rated Current	A	$0.01 \cdot I_{FIN} \dots 10 \cdot I_{FIN}$	11.1
 372	Rated Speed	RPM	96 ... 60000	11.1
  373	No. of pole pairs	-	1 ... 24	11.1
 374	Rated Cosinus Phi	-	0.01 ... 1.00	11.1
 375	Rated Frequency	Hz	10.00 ... 599.00	11.1
 376	Rated Mech. Power	kW	$0.1 \cdot P_{FIN} \dots 10 \cdot P_{FIN}$	11.1
Further motor parameters				
  377	Stator resistance	mOhm	0 ... 65535	11.2.1
  378	Leakage coefficient	%	1.0 ... 20.0	11.2.2
383	Voltage Constant	mVmin	0.0 ... 850.0	11.2.5
384	Stator Inductance	mH	0.1 ... 500.0	11.2.6
System data				
389	Factor Actual Value System	-	-100.000 ... 100.000	12.1
 397	Nominal Volumetric Flow	m3/h	1 ... 99999	12.2
 398	Nominal pressure	kPa	0.1 ... 999.9	12.2
Pulse width modulation				
400	Switching frequency	-	Selection	19.1
401	Min. Switching Frequency	-	Selection	19.1
Error/warning behavior				
405	Warning Limit Short Term Ixt	%	6 ... 100	14.1
406	Warning Limit Long Term Ixt	%	6 ... 100	14.1
407	Warning Limit Heat Sink Temp.	deg.C	-25 ... 0	14.2
408	Warning Limit Inside Temp.	deg.C	-25 ... 0	14.2
409	Controller-Status Message	-	Selection	14.3
Bus controller				
 412	Local/Remote	-	Selection	19.3
Error/warning behavior				
415	IDC Compensation Limit	V	0.0 ... 1.5	14.4
417	Frequency Switch-off Limit	Hz	0.00 ... 599.00	14.5
Frequency Limits				
   418	Minimum frequency	Hz	0.00 ... 599.00	15.1
   419	Maximum frequency	Hz	0.00 ... 599.00	15.1




































Frequency ramps				
No.	Description	Unit	Setting range	Chapter
 420	Acceleration (Clockwise)	Hz/s	0.00 ... 9999.99	15.7
 421	Deceleration (Clockwise)	Hz/s	0.01 ... 9999.99	15.7
 422	Acceleration Anticlockwise	Hz/s	-0.01 ... 9999.99	15.7
 423	Deceleration anticlockwise	Hz/s	-0.01 ... 9999.99	15.7
 424	Emergency stop clockwise	Hz/s	0.01 ... 9999.99	15.7
 425	Emergency stop anti-clockwise	Hz/s	0.01 ... 9999.99	15.7
 426	Maximum leading	Hz	0.01 ... 599.00	15.7
 430	Ramp rise time clockwise	ms	0 ... 65000	15.7
 431	Ramp fall time clockwise	ms	0 ... 65000	15.7
 432	Ramp Rise Time Anticlockwise	ms	0 ... 65000	15.7
 433	Ramp Fall Time Anticlockwise	ms	0 ... 65000	15.7
Traverse function				
 435	Operation mode	-	Selection	19.8
 436	Acceleration Time	s	0.01 ... 320.00	19.8
 437	Deceleration Time	s	0.01 ... 320.00	19.8
 438	Traverse Amplitude	%	0.01 ... 50.00	19.8
 439	Proportional Step	%	0.01 ... 50.00	19.8
Technology controller				
 440	Operation mode	-	Selection	18.3
 441	Fixed frequency	Hz	-599.00 ... 599.00	18.3
 442	max. P component	Hz	0.01 ... 599.00	18.3
 443	Hysteresis	%	0.01 ... 100.00	18.3
 444	Amplification	-	-15.00 ... 15.00	18.3
 445	Integral Time	ms	0 ... 32767	18.3
 446	Ind. volume flow control factor	-	0.10 ... 2.00	18.3
Blocking frequencies				
 447	1st Blocking Frequency	Hz	0.00 ... 599.00	15.9
 448	2nd Blocking Frequency	Hz	0.00 ... 599.00	15.9
 449	Frequency hysteresis	Hz	0.00 ... 100.00	15.9
Multifunction input 1				
 450	Tolerance Band	%	0.00 ... 25.00	16.1.1.3
 451	Filter time constant	ms	Selection	16.1.1.4
 452	Operation mode	-	Selection	16.1
 453	Error/Warning Behavior	-	Selection	16.1.1.5
 454	Point X1	%	0.00 ... 100.00	16.1.1.1
 455	Point Y1	%	-100.00 ... 100.00	16.1.1.1
 456	Point X2	%	0.00 ... 100.00	16.1.1.1
 457	Point Y2	%	-100.00 ... 100.00	16.1.1.1
Positioning				
 458	Operation mode	-	Selection	13.6
 459	Signal source	-	Selection	13.6.1
 460	Positioning distance	U	0.000 ... 1 10 ⁶	13.6.1
 461	Signal correction	ms	-327.68 ... 327.67	13.6.1
 462	Load correction	-	-32768 ... 32767	13.6.1
 463	Activity after positioning	-	Selection	13.6.1
 464	Time to wait	ms	0 ... 3.6 10 ⁶	13.6.1













Temperature Adjustment				
No.	Description	Unit	Setting range	Chapter
 465	Operation mode	-	Selection	19.7.2
 466	Temperature coefficient	%/100	0.00 ... 300.00	19.7.2
 467	Adjusting temperature	deg.C	-50.0 ... 300.0	19.7.2
Positioning				
 469	Reference orientation	°	0.0 ... 359.9	13.6.2
 471	Positioning Frequency	Hz	1.00 ... 50.00	13.6.2
 472	Max positional error	°	0.1 ... 90.0	13.6.2
Motor potentiometer				
473	Ramp Keypad Motorpoti	Hz/s	0.01 ... 999.99	15.10.3
474	Operation mode	-	Selection	15.10
Reference Frequency Channel				
 475	Reference frequency source	-	Selection	15.4
Reference percentage channel				
 476	Reference Percentage Source	-	Selection	15.5
Percentage ramp				
 477	Gradient Percentage Ramp	%/s	0 ... 60000	15.8
Technology controller				
 478	Actual percentage source	-	Selection	18.3
Positioning				
 479	time constant positioning contr.	ms	1.00 ... 9999.99	13.6.2
Fixed frequencies				
 480	Fixed Frequency 1	Hz	-599.00 ... 599.00	15.6.1
 481	Fixed Frequency 2	Hz	-599.00 ... 599.00	15.6.1
 482	Fixed Frequency 3	Hz	-599.00 ... 599.00	15.6.1
 483	Fixed Frequency 4	Hz	-599.00 ... 599.00	15.6.1
489	JOG frequency	Hz	-599.00 ... 599.00	15.6.2
Speed Sensor 1				
 490	Operation mode	-	Selection	11.4.1
 491	Division Marks	-	1 ... 8192	11.4.2
PWM-/repetition frequency input				
 496	Operation mode	-	Selection	15.11
 497	Divider	-	1 ... 8192	15.11
Brake Chopper				
506	Trigger Threshold	V	225 ... 1000 (201) 425 ... 1000 (401) 925 ... 1050 (501) 1225 ... 1400 (601)	19.4
Motor chopper				
 507	Trigger Threshold	V	225 ... 1000 (201) 425 ... 1000 (401) 925 ... 1050 (501) 1225 ... 1400 (601)	19.7.1
Digital Outputs				
 510	Setting Frequency	Hz	0.00 ... 599.00	16.3.2
Speed Sensor 1				
511	EC1 Gear Factor Numerator	-	-300.00 ... 300.00	11.4.3
512	EC1 Gear Factor Denominator	-	0.01 ... 300.00	11.4.3

Speed controller				
No.	Description	Unit	Setting range	Chapter
515	Integral Time Speedtracking	ms	1 ... 60 000	18.5.4.3
Digital Outputs				
	517 Setting Frequency Off Delta	Hz	0.00 ... 599.00	16.3.2
Percentage Value Limits				
	518 Minimum Reference Percentage	%	0.00 ... 300.00	15.3
	519 Maximum Reference Percentage	%	0.00 ... 300.00	15.3
Fixed percentages				
	520 Fixed Percentage 1	%	-300.00 ... 300.00	15.6.3
	521 Fixed Percentage 2	%	-300.00 ... 300.00	15.6.3
	522 Fixed Percentage 3	%	-300.00 ... 300.00	15.6.3
	523 Fixed Percentage 4	%	-300.00 ... 300.00	15.6.3
Digital Outputs				
	530 Op. Mode Digital Output 1	-	Selection	16.3
	532 Op. Mode Digital Output 3	-	Selection	16.3
	535 Op. Mode ext. Error	-	Selection	16.4.12
	536 Create warning mask	-	Selection	16.3.8
	540 Op. Mode Comparator 1	-	Selection	16.5.2
	541 Comparator On above	%	-300.00 ... 300.00	16.5.2
Digital Outputs				
	542 Comparator Off below	%	-300.00 ... 300.00	16.5.2
	543 Op. Mode Comparator 2	-	Selection	16.5.2
	544 Comparator On above	%	-300.00 ... 300.00	16.5.2
	545 Comparator Off below	%	-300.00 ... 300.00	16.5.2
	549 Max. Control Deviation	%	0.01 ... 20.00	16.3.3
Multifunction output 1				
	550 Operation mode	-	Selection	16.2.2
	551 Voltage 100%	V	0.0 ... 22.0	16.2.1.1
	552 Voltage 0%	V	0.0 ... 24.0	16.2.1.1
	553 Analog Operation	-	Selection	16.2.1
	554 Digital Operation	-	Selection	16.3
Multifunction output 1				
	555 Repetition frequency operation	-	Selection	16.2.2
	556 Division Marks	-	30 ... 8192	16.2.2.1
Error/warning behavior				
	570 Motor Temp. Operation Mode	-	Selection	14.6
Motor circuit breaker				
	571 Operation mode	-	Selection	19.5
	572 Frequency Limit	%	0 ... 300	19.5
Intelligent current limits				
	573 Operation mode	-	Selection	18.1
	574 Power Limit	%	40.00 ... 95.00	18.1
	575 Limitation Time	min	5 ... 300	18.1
Error/warning behavior				
	576 Phase supervision	-	Selection	14.7
	578 Allowed no. of AutoAck.	-	0 ... 20	14.8
	579 Restart delay	ms	0 ... 1000	14.8

Pulse width modulation				
No.	Description	Unit	Setting range	Chapter
580	Reduction limit Ti/Tk	deg.C	-25 ... 0	19.1
V-belt monitoring				
	581 Operation mode	-	Selection	19.6
	582 Trigger limit Iactive	%	0.1 ... 100.0	19.6
	583 Delay time	s	0.1 ... 600.0	19.6
V/f characteristic				
✓ 	600 Starting voltage	V	0.0 ... 100.0	17
✓ 	601 Voltage rise	%	-100 ... 200	17
✓ 	602 Rise frequency	%	0 ... 100	17
✓ 	603 Cut-off voltage	V	60.0 ... 560.0	17
✓ 	604 Cut-off frequency	Hz	0.00 ... 599.00	17
	605 Dyn. Voltage Pre-Control	%	0 ... 200	17.1
Current limit value controller				
	610 Operation mode	-	Selection	18.4.2
	611 Amplification	-	0.01 ... 30.00	18.4.2
	612 Integral Time	ms	1 ... 10000	18.4.2
	613 Current Limit	A	0.0 ... 0·I _{FIN}	18.4.2
✓ 	614 Frequency Limit	Hz	0.00 ... 599.00	18.4.2
Error/warning behavior				
	617 max.Temp. Windings	°C	0 ... 200	14.6
Technology controller				
	618 Derivative time	ms	0 ... 1000	18.3
Starting behavior				
✓ 	620 Operation mode	-	Selection	13.1.1
	621 Amplification	-	0.01 ... 10.00	13.1.1
	622 Integral Time	ms	1 ... 30000	13.1.1
✓ 	623 Starting current	A	0.0 ... 0·I _{FIN}	13.1.1.1
✓ 	624 Frequency Limit	Hz	0.00 ... 100.00	13.1.1.2
	625 Brake Release Time	ms	-5000 ... 5000	13.1.1.3
Application Warnings				
	626 Create warning mask application	-	Selection	16.3.9
Stopping behavior				
	630 Operation mode	-	Selection	13.2
Direct current brake				
✓ 	631 Braking current	A	0.00 ... $\sqrt{2} \cdot I_{FIN}$	13.3
	632 Braking time	s	0.0 ... 200.0	13.3
✓ 	633 Demagnetizing time	s	0.1 ... 30.0	13.3
	634 Amplification	-	0.00 ... 10.00	13.3
	635 Integral Time	ms	0 ... 1000	13.3
Stopping behavior				
	637 Switch-Off Threshold	%	0.0 ... 100.0	13.2.1
	638 Holding time	s	0.0 ... 200.0	13.2.2
Search run				
	645 Operation mode	-	Selection	13.5
	646 Brak. time after search run	s	0.0 ... 200.0	13.5
	647 Current / Rated Motor Current	%	1.00 ... 100.00	13.5
	648 Amplification	-	0.00 ... 10.00	13.5
	649 Integral Time	ms	0 ... 1000	13.5

Auto start				
No.	Description	Unit	Setting range	Chapter
651	Operation mode	-	Selection	13.4
PWM-/repetition frequency input				
652	Offset	%	-100.00 ... 100.00	15.11
653	Amplification	%	5.0 ... 1000.0	15.11
Slip compensation				
✓ 	660 Operation mode	-	Selection	18.4.1
	661 Amplification	%	0.0 ... 300.0	18.4.1
	662 Max. slip ramp	Hz/s	0.01 ... 650.00	18.4.1
	663 Minimum frequency	Hz	0.01 ... 599.00	18.4.1
Voltage controller				
	670 Operation mode	-	Selection	18.2
	671 Mains failure threshold	V	-200.0 ... -50.0	18.2
	672 Reference mains support value	V	-200.0 ... -10.0	18.2
	673 Mains support deceleration	Hz/s	0.01 ... 9999.99	18.2
	674 Acceleration on mains resumption	Hz/s	0.00 ... 9999.99	18.2
	675 Shutdown threshold	Hz	0.00 ... 599.00	18.2
	676 Reference shutdown value	V	225.0 ... 387.5 (201) 425.0 ... 770.0 (401) 550.0 ... 875.0 (501) 725.0 ... 1175.0 (601)	18.2
	677 Amplification	-	0.00 ... 30.00	18.2
	678 Integral Time	ms	0 ... 10000	18.2
	680 Reference DC link limitation	V	225.0 ... 387.5 (201) 425.0 ... 770.0 (401) 550.0 ... 875.0 (501) 725.0 ... 1175.0 (601)	18.2
	681 max. frequency rise	Hz	0.00 ... 599.00	18.2
	683 Gen. Ref. Current Limit	A	0.0 ... 0·I _{FIN}	18.2
Current controller				
✓ 	700 Amplification	-	0.00 ... 8.00	18.5.1
✓ 	701 Integral Time	ms	0.00 ... 10.00	18.5.1
Further motor parameters				
✓ 	713 Magnetizing current 50% flux	%	1 ... 50	11.2.3
✓ 	714 Magnetizing current 80% flux	%	1 ... 80	11.2.3
✓ 	715 Magnetizing current 110% flux	%	110 ... 197	11.2.3
✓ 	716 Rated magnetizing current	A	0.01·I _{FIN} ... 0·I _{FIN}	11.2.3
Field controller				
✓ 	717 Reference Flux	%	0.01 ... 300.00	18.5.6
Further motor parameters				
✓ 	718 Rated slip correction factor	%	0.01 ... 300.00	11.2.4
Frequency Limits				
	719 Slip Frequency	%	0 ... 10000	15.2
Speed controller				
	720 Operation mode	-	Selection	18.5.4
✓ 	721 Amplification 1	-	0.00 ... 200.00	18.5.4
	722 Integral Time 1	ms	0 ... 60000	18.5.4
✓ 	723 Amplification 2	-	0.00 ... 200.00	18.5.4
	724 Integral Time 2	ms	0 ... 60000	18.5.4

Acceleration pre-control				
No.	Description	Unit	Setting range	Chapter
 725	Operation mode	-	Selection	18.5.5
 726	Minimum acceleration	Hz/s	0.1 ... 6500.0	18.5.5
 727	Mech. Time Constant	ms	1 ... 60000	18.5.5
Speed controller				
 728	Current Limit	A	0.0 ... 0·I _{FIN}	18.5.4.1
 729	Current Limit Generator Op.	A	-0.1 ... 0·I _{FIN}	18.5.4.1
 730	Torque Limit	%	0.00 ... 650.00	18.5.4.1
 731	Torque limit generator operation	%	0.00 ... 650.00	18.5.4.1
 732	P-Comp. Torque Upper Limit	%	0.00 ... 650.00	18.5.4.1
 733	P-Comp. Torque Lower Limit	%	0.00 ... 650.00	18.5.4.1
Speed controller				
 734	Isq limit source motor operation	-	Selection	18.5.4.2
 735	Isq limit source gen. operation	-	Selection	18.5.4.2
 736	Torque limit source motor operation	-	Selection	18.5.4.2
 737	Torque limit source gen. operation	-	Selection	18.5.4.2
✓  738	Speed Control Switch-Over Limit	Hz	0.00 ... 599.00	18.5.4
 739	Power Limit	kW	0.00 ... 2·0·P _{FIN}	18.5.4.1
 740	Power Limit Generator Operation	kW	0.00 ... 2·0·P _{FIN}	18.5.4.1
Field controller				
 741	Amplification	-	0.0 ... 100.0	18.5.6
✓  742	Integral Time	ms	0.0 ... 1000.0	18.5.6
✓  743	Ref. Isd upper limit	A	0 ... 0·I _{FIN}	0
✓  744	Ref. Isd lower limit	A	-I _{FIN} ... I _{FIN}	0
Speed controller				
 748	Backlash damping	%	0 ... 300	18.5.4
Modulation controller				
 750	Reference modulator	%	3.00 ... 105.00	18.5.7
 752	Integral Time	ms	0.0 ... 1000.00	18.5.7
Modulation controller				
 753	Operation mode	-	Selection	18.5.7
Speed controller				
 754	Filter time constant	ms	0...128	18.5.4
Modulation controller				
 755	Reference Imr Lower Limit	A	0.01·I _{FIN} ... 0·I _{FIN}	0
 756	Control Deviation Limitation	%	0.00 ... 100.00	0
Current controller				
✓  757	Current below P. 700 is in effect	A	0.00· ... 0·I _{FIN}	18.5.2
✓  758	Current above P. 759 is in effect	A	0.00· ... 0·I _{FIN}	18.5.2
✓  759	Amplification high Current	-	0.00 ... 8.00	18.5.2
Speed sensor monitoring				
 760	Operation mode	-	Selection	19.7.3
 761	Timeout: Signal fault	ms	0 ... 65000	19.7.3
 762	Timeout: Track fault	ms	0 ... 65000	19.7.3
 763	Timeout: Direction fault	ms	0 ... 65000	19.7.3
Speed controller				
 766	Act. Speed Source	-	Selection	18.5.4

Torque controller				
No.	Description	Unit	Setting range	Chapter
 767	Frequency upper limit	Hz	-599.00 ... 599.00	18.5.2
 768	Frequency lower limit	Hz	-599.00 ... 599.00	18.5.2
 769	Frequency upper limit source	-	Selection	18.5.3.3
 770	Frequency lower limit source	-	Selection	18.5.3.3
Current controller				
<input checked="" type="checkbox"/>  775	Current above P. 700 is in effect	A	0.00 ... $0 \cdot I_{FIN}$	18.5.2
<input checked="" type="checkbox"/>  776	Current below P. 777 is in effect	A	0.00 ... $0 \cdot I_{FIN}$	18.5.2
<input checked="" type="checkbox"/>  777	Amplification low Current	-	0.00 ... 8.00	18.5.2
Field controller				
778	Reduction Factor Flux	%	20 ... 100	18.5.6
Starting behavior				
779	Minimum flux formation time	ms	1 ... 10000	13.1.2
<input checked="" type="checkbox"/>  780	Max. Flux-Formation Time	ms	1 ... 10000	13.1.2
<input checked="" type="checkbox"/>  781	Current during flux formation	A	$0.1 \cdot I_{FIN}$... $0 \cdot I_{FIN}$	13.1.2
Timer				
790	Operation Mode Timer 1	-	Selection	16.5.1
791	Time 1 Timer 1	s/m/h	0 ... 650.00	16.5.1.1
792	Time 2 Timer 1	s/m/h	0 ... 650.00	16.5.1.1
793	Operation Mode Timer 2	-	Selection	16.5.1
794	Time 1 Timer 2	s/m/h	0 ... 650.00	16.5.1
795	Time 2 Timer 2	s/m/h	0 ... 650.00	16.5.1
Auto set-up				
796	SET-UP Select	-	Selection	9.5
Further motor parameters				
 1190	Stator resistance	Ohm	0.001 ... 100.000	11.2.1
 1192	Peak current	A	$0.01\% I_{FIN}$... $100\,000\% 0 I_{FIN}$	11.2.7
Encoder 1 Filter time constant				
1193	EC1: Filter time constant	us	0...32000	11.4.4
Further motor parameters				
<input checked="" type="checkbox"/>  1199	Reverse sense of rotation	-	Selection	11.2.8
Mux/DeMux				
1250	Mux input index (write)	-	EEPROM: 0 ... 16 RAM: 17 ... 33	16.5.4
1251	Mux input index (read)	-	EEPROM: 0 ... 16 RAM: 17 ... 33	16.5.4
1252	Mux inputs	-	Selection	16.5.4
1253	DeMux Input	-	Selection	16.5.4
User Warning				
1363	User Warnig 1	-	Selection	16.4.11
1364	User Warnig 2	-	Selection	16.4.11
Profibus/Internal Notation converter				
1370	In-F-PDP-word 1		Selection	19.9
1371	In-F-PDP-word 2		Selection	19.9
1372	In-F-intern long 1		Selection	19.9
1373	In-F-intern long 2		Selection	19.9
1374	In-F-Convert Reference	Hz	0.01...599.00	19.9



In the KP500 control unit, parameter numbers > 999 are shown in hexadecimal form (999, A00 ... B5 ... C66).

Index

A

Acceleration pre-control	230
Acknowledging error messages	
automatic	151
with logic signal	193
Actual value memory	254
Actual value system	131
Actual values	
of frequency inverter	251
of machine	253
of system	255
Auto set-up	112

B

Blocking frequencies	163
Brake chopper	236
Brake release	182
Brake release time	134
Brake resistor	
dimensioning	237
Braking resistor	
connection	62
Bus controller	235

C

Cable length	61
CE conformity	32
Check direction of rotation	110
Commissioning	99
Communication module	57
Comparator	198
Conductor cross-section	58
Configurations	
Overview	77, 100, 116
wiring diagrams	76
Control functions	204
Mains failure regulation	208
Power failure regulation	208
Control Level	115
Control terminals	73
Technical data	33
Control unit	57, 87
Controlling the motor	97
displays	87
Function of buttons	87
Menu	88
Copying parameter values	91
Error messages	93
Copyright	14
Current controller	223
Advanced	224
Current limit value controller	222
Current limitation	182

D

Decommissioning	22
Designated use	15
Diagnosis	263
Digital inputs	

control terminals	73
Logic signal	187
Technical data	34, 56

Digital outputs

control terminals	74
Technical data	34, 56

Direct current brake

Drehgeber

Strichzahl	128
------------------	-----

E

Electrical connections	20
EMC	54
Error environment	261
Error messages	257
of auto-setup	108
Extension module EM	57
External fan	182
External power supply	75

F

Fan	235
Field controller	231
Filter time constant	171
Filter time constant, Speed Sensor 1	129
Fixed frequency change-over	194
Flow rate control	131
Flux formation	134
Flux forming finished	182
Font style	18
Frequency Limit	134
Frequency ramps	160

G

General Information about the Documentation	11
Group drive	61

H

Hysteresis	
of analog input signal	170

I

Installation	20
Electrical	52, 63
Mechanical	46
Intelligent current limits	204
Inverter data	115

J

JOG function	98, 159
--------------------	---------


L

Limit value sources	226
Liquid Level control	217, 218
List of errors	257
List of parameters	267

M

Machine data	103, 121
Mains connection	63
Master drive	247
Mechanical installation	46
Modulation controller	232

Monitoring		Setpoint	
Analog input signal.....	172	Fixed setpoint	159
Controller intervention.....	149	Setting Frequency.....	179
DC component	149	SF Auto-setup error messages	108
Heat Sink Temperature.....	148	Slip compensation.....	221
Load behavior	244	Speed controller	226
Motor temperature	150, 238	Switch-over speed/torque control	193
output frequency	150	Speed sensor	111
Overload	148	Connection.....	61, 81, 82
Phase failure.....	151	evaluation	126, 130
warning mask	183	gear factor	128
Motor chopper.....	245	Monitoring	247
Motor circuit breaker	238	SS self-setup status messages	106
Motor connection	60, 63	Start clockwise	192
Motor potentiometer.....	98, 164, 194	Starting behavior	132
Motor protection		Starting current	133
Motor protection by I2t monitoring.....	242	Stopping behavior.....	136
Multifunction input.....	168	Switch data set.....	102, 193
Multifunction output	173	Switch-off threshold stop.....	138
Multiplexer	200	T	
P		Table of functions	200
Parameter identification	105	Technical data	32
Percentage Value Ramps	162	Technology controller.....	212
Plausibility check	104	Temperature Adjustment.....	246
Positioning	142	Therm. Contact.....	76, 193
Axle positioning	145	Three-wire control	192
from reference point	142	Timer	193, 195
Pressure control	216	Torque controller	224
Pulse width modulation.....	234	Torque preset.....	225
PWM input	166	Traverse function.....	247
R		Traverse Function	
Ramp time	161	Handshake.....	195
Reference percentage channel	156	U	
Reference value		UL Approval.....	32
Fixed frequency	159	User Name	115
Fixed percentage	160	User Warning	195
reached.....	180	V	
Reference Value	152	V/f characteristic mode	202
Relay output	75	Voltage controller	206
Technical data	34	Voltage input.....	75
Reset.....	96	Volumetric Flow Control	256
S		W	
SA Auto-setup warning messages.....	106	Warning mask, application	186
Safety		Warning messages	
General	15	of auto-setup	106
Safety function.....	23	Warning Status.....	265
Status of inputs.....	253	Warranty and liability	13
Sense of rotation		X	
reverse.....	125	X10.....	75
via fixed setpoints	159	X210A	73
Service	22	X210B	74



Configuration 30

n/M change-over	Technology controller	Speed controlled
230 430 530 630	111 211 411 611	110 210 410 510 610
STOA/error acknowledgment ¹⁾	STOA/error acknowledgment ¹⁾	STOA/error acknowledgment ¹⁾
Start Clockwise	Fixed Percent Change-Over 1	Start Clockwise
n/M change-over	no function	Start Anticlockwise
Data set change-over 1 ²⁾	Fixed percentage change-over 2	Data set change-over 1 ²⁾
430	211	Speed sensor track B
530	411	Speed sensor track A
630	611	Motor therm. contact
Data set change-over 2	Data set change-over 2	Motor therm. contact
230	211	STOB/error acknowledgment ¹⁾
STOB/error acknowledgment ¹⁾	STOB/error acknowledgment ¹⁾	STOB/error acknowledgment ¹⁾
Run Signal	Run Signal	Run Signal
Actual frequency	Actual frequency	Actual frequency
Reference speed (n) or Reference percentage (M)	Actual percentage value	Reference Speed



Error signal, inverted	Error signal, inverted	Error signal, inverted	A

STATUS ... S/INL: Digital inputs, S/OUT: Digital output, MHT: Multitunction output (default output), MHT: Multitunction input (default setting:

analog voltage input), S3OUT: Relay output, \longleftrightarrow bidirectional, \longleftrightarrow input (E), \longleftrightarrow output (A)

- 1) Error acknowledgment via STOA or STOB,

²⁾linked to Timer 1 (Data Set Change-Over 1 **70** = „**158** – **Timer 1**“ **83** = „73 – S4IND“, default setting *Time 1 Timer 1* **791** = 0.00

c/m/h)

Bonfiglioli worldwide network

Bonfiglioli Australia

2, Cox Place Glendenning NSW 2761
Locked Bag 1000 Plumpton NSW 2761
Tel. (+ 61) 2 8811 8000 - Fax (+ 61) 2 9675 6605
www.bonfiglioli.com.au

Bonfiglioli Brasil

Travessa Cláudio Armando 171
Bloco 3 - CEP 09861-730 - Bairro Assunção
São Bernardo do Campo - São Paulo
Tel. (+55) 11 4344 2323 - Fax (+55) 11 4344 2322
www.bonfigliolidobrasil.com.br

Bonfiglioli Canada

2-7941 Jane Street - Concord, Ontario L4K 4L6
Tel. (+1) 905 7384466 - Fax (+1) 905 7389833
www.bonfigliolicanada.com

Bonfiglioli China

Unit D, 8th Floor, Building D, BenQ Plaza, No.207
Songhong Road, Shanghai 200335
Tel. (+86) 21 60391118 - Fax (+86) 59702957
www.bonfiglioli.cn

Bonfiglioli Deutschland

Industrial, Mobile, Wind
Sperberweg 12 - 41468 Neuss
Tel. +49 (0) 2131 2988 0 - Fax +49 (0) 2131 2988 100
www.bonfiglioli.de

Industrial, Photovoltaic
Europark Fichtenhain B6 - 47807 Krefeld
Tel. +49 (0) 2151 8396 0 - Fax +49 (0) 2151 8396 999
www.vectron.net

Bonfiglioli España

Industrial, Mobile, Wind
Tecnotrans Bonfiglioli S.A.
Pol. Ind. Zona Franca sector C, calle F, n°6
08040 Barcelona
Tel. (+34) 93 4478400 - Fax (+34) 93 3360402
www.tecnotrans.com
Photovoltaic
Bonfiglioli Renewable Power Conversion Spain, SL
Ribera del Loira, 46 - Edificio 2 - 28042 Madrid
Tel. (+34) 91 5030125 - Fax (+34) 91 5030099
www.tecnotrans.com

Bonfiglioli France

14 Rue Eugène Pottier
Zone Industrielle de Moimont II - 95670 Marly la Ville
Tel. (+33) 1 34474510 - Fax (+33) 1 34688800
www.bonfiglioli.fr

Bonfiglioli India

Industrial
Bonfiglioli Transmission PVT Ltd.
Survey No. 528, Perambakkam High Road
Mannur Village - Sriperumbudur Taluk 602105
www.bonfiglioli.in
Mobile, Wind
Bonfiglioli Transmission PVT Ltd.
PLOT AC7-AC11 Sidco Industrial Estate
Thirumudivakkam - Chennai 600 044
Tel. +91(0) 44 24781035 - 24781036 - 24781037
Fax +91(0) 44 24780091 - 24781904
www.bonfiglioli.in
Photovoltaic
Bonfiglioli Renewable Power Conversion India (P) Ltd
No. 543, 14th Cross, 4th Phase,
Peenya Industrial Area, Bangalore - 560 058
Tel. +91 80 2836 1014/15 - Fax +91 80 2836 1016
www.bonfiglioli.in

Bonfiglioli Italia

Industrial, Photovoltaic
Via Sandro Pertini lotto 7b - 20080 Carpiano (Milano)
Tel. (+39) 02 985081 - Fax (+39) 02 985085817
www.bonfiglioli.it
Bonfiglioli Mechatronic Research
Via F. Zeni 8 - 38068 Rovereto (Trento)
Tel. (+39) 0464 443435/36 - Fax (+39) 0464 443439
www.bonfiglioli.it

Bonfiglioli New Zealand

88 Hastie Avenue, Mangere Bridge, Auckland
2022, New Zealand - PO Box 11795, Ellerslie
Tel. (+64) 09 634 6441 - Fax (+64) 09 634 6445
www.bonfiglioli.co.nz

Bonfiglioli Österreich

Molkereistr 4 - A-2700 Wiener Neustadt
Tel. (+43) 02622 22400 - Fax (+43) 02622 22386
www.bonfiglioli.at

Bonfiglioli South East Asia

24 Pioneer Crescent #02-08
West Park Bizcentral - Singapore, 628557
Tel. (+65) 6268 9869 - Fax. (+65) 6268 9179
www.bonfiglioli.com

Bonfiglioli South Africa

55 Galaxy Avenue,
Linbro Business Park - Sandton
Tel. (+27) 11 608 2030 OR - Fax (+27) 11 608 2631
www.bonfiglioli.co.za

Bonfiglioli Türkiye

Atatürk Organize Sanayi Bölgesi,
10044 Sk. No. 9, 35620 Çiğli - İzmir
Tel. +90 (0) 232 328 22 77 (pbx)
Fax +90 (0) 232 328 04 14
www.bonfiglioli.com.tr

Bonfiglioli United Kingdom

Industrial, Photovoltaic
Unit 7, Colemeadow Road
North Moons Moat - Redditch,
Worcestershire B98 9PB
Tel. (+44) 1527 65022 - Fax (+44) 1527 61995
www.bonfiglioli.co.uk
Mobile, Wind
3 - 7 Grosvenor Grange, Woolston
Warrington - Cheshire WA1 4SF
Tel. (+44) 1925 852667 - Fax (+44) 1925 852668
www.bonfiglioli.co.uk

Bonfiglioli USA

3541 Hargrave Drive Hebron, Kentucky 41048
Tel. (+1) 859 334 3333 - Fax (+1) 859 334 8888
www.bonfiglioliusa.com

Bonfiglioli Vietnam

Lot C-9D-CN My Phuoc Industrial Park 3
Ben Cat - Binh Duong Province
Tel. (+84) 650 3577411 - Fax (+84) 650 3577422
www.bonfiglioli.vn



Bonfiglioli has been designing and developing innovative and reliable power transmission and control solutions for industry, mobile machinery and renewable energy applications since 1956.